Precision Balances and Comparators

XPR






Table of Contents

1	Introd	lustian	7
•		luction	
	1.1	Further documents and information	7
	1.2	Explanation of conventions and symbols used	7
	1.3	Acronyms and abbreviations	8
	1.4	Product range	8
		1.4.1 XPR precision balances	8
		1.4.1.1 S weighing platform	8
		1.4.1.2 L weighing platform	9
		1.4.2 XPR precision comparators	10
		1.4.2.1 S weighing platform	10
		1.4.2.2 L weighing platform	10
	1.5	Compliance information	11
2	Safety	y Information	12
_	2.1	Definitions of signal words and warning symbols	12
	2.2		12
	2.2	Product-specific safety information	12
3	Desig	n and Function	14
	3.1	Function description	14
	3.2	Overview S weighing platform	14
		3.2.1 Balances with Pro draft shield	14
		3.2.2 Comparators with Pro draft shield	15
		3.2.3 Balances without Pro draft shield	16
		3.2.4 Interface board	17
	3.3	Overview L weighing platform	17
		3.3.1 Balances	17
		3.3.2 Comparators	18
		3.3.3 Interface board	18
	3.4	Overview terminal	19
	3.5	Overview type plate	19
	3.6	User interface	20
	5.0	3.6.1 Main sections at a glance	20
		0	21
			22
		3.6.4 Work screen "Methods"	22
		3.6.5 Work screen "Protocol"	23
		3.6.6 Icons and symbols	23
		3.6.6.1 System status icons	23
		3.6.6.2 Weighing status icons	24
4	Instal	lation and Putting into Operation	25
	4.1	Selecting the location	25
	4.2	Unpacking the balance	25
	4.3	Scope of delivery	26
		4.3.1 Balances with S weighing platform	26
		4.3.2 Comparators with S weighing platform	26
		4.3.3 Balances with L weighing platform	27
		4.3.4 Comparators with L weighing platform	27
	4.4	Installation	27
	7.4	4.4.1 Balances with S weighing platform	27
		3	27
		0 01	21
		4.4.1.2 Assembling balances 0.1 mg with Pro draft shield and SmartPan weighing pan	28
		4.4.1.3 Assembling balances 1 mg with Pro draft shield	30
		4.4.1.4 Assembling comparators 0.1 mg and 1 mg with LevelMatic weighing pan	31
		/ Coomsing comparation of this will be working pull	J 1

		4.4.1.5	Assembling balances 1 mg with SmartPan weighing pan	31
		4.4.1.6	Assembling balances 5 mg and 10 mg with SmartPan weighing pan	32
		4.4.1.7	Assembling balances 100 mg	32
		4.4.2	Balances with L weighing platform	33
		4.4.2.1	Attaching the terminal to the weighing platform	33
		4.4.2.2	Assembling balances 100 mg and 1 g	33
		4.4.2.3	Assembling balances 10 mg with SmartPan weighing pan	34
		4.4.2.4	Removing and installing the transport safety screws (only for comparators)	34
		4.4.2.5	Assembling comparators 1 mg / 5 mg with LevelMatic weighing pan	35
	4.5	Puttina in	to operation	35
		4.5.1	Connecting the balance	
		4.5.2	Switching on the balance	
		4.5.3	Logging in	
		4.5.4	Leveling the balance	
		4.5.5	Performing an internal adjustment	
		4.5.6	Setting the balance to standby mode	
		4.5.7	Switching off the balance	
	16		· · · · · · · · · · · · · · · · · · ·	
	4.6	4.6.1	ng a simple weighing	
		4.6.1	Zeroing the balance	
			Taring the balance	
		4.6.3	Performing a weighing	
	4 7	4.6.4	Completing the weighing	
	4.7		ing, packing and storing	38
		4.7.1	Transporting the balance over short distances	
		4.7.2	Transporting the balance over long distances	
		4.7.3	Packing and storing	
	4.8		below the balance	
		4.8.1	S weighing platform	
		4.8.2	L weighing platform	40
5	Onor	ntion		41
5	Opero		****	41
5	Oper (5.1	Touch sci	reen	41
5	_	Touch sci 5.1.1	Selecting or activating an item	41 41
5	_	Touch sci 5.1.1 5.1.2	Selecting or activating an item	41 41 41
5	_	Touch sci 5.1.1 5.1.2 5.1.3	Selecting or activating an item Scrolling Using the drawers	41 41 41 41
5	_	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers	41 41 41 41 42
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time	41 41 41 42 42
5	_	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time	41 41 41 42 42 43
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview	41 41 41 42 42 43 43
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing"	41 41 41 42 42 43 43 43
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing"	41 41 41 42 42 43 43 43
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1 5.2.2.2	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing"	41 41 41 42 42 43 43 43 44 44
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Method "Simple formulation"	41 41 41 42 42 43 43 43 44 44
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1 5.2.2.2	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Method "Simple formulation" Creating a method "Simple formulation"	41 41 41 42 42 43 43 43 44 44
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1 5.2.2.2 5.2.3	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Method "Simple formulation" Creating a method "Simple formulation"	41 41 41 42 43 43 43 44 44 45
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1 5.2.2.2 5.2.3 5.2.3.1	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Method "Simple formulation" Creating a method "Simple formulation" Performing a "Simple formulation" Method "Piece counting"	41 41 42 42 43 43 44 44 45
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1 5.2.2.2 5.2.3.1 5.2.3.2	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Method "Simple formulation" Creating a method "Simple formulation" Performing a "Simple formulation" Method "Piece counting"	41 41 41 42 42 43 43 43 44 44 45 45
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1 5.2.2.2 5.2.3 5.2.3.1 5.2.3.2 5.2.4	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Method "Simple formulation" Creating a method "Simple formulation" Performing a "Simple formulation" Method "Piece counting" Creating a method "Piece counting"	411 411 412 422 433 433 444 445 456 466 47
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1 5.2.2.2 5.2.3 5.2.3.1 5.2.3.2 5.2.4 5.2.4.1	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Method "Simple formulation" Creating a method "Simple formulation" Performing a "Simple formulation" Method "Piece counting" Creating a method "Piece counting" Performing a "Piece counting"	41 41 41 42 42 43 43 44 44 45 45 46 47 47
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1 5.2.2.2 5.2.3 5.2.3.1 5.2.3.2 5.2.4 5.2.4.1 5.2.4.2	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Method "Simple formulation" Creating a method "Simple formulation" Performing a "Simple formulation" Performing a method "Piece counting" Creating a method "Piece counting" Performing a "Piece counting" Method "Interval weighing"	41 41 41 42 42 43 43 44 44 45 45 46 47 47
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1 5.2.2.2 5.2.3.1 5.2.3.2 5.2.3.1 5.2.3.2 5.2.4.1 5.2.4.2 5.2.5	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Method "Simple formulation" Creating a method "Simple formulation" Performing a "Simple formulation" Performing a "Simple formulation" Performing a "Piece counting" Creating a method "Piece counting" Performing a "Piece counting" Creating a method "Interval weighing" Creating a method "Interval weighing"	411 411 422 422 433 434 444 455 456 477 477 477 488 48
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1 5.2.2.2 5.2.3 5.2.3.1 5.2.3.2 5.2.4 5.2.4.1 5.2.4.2 5.2.5.5	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Method "Simple formulation" Creating a method "Simple formulation" Performing a "Simple formulation" Performing a "Simple formulation" Performing a "Piece counting" Creating a method "Piece counting" Performing a "Piece counting" Creating a method "Interval weighing" Creating a method "Interval weighing" Performing a "Interval Weighing"	411 411 422 433 433 444 455 466 477 477 478 488 499
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1 5.2.2.2 5.2.3 5.2.3.1 5.2.3.2 5.2.4 5.2.4.1 5.2.4.2 5.2.5 5.2.5.1 5.2.5.2 5.2.5 5.2.6	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Method "Simple formulation" Creating a method "Simple formulation" Performing a "Simple formulation" Performing a "Simple formulation" Performing a "Piece counting" Creating a method "Piece counting" Performing a "Piece counting" Creating a method "Interval weighing" Performing a method "Interval weighing" Performing an "Interval weighing" Performing an "Interval Weighing" Method "Titration"	411 411 422 423 433 434 444 455 466 477 477 488 489 49
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2 5.2.3 5.2.3.1 5.2.3.2 5.2.4 5.2.4.1 5.2.4.2 5.2.5 5.2.5 5.2.5.1 5.2.5.2 5.2.6 5.2.6.1	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Method "Simple formulation" Creating a method "Simple formulation" Performing a "Simple formulation" Method "Piece counting" Creating a method "Piece counting" Performing a "Piece counting" Creating a method "Piece counting" Performing a "Interval weighing" Creating a method "Interval weighing" Performing an "Interval Weighing" Method "Titration" Creating a method "Titration"	411 411 422 433 433 444 445 456 477 477 478 489 499 50
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1 5.2.2.2 5.2.3 5.2.3.1 5.2.3.2 5.2.4 5.2.4.1 5.2.4.2 5.2.5 5.2.5.1 5.2.5.2 5.2.6 5.2.6.1 5.2.6.2	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Creating a method "Simple formulation" Creating a method "Simple formulation" Performing a "Simple formulation" Method "Piece counting" Creating a method "Piece counting" Performing a "Piece counting" Performing a "Piece counting" Method "Interval weighing" Creating a method "Interval weighing" Performing an "Interval Weighing" Method "Titration" Creating a method "Titration" Creating a method "Titration" Performing a "Titration"	411 411 422 433 433 434 444 455 466 477 477 478 489 499 500 500
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1 5.2.2.2 5.2.3 5.2.3.1 5.2.3.2 5.2.4 5.2.4.1 5.2.4.2 5.2.5 5.2.5.1 5.2.5.2 5.2.6 5.2.6.1 5.2.6.2 5.2.7	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Method "Simple formulation" Creating a method "Simple formulation" Performing a "Simple formulation" Method "Piece counting" Creating a method "Piece counting" Performing a "Piece counting" Method "Interval weighing" Creating a method "Interval weighing" Performing an "Interval weighing" Performing an "Interval Weighing" Method "Titration" Creating a method "Titration" Performing a "Titration" Method "Density determination"	411 411 422 433 433 434 444 45 45 467 477 477 478 489 499 500 501
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1 5.2.2.2 5.2.3 5.2.3.1 5.2.3.2 5.2.4 5.2.4.1 5.2.4.2 5.2.5 5.2.5.1 5.2.5.2 5.2.6 5.2.6.1 5.2.6.2 5.2.7 5.2.7.1	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Method "Simple formulation" Creating a method "Simple formulation" Performing a "Simple formulation" Method "Piece counting" Creating a method "Piece counting" Performing a "Piece counting" Method "Interval weighing" Creating a method "Interval weighing" Performing a "Interval weighing" Performing a method "Interval weighing" Performing a method "Interval weighing" Method "Titration" Creating a method "Titration" Performing a "Titration" Performing a "Titration" Method "Density determination" Creating a method "Density determination"	411 411 412 422 433 434 444 455 456 477 477 478 489 499 500 511 511
5	5.1	Touch sci 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 Methods 5.2.1 5.2.2 5.2.2.1 5.2.2.2 5.2.3 5.2.3.1 5.2.3.2 5.2.4 5.2.4.1 5.2.4.2 5.2.5 5.2.5.1 5.2.5.2 5.2.6 5.2.6.1 5.2.6.2 5.2.7	Selecting or activating an item Scrolling Using the drawers Entering characters and numbers Changing the date and time Methods overview Method "General weighing" Creating a method "General weighing" Performing a "General weighing" Method "Simple formulation" Creating a method "Simple formulation" Performing a "Simple formulation" Method "Piece counting" Creating a method "Piece counting" Performing a "Piece counting" Method "Interval weighing" Creating a method "Interval weighing" Performing an "Interval weighing" Performing an "Interval Weighing" Method "Titration" Creating a method "Titration" Performing a "Titration" Method "Density determination"	411 411 412 422 433 434 444 455 456 477 477 477 478 488 499 500 511 511 52

	5.2.9	Cloning a method	52
	5.2.10	Deleting a method	
	5.2.11	Deleting a task	
	5.2.12	Using method templates	
	5.2.12.1	Defining a template during the method-defining process	53
	5.2.12.2	Defining a template in a current task	54
	5.2.12.3	Working with templates	54
5.3		Working Will fortification	54
0.0	5.3.1	Overview routine tests	54
	5.3.1.1	Eccentricity test	55
	5.3.1.2		55
	5.3.1.3	Repeatability test	55
	5.3.1.3	Sensitivity tests	
		Creating an own new test	
	5.3.3	Defining a test weight	
	5.3.4	Performing a test	
	5.3.4.1	Performing an eccentricity test	57
	5.3.4.2	Performing a repeatability test	58
	5.3.4.3	Performing a sensitivity test	59
	5.3.5	Editing a test	61
	5.3.6	Printing test results	61
	5.3.7	Deleting a test	61
	5.3.8	Consulting the test history	61
5.4	-	nts	61
	5.4.1	Internal adjustment	
	5.4.1.1	Editing an internal adjustment	62
	5.4.1.2	Performing an internal adjustment	62
	5.4.2	External adjustment	
	5.4.2.1	Editing an external adjustment	62
	5.4.2.2	Performing a external adjustment	63
	5.4.3	Consulting the adjustment history	63
5.5	External d	evices	63
	5.5.1	Adding a device	63
	5.5.2	Deleting a device	64
	5.5.3	Editing device settings	64
	5.5.4	Printing a test page	64
	5.5.5	Using an RFID reader	64
	5.5.5.1	Testing an RFID reader	64
5.6	User man	agement	65
	5.6.1	Activating the user management	65
	5.6.2	Disabling the user management	66
	5.6.3	Managing users and user groups	66
	5.6.3.1	Creating a new user	66
	5.6.3.2	Creating a new group	66
	5.6.3.3	Deleting users or user groups	67
5.7		profiles	67
5.8		agement	67
0.0	5.8.1	Exporting data and settings	67
	5.8.2	Importing data and settings	68
5.9		protection and balance reset	68
5.5	5.9.1	Password protection	68
	5.9.1.1	Changing a password	68
	5.9.1.1	Requesting a reset password	69
	5.9.1.2	Creating an unblocking password	69
	5.9.1.3		69
	5.9.2.1	Logging in and logging out	69
	5.9.2.1	Logging in	
	5.9.2.2 5.9.3	Logging out	69 69
	. 1 🕶 🤿	CALLE MODEL COURT TO BE FOUND TO THE COURT OF THE COURT O	nv

		5.9.3.1	Blocking the balance	70
		5.9.3.2	Unblocking the balance	70
		5.9.4	Resetting the balance	70
6	Softw	are descri		71
	6.1	Balance r	menu settings	71
		6.1.1	Leveling aid	71
		6.1.2	History	71
		6.1.2.1	Adjustments	71
		6.1.2.2	Tests	72
		6.1.2.3	Alibi memory	72
		6.1.2.4	Service	73
		6.1.2.5	Changes	73
		6.1.3	Balance info	74
		6.1.4	Users	
		6.1.4.1	General	74
		6.1.4.2	Users	75
		6.1.4.3	Groups	75
		6.1.5	Settings	76
		6.1.5.1	Balance	76
		6.1.5.2	Interfaces	82
		6.1.5.3	Devices / Printers	83
		6.1.5.4		84
			LabX / Services	
		6.1.5.5	Printing the settings	85
		6.1.6	Maintenance	85
	0.0	6.1.6.1	Service menu	85
	6.2		methods settings	85
		6.2.1	Settings: method "General weighing"	85
		6.2.1.1	General	86
		6.2.1.2	ID format	86
		6.2.1.3	Weighing item	87
		6.2.1.4	Templates	88
		6.2.1.5	Weighing	88
		6.2.1.6	Automation	91
		6.2.1.7	Print / Export	93
		6.2.2	Settings: method "Simple formulation"	96
		6.2.2.1	General	97
		6.2.2.2	Formulation	97
		6.2.2.3	ID format	98
		6.2.2.4	Weighing item	99
		6.2.2.5	Templates	99
		6.2.2.6	Weighing	100
		6.2.2.7	Automation	101
		6.2.2.8	Print / Export	101
		6.2.3	·	_
		6.2.3.1	General	105
		6.2.3.2	ID format	106
		6.2.3.3	Weighing item	107
		6.2.3.4	Weighing	107
		6.2.3.5	Automation	109
		6.2.3.6	Print / Export	110
		6.2.4	3	113
		6.2.4.1	General	114
		6.2.4.2	Interval	114
		6.2.4.3	ID format	114
		6.2.4.4	Weighing item	115
		6.2.4.5	Weighing	115
		6.2.4.6	Automation	116

		6.2.4.7	Print / Export	1	16
		6.2.5	Settings: method "Titration"	1	17
		6.2.5.1	General	1	17
		6.2.5.2	Titration		
		6.2.5.3	ID format		
		6.2.5.4	Weighing item		
		6.2.5.5	Automation		
		6.2.5.6	Print / Export		
		6.2.6	Settings: method "Density determination"		
		6.2.6.1	General		
		6.2.6.2	Density		
		6.2.6.3 6.2.6.4	ID format		
		6.2.6.5	Weighing item		
		6.2.6.6	Automation		
		6.2.6.7	Print / Export		
	6.3		ings		
	0.0	6.3.1	Settings: eccentricity test		
		6.3.2	Settings: repeatability test		
		6.3.3	Settings: sensitivity test		
	6.4		nts settings		
7		enance			40
	7.1		nce tasks		
	7.2	_	Disconnection that Does doubt ability for all angles		
		7.2.1	Disassembling the Pro draft shield for cleaning		
		7.2.2 7.2.3	Cleaning agents		
		7.2.3 7.2.4	Cleaning the balance Putting into operation after cleaning		
	7.3		update		
	7.5	7.3.1	Updating the software		
		7.3.2	Restoring the software to the previous version		
		7.3.3	Putting into operation after software update		
			<u> </u>		_
8		leshooting			45
	8.1		sages		
	8.2		ptoms		
	8.3	Putting in	to operation after fixing an error	I4	4 /
9	Techn	ical Data		14	48
	9.1		ata		
	9.2		pry notes for the METTLER TOLEDO AC/DC adapter		
	9.3		ecific data		
		9.3.1	Balances with S weighing platform	1	50
		9.3.1.1	Readability 0.1 mg, with Pro draft shield		
				1.1	50
		9.3.1.2	Readability 1 mg, with Pro draft shield and SmartPan weighing pan		
		9.3.1.2 9.3.1.3	Readability 1 mg, with Pro draft shield and SmartPan weighing pan Readability 1 mg, with SmartPan weighing pan		
			Readability 1 mg, with SmartPan weighing panReadability 5 mg, with SmartPan weighing pan	1 <i>!</i>	54 55
		9.3.1.3 9.3.1.4 9.3.1.5	Readability 1 mg, with SmartPan weighing pan	15 15	54 55 56
		9.3.1.3 9.3.1.4 9.3.1.5 9.3.1.6	Readability 1 mg, with SmartPan weighing pan	1! 1! 1!	54 55 56 59
		9.3.1.3 9.3.1.4 9.3.1.5 9.3.1.6 9.3.2	Readability 1 mg, with SmartPan weighing pan	18 18 18 18	54 55 56 59
		9.3.1.3 9.3.1.4 9.3.1.5 9.3.1.6 9.3.2 9.3.2.1	Readability 1 mg, with SmartPan weighing pan Readability 5 mg, with SmartPan weighing pan Readability 10 mg, with SmartPan weighing pan Readability 100 mg Comparators with S weighing platform Redability 0.1 mg, with Pro draft shield	18 18 18 18 18	54 56 59 61
		9.3.1.3 9.3.1.4 9.3.1.5 9.3.1.6 9.3.2 9.3.2.1 9.3.2.2	Readability 1 mg, with SmartPan weighing pan Readability 5 mg, with SmartPan weighing pan Readability 10 mg, with SmartPan weighing pan Readability 100 mg Comparators with S weighing platform Redability 0.1 mg, with Pro draft shield Readability 1 mg	18 18 18 18 16 16	54 55 56 59 61 63
		9.3.1.3 9.3.1.4 9.3.1.5 9.3.1.6 9.3.2 9.3.2.1 9.3.2.2 9.3.3	Readability 1 mg, with SmartPan weighing pan Readability 5 mg, with SmartPan weighing pan Readability 10 mg, with SmartPan weighing pan Readability 100 mg Comparators with S weighing platform Redability 0.1 mg, with Pro draft shield Readability 1 mg Balances with L weighing platform	18 18 18 18 16 16 16	54 55 56 61 63 64
		9.3.1.3 9.3.1.4 9.3.1.5 9.3.1.6 9.3.2 9.3.2.1 9.3.2.2 9.3.3 9.3.3.1	Readability 1 mg, with SmartPan weighing pan. Readability 5 mg, with SmartPan weighing pan. Readability 10 mg, with SmartPan weighing pan. Readability 100 mg Comparators with S weighing platform Redability 0.1 mg, with Pro draft shield Readability 1 mg Balances with L weighing platform Readability 10 mg, with SmartPan weighing pan.	18 18 18 16 16 16 16	54 55 56 59 61 63 64
		9.3.1.3 9.3.1.4 9.3.1.5 9.3.1.6 9.3.2 9.3.2.1 9.3.2.2 9.3.3	Readability 1 mg, with SmartPan weighing pan Readability 5 mg, with SmartPan weighing pan Readability 10 mg, with SmartPan weighing pan Readability 100 mg Comparators with S weighing platform Redability 0.1 mg, with Pro draft shield Readability 1 mg Balances with L weighing platform	18 18 18 16 16 16 16 16	54 55 56 59 61 63 64 65

		9.3.4.1	Redability 1 mg	168
		9.3.4.2	Readability 5 mg	169
		9.3.4.3	Readability 10 mg	170
	9.4	Dimension	ns	171
		9.4.1	Balances with S weighing platform	171
		9.4.1.1	Readability 0.1 mg, with Pro draft shield and SmartPan weighing pan	171
		9.4.1.2	Readabilty 1 mg, with Pro draft shield and SmartPan weighing pan	
		9.4.1.3	Readabilty 1 mg, with SmartPan weighing pan	173
		9.4.1.4	Readabilty 5 mg / 10 mg, with SmartPan weighing pan	
		9.4.1.5	Readability 100 mg	
		9.4.2	Comparators with S weighing platform	
		9.4.2.1	Readability 0.1 mg, with Pro draft shield and LevelMatic weighing pan	176
		9.4.2.2	7 9,	
		9.4.2.3	Readability 1 mg, with XP-W12 draft shield and LevelMatic weighing pan	
		9.4.2.4	Readability 1 mg, with Pro draft shield	179
		9.4.3	Balances with L weighing platform	180
		9.4.3.1	Readability 10 mg, with SmartPan weighing pan	
		9.4.3.2	Readability 100 mg / 1 g	
		9.4.4	Comparators with L weighing platform	182
		9.4.4.1	Readability 1 mg / 5 mg, with XP-W64 draft shield and LevelMatic weighing	100
		9.4.4.2	pan	
		9.4.4.2	Readability 5 mg / 10 mg Draft shield XP-W12 (for models with S weighing platform)	
		9.4.6	Draft shield XP-W64 (for models with L weighing platform))	
		3.4.0	Totali siliela XF-W04 (loi filodeis Willi E Weighing planoffil)	100
10	Dispo	sal		186
11	Acces	sories and	Spare Parts	187
	11.1		9S	_
	11.2		ts	
		11.2.1	Balances S weighing platform	
		11.2.2	Comparators S weighing platform	
		11.2.3	S Platform miscellaneous	
		11.2.4	Balances L weighing platform	
		11.2.5	Comparators L weighing platform	
		11.2.6	L platform miscellaneous	
		11.2.7	Pro draft shield	
		11.2.8	Packaging	
		11.2.8.1	S platform with draft shield	
		11.2.8.2	S platform without draft shield	
		11.2.8.3	L platform, readability 10 mg	
		11.2.8.4	L platform, readability 100 mg and 1g	204
	Index			205

1 Introduction

Thank you for choosing a METTLER TOLEDO balance. The balance combines high performance with ease of use.

This document is based on the software version V 2.0.204.

Disclaimer for comparators

In this document, the term "balance" is used to describe both balances and comparators.

Comparators are characterized by their higher resolution compared to balances and are mainly used for differential weighing application, such as the calibration of standard weights. Beside standard balance tests, comparators have also been tested with differential repeatability (ABA repeatability) during production.

EULA

The software in this product is licensed under the METTLER TOLEDO End User License Agreement (EULA) for Software.

www.mt.com/EULA

When using this product you agree to the terms of the EULA.

1.1 Further documents and information

www.mt.com/xpr-precision

This document is available in other languages online.

www.mt.com/XPR-precision-RM

Search for software downloads

www.mt.com/labweighing-software-download

Search for documents

www.mt.com/library

For further questions, please contact your authorized METTLER TOLEDO dealer or service representative.

www.mt.com/contact

1.2 Explanation of conventions and symbols used

Conventions and symbols

Key and/or button designations and display texts are shown in graphic or bold text, e.g., /, Edit.

Note For useful information about the product.



Refers to an external document.

Elements of instructions

In this manual, step-by-step instructions are presented as follows. The action steps are numbered and can contain prerequisites, intermediate results and results, as shown in the example. Sequences with less than two steps are not numbered.

- Prerequisites that must be fulfilled before the individual steps can be executed.
- 1 Step 1
 - ⇒ Intermediate result
- 2 Step 2
- ⇒ Result

1.3 Acronyms and abbreviations

Original term	Explanation
ASTM	American Society for Testing and Materials
EMC	Electromagnetic Compatibility
FCC	Federal Communications Commission
GWP	Good Weighing Practice
ID	Identification
LPS	Limited Power Source
MT-SICS	METTLER TOLEDO Standard Interface Command Set
NA	Not Applicable
OIML	Organisation Internationale de Métrologie Légale (International Organization of Legal Metrology)
RFID	Radio-frequency identification
RM	Reference Manual
RS (RS232C)	Recommended Standard (RS232C)
sd	Standard deviation
SELV	Safety Extra Low Voltage
SOP	Standard Operating Procedure
UM	User Manual
USB	Universal Serial Bus
USP	United States Pharmacopeia

1.4 Product range

1.4.1 XPR precision balances

1.4.1.1 S weighing platform

Balance	Models designation
	Readability: 0.1 mg • XPR204S
	• XPR404S
aar,	XPR504SXPR504SDR
aut.	Readability: 1 mg

Balance	Models designation
axi	Readability: 1 mg • XPR303SN • XPR603SN • XPR603SNDR
	Readability: 1 mg • XPR3003SD5 • XPR6003SD5
	Readability: 10 mg • XPR1202S • XPR2002S • XPR4002S • XPR6002S • XPR6002SDR • XPR8002S • XPR10002S
00,	Readability: 100 mg • XPR4001S • XPR6001S • XPR8001S • XPR10001S

1.4.1.2 L weighing platform


Balance	Models designation
	Readability: 10 mg • XPR15002L • XPR20002LDR
	Readability: 100 mg
	Readability: 1 g • XPR32000L • XPR64000L

1.4.2 XPR precision comparators

1.4.2.1 S weighing platform



1.4.2.2 L weighing platform



Balance	Models designation
	Readability: 1 mg
	• XPR32003LD5C
	Readability: 10 mg
	• XPR64002LC
	Readability: 10 mg
	• XPR64002LC-T
285	
400	
1000	

1.5 Compliance information

National approval documents, e.g., the FCC Supplier Declaration of Conformity, are available online and/or included in the packaging.

► http://www.mt.com/ComplianceSearch

Contact METTLER TOLEDO for questions about the country-specific compliance of your instrument.

www.mt.com/contact

United States of America

This equipment has been tested and found to comply with the limits for a **Class A** digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Canada

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- 1. This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

2 Safety Information

Two documents named "User Manual" and "Reference Manual" are available for this instrument.

- The User Manual is printed and delivered with the instrument.
- The electronic Reference Manual contains a full description of the instrument and its use.
- Keep both documents for future reference.
- Include both documents if you transfer the instrument to other parties.

Only use the instrument according to the User Manual and the Reference Manual. If you do not use the instrument according to these documents or if the instrument is modified, the safety of the instrument may be impaired and Mettler-Toledo GmbH assumes no liability.

2.1 Definitions of signal words and warning symbols

Safety notes contain important information on safety issues. Ignoring the safety notes may lead to personal injury, damage to the instrument, malfunctions and false results. Safety notes are marked with the following signal words and warning symbols:

Signal words

DANGER A hazardous situation with high risk, resulting in death or severe injury if not avoided.

WARNING A hazardous situation with medium risk, possibly resulting in death or severe injury if

not avoided.

CAUTION A hazardous situation with low risk, resulting in minor or moderate injury if not avoided.

NOTICE A hazardous situation with low risk, resulting in damage to the instrument, other

material damage, malfunctions and erroneous results, or loss of data.

Warning symbols



General hazard: read the User Manual or the Reference Manual for information about the hazards and the resulting measures.



Electrical shock



Notice

2.2 Product-specific safety information

Intended use

This instrument is designed to be used by trained staff. The instrument is intended for weighing purposes. Any other type of use and operation beyond the limits of use stated by Mettler-Toledo GmbH without consent from Mettler-Toledo GmbH is considered as not intended.

Responsibilities of the instrument owner

The instrument owner is the person holding the legal title to the instrument and who uses the instrument or authorizes any person to use it, or the person who is deemed by law to be the operator of the instrument. The instrument owner is responsible for the safety of all users of the instrument and third parties.

METTLER TOLEDO assumes that the instrument owner trains users to safely use the instrument in their workplace and deal with potential hazards. METTLER TOLEDO assumes that the instrument owner provides the necessary protective gear.

Safety notes



WARNING

Death or serious injury due to electric shock

Contact with parts that carry a live current can lead to death or injury.

- Only use the METTLER TOLEDO power supply cable and AC adapter designed for your instrument.
- 2 Connect the power cable to a grounded power outlet.
- 3 Keep all electrical cables and connections away from liquids and moisture.
- 4 Check the cables and the power plug for damage and replace damaged cables and power plugs.



NOTICE

Damage to the instrument due to the use of unsuitable parts

Using unsuitable parts with the instrument can damage the instrument or cause it to malfunction.

- Only use parts from METTLER TOLEDO that are intended to be used with your instrument.

3 Design and Function

3.1 Function description


The XPR line comprises a range of balances that differ from each other due to their weighing range and resolution. The balances of the XPR line combine a large number of weighing and adjustment possibilities with a simple operation handling.

The following features are common to all models of the XPR precision line:

- Fully automatic adjustment using internal weights.
- Built-in level sensor and leveling aid for fast and easy leveling.
- 7-inch capacitive color TFT-touch screen.
- · Various methods that can be defined individually.
- Various routine tests that can be defined individually.
- Functions to manage user groups and user rights.
- History about performed tests and adjustments, as well as changes applied to the balance settings.

3.2 Overview S weighing platform


3.2.1 Balances with Pro draft shield




1	DripTray	6	Pro draft shield
2	SmartPan weighing pan	7	Weighing platform with protective cover
3	Weighing pan	8	Leveling foot
4	Pro draft shield door handle	9	Terminal with protective cover
5	Pro draft shield door		

3.2.2 Comparators with Pro draft shield

0.1 mg / 1 mg







1	Bottom plate 7 Pro draft shield door handle		Pro draft shield door handle
2	Pro draft shield door		Pro draft shield door
3	LevelMatic weighing pan holder	9	Pro draft shield
4	4 SmartPan weighing pan 10 Weighing platform with protective		Weighing platform with protective cover
5	LevelMatic weighing pan	11	Leveling foot
6	Weighing pan	12	Terminal with protective cover

3.2.3 Balances without Pro draft shield


1 mg



5 mg / 10 mg




100 mg



1	Weighing pan support cap	6	Safety foot
2	DripTray	7	Weighing platform with protective cover
3	SmartPan weighing pan	8	Fastening plate with position screws
4	Weighing pan support	9	Leveling foot
5	Weighing pan with protective cover	10	Terminal with protective cover


3.2.4 Interface board



1	Ethernet port	5	USB-B port (to host)
2	USB-A ports (to device)	6	Socket for terminal connection cable
3	Fixations for optional terminal stand	7	Socket for AC/DC adapter
4	Service seal		

3.3 Overview L weighing platform


3.3.1 Balances



1	Weighing pan support cap	6	Weighing pan
2	Adapter plate	plate 7 Weighing platform	
3	Draft shield element	8	Leveling foot
4	4 SmartPan weighing pan 9 Terminal with protective cover		Terminal with protective cover
5	Weighing pan with protective cover		

3.3.2 Comparators


1 mg / 5 mg / 10 mg



3.3.3 Interface board


5

LevelMatic weighing pan holder



1 Socket for AC/DC adapter 4 USB-B port (to host)			
2	Socket for terminal connection cable	5	USB-A ports (to device)
3 Service seal		6	Ethernet port

3.4 Overview terminal




	Name	Description	
, , , , , ,		By tapping \circlearrowleft the balance is not completely switched off but goes into standby mode. To switch the balance completely off, it must be unplugged from the power	
		Note Do not disconnect the balance from the power supply unless the balance is not used for an extended period of time.	
→T←	Tare	Tares the balance. This function is used when the weighing process involves containers. After taring the balance, the screen shows Net which indicates that all displayed weights are net.	
→0 ←	Zero	Zeroes the balance. The balance must always be zeroed before starting the weighing process. After zeroing, the balance sets a new zero point.	
	Home	To return from any menu level to the main weighing screen.	

3.5 Overview type plate

The information on the type plate helps to identify the balance and terminal.

Terminal type plate


The terminal type plate is located on the terminal and contains the following information:



- 1. Terminal type
- 2. Terminal serial number

Weighing unit type plate

The balance type plate is located on the side of the weighing unit and contains the following information:




- 1. Designation of balance model
- 2. Year of manufacture
- 3. Readability
- 4. Maximum capacity
- Manufacturer
- Balance type
- 7. Serial number
- 3. Power supply

3.6 User interface

3.6.1 Main sections at a glance

The main weighing screen (1) is the central navigation point where all the menus and settings can be found. The **Balance menu** (2), **Methods** (3) and **Protocol** (4) open when tapping the drawers along the sides of the main weighing screen.



See also

- Main weighing screen ▶ Page 21
- Work screen "Balance menu" ▶ Page 22
- Work screen "Methods" ▶ Page 22
- Work screen "Protocol" ▶ Page 23

3.6.2 Main weighing screen



	Name	Description	
1	User name	Shows the name of the current user.	
2	Weighing value field	Shows the current weighing value.	
3	Level indicator	Indicates if the balance is leveled (green) or not (red).	
4	Methods menu	Accesses the user-defined list of methods, tests, and alignments.	
5	Info weight	Shows the current weighing value in another unit.	
6	Warning and error message area	Shows current warning and/or error messages.	
7	Drawer Protocol	Shows the recent weighing results.	
8	Sample status OK	Result status indicator green: indicates that the result fulfills a set of criteria. For example:	
		The balance is in level.	
		The internal adjustment was performed and ok.	
		 The weighing result is within the defined tolerance range (only if tolerance is defined). 	
9	Sample status Excluded	Result status indicator black: indicates that the result was excluded from the protocol.	
10	Sample status Not OK	Result status indicator red: indicates that the result criteria are not fulfilled, e.g., "The weighing result was out of the defined tolerances".	
11	Button Add to protocol	Adds the result to the protocol. Depending on the selected method, the button can have different functions.	
12	Weighing action field	Contains actions referring to the current task.	
13	Balance menu	Accesses the balance properties.	
14	Method information area	Contains information about the sample, method or task IDs.	
15	SmartTrac	Used as a weighing aid to define a target weight with upper and lower tolerances.	
16	Weighing value area	Shows the results of the current weighing process.	
17	Method name	Shows the name of the current method.	

3.6.3 Work screen "Balance menu"



	Name	Description	
1	Leveling aid	ing aid Opens the leveling dialog.	
2	History Opens the history dialog.		
3	Balance info Shows Balance information.		
4	Users Opens the user management.		
5	5 Settings Opens the complete settings dialog.		
6	Maintenance Opens the balance maintenance dialog.		
7	Exit / Block balance Opens the logout / block balance dialog.		

3.6.4 Work screen "Methods"



	Name	Description	
1 Methods list Lists the methods already defined by the user.		Lists the methods already defined by the user.	
		Methods can be edited, cloned, started or created.	
2	Tasks	A method/task can be started and then a task is associated with this method. There can be up to one task for each method.	
3 Tests Working with routine test.		Working with routine test.	
		Sensitivity tests	
Repeatability tests		Repeatability tests	
		Eccentricity tests	
	Routine test can be edited, started or created.		
4	4 Adjustments Lists all internal or external adjustments. Adjustment can be edited, created and started.		

3.6.5 Work screen "Protocol"



	Name	Description	
1	Result state	Shows the state of the weighing process.	
2	Sample ID	Shows the Sample ID of the weighing.	
3	3 Gross weight Shows the gross weight.		
		D : indicates that the value was unstable.	
		*: indicates that the value was calculated.	
4	Timestamp	Shows the individual timestamp of each weighing item.	
5	Balance status	Shows stability, level state of the balance, minimum weight, tolerance state and test and adjustment state.	
6	Complete	Opens the dialog Complete task.	
		Print task label manually	
		Print protocol manually	
		Export protocol manually	
7	More	Opens the dialog More .	
		Start adjustment	
		Change display unit	
		Configure tare	
		Configure zero	
		Save as method with templates (only available for methods with the option Templates)	
8	Exclude result	Excludes the current protocol result. A comment can be added to the excluded result, e.g., to describe the reason of the exclusion.	
		Depending on the format of the protocol printout, the excluded result can be printed or not.	
9	Cancel task	Cancels the current running task.	

3.6.6 Icons and symbols

3.6.6.1 System status icons

System messages can appear due to a user action, a user input or a system process. Some messages leave it up to the user to choose upon acting, they will disappear after acknowledging. Other messages remain persistent, so the user can defer them but eventually has to handle them. These messages can be seen in the main status bar on the upper right-hand side of the display.

Icon	Name	Description
0	The balance is out of level.	The balance must be leveled. Information about leveling the balance can be found in the section Leveling the balance. When the balance is leveled the symbol appears.
0	Information	Information messages appear due to user actions or system processes and offer opportunities that are related to the current action or process.
	Warning	Warning messages appear due to user actions or system processes that could lead to a problem that can be prevented.
	Error	Error messages appear due to user actions or system processes that have failed. It is mostly still possible to handle such a problem.

3.6.6.2 Weighing status icons

Weighing status icons appear due to the weight value matching certain quality criteria. The information on the status can be looked by tapping on any of the visible weighing status icons.


Icon	Name	Description
0	Stability indicator	When the stability indicator appears, the balance is not stable. Make sure that the balance is placed at an adequate location. Information about the adequate location can be found in the section Selecting the location.
Net	Net indicator	Appears when the tare key has been pressed and the tare weight has been subtracted.
<	Minimum weight violation	The current weight value undershoots the defined minimum weight definition. Make sure that the weight is not below the minimum weight.
*	Calculated value	The current weight value is calculated. This symbol only appears in the weighing value area when a container has been used with the function Pretare .
GWP X	Balance invalid	The current balance configuration is invalid or quality criteria have not been fulfilled according to the GWP approved definition.
GWP	Weight not ready	The current weight measurement is not ready according to the GWP approved definition. This can be caused by undershooting the minimum weight, an overload or an underload.
GWP	Weight ready	The current weight measurement is ready according to the GWP approved definition. It can be added to the protocol.
4	External ionizer discharging	The external ionizer is currently discharging.

4 Installation and Putting into Operation

4.1 Selecting the location

A balance is a sensitive precision instrument. The location where it is placed will have a profound effect on the accuracy of the weighing results.

Requirements of the location



Sufficient spacing for balances: > 15 cm all around the instrument Take into account the environmental conditions. See "Technical Data".

4.2 Unpacking the balance

Open the balance packaging and check for transportation damage or missing parts. Please inform a METTLER TOLEDO service representative in the event of missing or defective parts.

METTLER TOLEDO recommends retaining the original box with its packaging elements. Use the packaging elements to store and to transport the balance.

4.3 Scope of delivery

4.3.1 Balances with S weighing platform

Components	0.1 mg with Pro draft shield	1 mg with Pro draft shield	1 mg without Pro draft shield	5 mg / 10 mg	100 mg
Weighing platform with protective cover	✓	1	✓	1	✓
Terminal with protective cover	√	1	✓	1	1
Terminal support	✓	1	✓	✓	✓
Terminal connection cable (pre-assembled)	✓	1	✓	1	✓
Pro draft shield	√	1	-	_	_
Weighing pan 127 x 127 mm	_	1	-	_	_
Weighing pan 172 × 205 mm	_	_	_	1	_
Weighing pan 193 × 223 mm	_	_	_	_	✓
SmartPan weighing pan	√	1	✓	1	_
Weighing pan support	_	_	_	_	√
DripTray	√	1	1	1	_
Ring seal	√	_	-	_	_
Weighing hook for below-the-balance weighing	/	1	1	1	1
AC/DC adapter	√	1	1	1	1
Power cable (country-specific)	√	1	✓	1	1
User Manual	1	1	1	1	1
Production certificate	1	1	1	1	1
Declaration of Conformity	✓	1	✓	✓	✓

4.3.2 Comparators with S weighing platform

Components	0.1 mg	1 mg
Weighing platform with protective cover	✓	✓
Terminal with protective cover	✓	✓
Terminal support	✓	✓
Terminal connection cable (pre-assembled)	✓	✓
Pro draft shield (not for XPR10003SC)	✓	✓
Draff shield XP W12 (only for XPR10003SC)	_	✓
SmartPan weighing pan	✓	✓
LevelMatic weighing pan Ø 130 mm (not for XPR2003SC)	✓	✓
Bottom plate	✓	✓
Ring seal	✓	_
Weighing hook for below-the-balance weighing	✓	✓
AC/DC adapter	✓	✓
Power cable (country-specific)	✓	✓
User Manual	✓	✓
Mass calibration software MC Link	✓	✓
Production certificate	✓	✓
Declaration of Conformity	✓	✓

4.3.3 Balances with L weighing platform

Components	10 mg	100 mg / 1 g
Weighing platform	✓	✓
Terminal with protective cover	✓	✓
Terminal support	✓	✓
Terminal connection cable	✓	✓
Draft shield element	✓	_
Weighing pan 172 × 205 mm	✓	_
Weighing pan 280 × 360 mm	_	✓
SmartPan weighing pan	✓	_
AC/DC adapter	✓	✓
Power cable (country-specific)	√	✓
User Manual	✓	✓
Production certificate	1	✓
Declaration of Conformity	✓	✓

4.3.4 Comparators with L weighing platform

Components	1 mg	5 mg	10 mg
Weighing platform	✓	✓	1
Terminal with protective cover	✓	✓	1
Terminal support	✓	✓	1
Terminal connection cable	✓	✓	1
Draft shield element XP W64 (only for XPR26003LC and XPR64003LD5C)	√	✓	_
Weighing pan 280×360 mm (not for XPR64003LD5C and XPR64002LC)	-	√	1
LevelMatic weighing pan Ø 220 mm with draft shield element and weighing pan holder (not for XPR32003LD5C)	√	1	_
Weighing pan Ø 220 mm with draft shield cover (only for XPR64002LC)	-	_	1
AC/DC adapter	✓	✓	1
Power cable (country-specific)	✓	✓	1
Transport case (only for XPR64002LC)	-	_	√
User Manual	✓	✓	1
Mass calibration software MC Link	✓	✓	1
Production certificate	✓	✓	1
Declaration of Conformity	✓	✓	1

4.4 Installation

4.4.1 Balances with S weighing platform

4.4.1.1 Attaching the terminal to the weighing platform

The terminal is usually placed in front of the weighing platform on the terminal support. The terminal can also be placed individually, e.g. beside the weighing platform or it can be fixed on an additional terminal stand.


NOTICE




Damage to the balance

The weighing platform and the terminal are not safely fixed by the terminal support and may fall off when carrying.

- Remove the terminal from the weighing platform and place it on the weighing pan when carrying the balance.
- 1 Place the weighing platform on a flat surface.
- 2 Position the terminal support (1) in front of the weighing platform. The plug of the pre-mounted terminal connection cable (2) must lie between the terminal support (1) and the weighing platform.
- 3 Push the terminal support towards the weighing platform. The far end of the terminal support (3) must be pushed into the lock element (4) at the bottom of the weighing platform.
- 4 Use the terminal connection cable to connect the terminal with the weighing platform.



- 5 Place the terminal on top of the terminal support.
- 6 Push the terminal towards the weighing platform until the terminal locks into the terminal support.
- ⇒ The terminal is mounted and connected to the weighing platform.




4.4.1.2 Assembling balances 0.1 mg with Pro draft shield and SmartPan weighing pan



Note

The 0.1 mg balances with Pro draft shield are equipped with a ring seal. The aim of the ring seal is to isolate the weighing chamber from draft and must always be correctly installed at the bottom of the Pro draft shield.


- 1 Turn the Pro draft shield carefully sideways into horizontal position.
- 2 Push the ring seal (2) through the opening (1) on the bottom of the Pro draft shield.




- 3 Fix the ring seal in the opening of the Pro draft shield. The ring seal (3) must be properly fixed into the opening. The upper edge (4) of the ring seal must lay all around the bottom of the Pro draft shield.
- 4 Turn the Pro draft shield carefully back into vertical position.



- 5 Open the Pro draft shield with the door handles on both sides.
- 6 Hold the Pro draft shield on the top bars (5) on both sides and place it on top of the weighing platform.




- 7 Place the DripTray (6) into the Pro draft shield.
- 8 Place the SmartPan weighing pan (7) into the Pro draft shield on top of the DripTray (6).




4.4.1.3 Assembling balances 1 mg with Pro draft shield

- 1 Open both side doors of the Pro draft shield.
- 2 Hold the Pro draft shield on the top bars (1) on both sides.
- 3 Place the Pro draft shield on top of the weighing platform.




- 4 Place the DripTray (2) into the Pro draft shield.
- 5 Place the SmartPan weighing pan (3) into the Pro draft shield on top of the DripTray (2).
- 6 The weighing pan (4) is optional and can be placed into the Pro draft shield on top of the SmartPan weighing pan (3).




4.4.1.4 Assembling comparators 0.1 mg and 1 mg with LevelMatic weighing pan

- 1 Open both side doors of the Pro draft shield.
- 2 Lift the Pro draft shield by holding on the top bars (1) on both sides.
- 3 Place the Pro draft shield on top of the weighing platform.




- 4 Place the bottom plate (2) into the Pro draft shield.
- 5 Place the LevelMatic holder (3) into the Pro draft shield on top of the bottom plate (2).
- 6 Place the LevelMatic weighing pan (4) into the Prodraft shield on top of the LevelMatic weighing pan holder (3).




4.4.1.5 Assembling balances 1 mg with SmartPan weighing pan

- 1 Place the DripTray (1) on top of the weighing platform.
- 2 Place the SmartPan weighing pan (2) on top of the DripTray (1).
- 3 The weighing pan can be placed on top of the SmartPan weighing pan if needed.




4.4.1.6 Assembling balances 5 mg and 10 mg with SmartPan weighing pan

- 1 Place the weighing pan support caps (1) on top of the weighing platform.
- 2 Place the DripTray (2) on top of the weighing platform.
- 3 Place the SmartPan weighing pan (3) on top of the 4 weighing pan support caps (1).
- 4 Place the weighing pan with the protective cover (4) on top of the SmartPan weighing pan (3).



4.4.1.7 Assembling balances 100 mg

- 1 Place the 4 pan support caps (1) on top of the weighing platform.
- 2 Place the weighing pan support (2) on top of the 4 weighing pan support caps (1).
- 3 Place the weighing pan with the protective cover (3) on top of the weighing pan support (2).




4.4.2 Balances with L weighing platform


4.4.2.1 Attaching the terminal to the weighing platform

The terminal can be attached to the long side or to the short side of the L weighing platform.

- 1 Turn the weighing platform upside down.
- 2 Dismantle the screws (1) on the long side or the screws (2) on the short side of the weighing platform.
- 3 Connect the terminal to the weighing platform with the terminal connection cable.
- 4 Attach the terminal support to the long side or to the short side of the weighing platform. Fix the terminal support with the screws from the weighing platform.








Note

When inserting the terminal connection cable into the cable channel, the terminal connection cable must be inserted simultaneously from both directions. The terminal connection cable must not have any play between the plug and the cable channel (see picture).

6 Turn the weighing platform.


4.4.2.2 Assembling balances 100 mg and 1 g

- 1 Place the weighing pan support caps (1) on top of the weighing platform.
- 2 Place the weighing pan (2) on top of the weighing pan support caps (1).



4.4.2.3 Assembling balances 10 mg with SmartPan weighing pan


- 1 Place the adapter plate (1) on top of the weighing platform.
- 2 Place the weighing pan support caps (2) on top of the adapter plate.
- 3 Place the draft shield element (3) on top of the adapter plate (1).
- 4 Place the SmartPan weighing pan (4) on top of the weighing pan support caps (2).
- 5 Place the weighing pan (5) on top of the SmartPan weighing pan (4) if needed.



4.4.2.4 Removing and installing the transport safety screws (only for comparators)


Transport safety screws are used to prevent damaging the load cell during transport. Before installing the weighing pan, the transport safety screws on top of the weighing platform must be removed. Keep the transport safety screws for transporting the comparator.

- 1 Unscrew and remove the transport safety screws (1) from the top of the weighing platform.
- 2 Close the openings with the enclosed plastic covers.
- 3 Before transporting the comparator, reinstall the transport safety screws.



4.4.2.5 Assembling comparators 1 mg / 5 mg with LevelMatic weighing pan

- 1 Place the adapter plate with the LevelMatic base plate (1) on top of the weighing platform.
- 2 Place the draft shield element (2) on top of the adapter plate (1).
- 3 Place the LevelMatic weighing pan holder (3) on top of the LevelMatic base plate (1).
- 4 Place the LevelMatic weighing pan (4) on top of the LevelMatic weighing pan holder (3).



4.5 Putting into operation

4.5.1 Connecting the balance




↑ WARNING

Death or serious injury due to electric shock

Contact with parts that carry a live current can lead to death or injury.

- 1 Only use the METTLER TOLEDO power supply cable and AC adapter designed for your instrument.
- 2 Connect the power cable to a grounded power outlet.
- 3 Keep all electrical cables and connections away from liquids and moisture.
- 4 Check the cables and the power plug for damage and replace damaged cables and power plugs.
- 1 Install the cables in such a way that they cannot be damaged or interfere with operation.
- 2 Insert the plug of the AC/DC adapter (2) into the power inlet of the instrument (1).
- 3 Secure the plug by firmly tightening the knurled nut.
- 4 Insert the plug of the power cable into a grounded power outlet that is easily accessible.
- ⇒ The balance performs a self-test after connection to the power supply and is then ready to use.





Do not connect the instrument to a power outlet controlled by a switch. After switching on the instrument, it must warm up before giving accurate results.

4.5.2 Switching on the balance

EULA (End User License Agreement)

When the balance is switched on the first time, the EULA (End User License Agreement) appears on the screen.

- 1 Read the conditions.
- 2 Tap I accept the terms in the license agreement, and confirm with **J** OK.

Warming up

Before the balance gives reliable results, it must warm up. This takes at least 30 minutes after connecting the balance (or 60 minutes for comparators). When the balance is switched on from standby, it is ready immediately.

- The balance has warmed up.
- Press (1).
 - ⇒ The main weighing screen appears.

When the balance is switched on, the main weighing screen appears. The display will always show the screen of the method last used before switching it off.

4.5.3 Logging in

If the user management is activated, you have to log in with your user ID before performing a weighing. When the balance starts, the login dialog opens automatically.

- 1 Select a user or tap **User name**.
- 2 Tap Password.
 - ⇒ The input dialog opens.
- 3 Enter your password and tap **V OK**.
- 4 Tap (Login.
 - ⇒ The login dialog closes and you are logged in. Your user ID is shown on the main screen.

The user management can be activated through the balance menu:

Navigation: > Balance menu > 🗘 Settings > 😩 > Balance > 💝 General > User management

See also

- Activating the user management ▶ Page 65
- Users ▶ Page 74

4.5.4 Leveling the balance

Exact horizontal and stable positioning are essential for repeatable and accurate weighing results.

If the message **Balance** is out of level appears:

- 1 Tap ▶ Level the balance.
 - ⇒ The Leveling aid opens.
- 2 Follow the instructions from the wizard.

The leveling aid can also be accessed through the balance menu:

Navigation: ightharpoonup Balance menu $> \ \ \ \$ Leveling aid

4.5.5 Performing an internal adjustment

- The adjustment Strategy is set to Internal adjustment.
- 1 Open the **Methods** section, tap \blacksquare , select the adjustment, and tap \blacktriangleright **Start**

- or -

from the main weighing screen, tap ••• More and tap Start adjustment.

- ⇒ Internal adjustment is being executed.
- ⇒ When the adjustment has been completed, an overview of the adjustment results appears.
- 2 Tap **Print** if you want to print the results.
- 3 Tap Finish adjustment.
- ⇒ The balance is ready.

4.5.6 Setting the balance to standby mode

The balance can be set to standby mode by holding $\mathbf{0}$. The standby mode can be finished by holding $\mathbf{0}$ again.

4.5.7 Switching off the balance

To completely switch off the balance it must be disconnected from the mains. By holding \circlearrowleft the balance goes only into standby mode.



When the balance was completely switched off for some time, it must warm up before it can be used.

See also

Switching on the balance ▶ Page 36

4.6 Performing a simple weighing

4.6.1 Zeroing the balance

- 1 Open the draft shield, if applicable.
- 2 Clear the weighing pan.
- 3 Close the draft shield, if applicable.
- 4 Press $\rightarrow 0 \leftarrow$ to zero the balance.
- \Rightarrow The balance is zeroed.

4.6.2 Taring the balance

If a sample vessel is used, the balance must be tared.

- 1 Open the draft shield, if applicable.
- 2 Clear the weighing pan.
- 3 Close the draft shield, if applicable.
- 4 Press $\rightarrow 0 \leftarrow$ to zero the balance.
- 5 Open the draft shield, if applicable.
- 6 Place the sample vessel on the weighing pan.
- 7 Close the draft shield, if applicable.
- 8 Press \rightarrow **T** \leftarrow to tare the balance.
- ⇒ The balance is fared. The icon Net appears.

4.6.3 Performing a weighing

1 Open the draft shield, if applicable.

- 2 Place the weighing object into the sample vessel.
- 3 Tap + Add to protocol if you want to report the weighing result.
- ⇒ The weight value is listed in the **Protocol**.

4.6.4 Completing the weighing

- 1 To save the weighing protocol, tap **Complete**.
 - ⇒ The window **Complete task** opens.
- 2 Select an option to save or print the protocol.
 - ⇒ The respective menu window opens.
- 3 Follow the instructions of the wizard.
- 4 Tap **✓Complete**
- ⇒ The **Protocol** is saved/printed and then cleared.

4.7 Transporting, packing and storing



NOTICE


Damage to the draft shield, terminal or additional terminal stand

Do not hold the balance only by the glass draft shield, by the terminal or by the terminal stand when carrying the balance.

 Remove the terminal of the S weighing platform from the terminal support and place the terminal on top of the weighing pan. Always hold the weighing platform with both hands when carrying the balance.

4.7.1 Transporting the balance over short distances

- 1 Disconnect the balance from the AC/DC adapter.
- 2 Unplug all interface cables if necessary.
- 3 Remove the terminal from the terminal support element and place the terminal on top of the weighing platform (only for S weighing platform).
- 4 Hold the weighing platform with both hands.
- 5 Carry the balance in horizontal position to the new location.



4.7.2 Transporting the balance over long distances

METTLER TOLEDO recommends using the original packaging for transportation or shipment of the balance or balance components over long distances. The elements of the original packaging are developed specifically for the balance and its components and ensure maximum protection during transportation.

NOTICE



Damage to the comparator

Always install the transport safety screws on top of the weighing platform when transporting the comparator over long distances.

See also

Removing and installing the transport safety screws (only for comparators) > Page 34

4.7.3 Packing and storing

Packing the balance

Store all parts of packaging in a safe place. The elements of the original packaging are developed specifically for the balance and its components, and ensures maximum protection during transportation and storage.

Storing the balance

Only store the balance under the following conditions:

- Indoor and in the original packaging
- According to the environmental conditions, see "Technical Data"



Note

When storing for longer than 6 months, the rechargeable battery may become empty (only date and time get lost).

See also

Technical Data ▶ Page 148

4.8 Weighing below the balance


All models with S weighing platform are equipped with a weighing hook for below-the-balance weighing. Models with L weighing platform are not equipped with a weighing hook. The weighing hook for L weighing platforms can be ordered as an accessory.

See also

Dimensions ▶ Page 171

4.8.1 S weighing platform

- A weighing table or workbench is available, through which the weighing hook can be accessed.
- 1 Disconnect the balance from the AC/DC adapter.
- 2 Remove all elements from the weighing platform, e.g., draft shield, terminal and weighing pan.
- 3 Turn the weighing platform to its side.
- 4 Remove the screws (1) and remove the weighing hook cover (2).
- 5 Turn the weighing platform back on its feet and reinstall all components.
- ⇒ The weighing hook is accessible and can be used for below-the-balance weighing.



4.8.2 L weighing platform




NOTICE

Damage to the comparator

Make sure that the transport arrestments have been correctly removed from the comparator before installing the weighing hook. Otherwise the outstanding transport arrestments might damage the balance or the surface where the balance is placed.

- A weighing table or workbench is available, through which the weighing hook can be accessed.
- 1 Disconnect the balance from the AC/DC adapter.
- 2 Remove all elements from the weighing platform, e.g., draft shield, terminal and weighing pan.
- 3 Turn the weighing platform upside down.
- 4 Remove the screws (1) and remove the weighing hook cover (2).
- 5 Install the weighing hook.
- 6 Turn the weighing platform back on its feet and reinstall all components.
- ⇒ The weighing hook is accessible and can be used for below-the-balance weighing.



5 Operation

5.1 Touch screen


5.1.1 Selecting or activating an item

- Tap the item or function to be selected or activated.



5.1.2 Scrolling


Move the list up/down.




5.1.3 Using the drawers

The drawers are placed along the sides of the main weighing screen.

1 Place the finger on one drawer along one side of the screen, e.g., \blacktriangleleft .



2 Keep the finger on the drawer and slide it in the direction towards which the arrow is pointing.



Note

The drawers can also be opened or closed by tapping the drawer symbol.

5.1.4 Entering characters and numbers



	Name	Description
1	Input field	Shows the data that has been entered.
2	Delete	Deletes the character left of the current curser position. The curser can be positioned by using the touch screen.
3	Discard	Closes the keyboard dialog.
4	Confirm	Confirms the entered data.
5	Numbers and special characters	Switches into the special character mode.
6	Shift	Switches between lower or upper case letters.
7	Menu section title	Shows the title of the current setting section.

5.1.5 Changing the date and time



	Name	Explanation
1	Plus button	Increment
2	Display field	Shows the defined time or date.
3	Minus button	Decrement



The format of date and time can be defined in the settings via the options Date format and Time format.

See also

Date / Time / Language / Format ▶ Page 81

5.2 Methods

A weighing method is an application for carrying out specific weighing tasks. The balance offers the method "General Weighing" with default parameters. You have the possibility to create a maximum of 50 methods and edit the methods. You can use these methods for your weighing task or edit them according to your requirements. Methods can also be deleted or cloned.

To support you while configuring new methods, a configuration wizard leads you through the whole process. The changes performed to a method are recorded in the change history (if activated).

5.2.1 Methods overview

The section **Methods list** provides an overview of all methods already created on the balance. In this section, new methods can be defined and existing methods can be edited, cloned or deleted. It is also the starting point for using any method in a weighing procedure.

Navigation: ▼ Methods > ₹ Methods list

The following methods are available:


- A General Weighing (see Method General weighing)
- **6** Interval weighing (see Method Interval weighing)
- **<u>**</u>** Piece counting (see Method Piece counting)
- **Simple formulation** (see Method Simple formulation)
- La Titration (see Method Titration)
- **Density determination** (see Method Density determination)

5.2.2 Method "General weighing"

The method **General Weighing** offers the basic weighing functions (zeroing, taring, weighing). The method is used for simple weighing tasks or to perform a series of check weighing or dosing.

The parameters of the weighing item, e.g., sample ID and target weight, can either be entered manually or by using a template. Therefore two different methods exist:

- General Weighing: Select this method if you want to work without pre-defined templates.
- General Weighing with templates: Select this method if you want to use a template to define the
 parameters individually for each single weighing item. Templates are particularly useful when the weighing
 task consists of a series of weighings, each with its own individual parameters, such as target weight,
 tolerances, etc. For further information, see [Using method templates ▶ Page 53].



You have the possibility to start with method factory setting parameter or to create a new method with changed method parameter.

For details about method settings:

See also

Settings: method "General weighing" ▶ Page 85

5.2.2.1 Creating a method "General weighing"

Navigation: ▼ Methods > ₹3 Methods list

- 1 Tap + New in the action bar.
 - ⇒ The method wizard opens, starting at 1. Method type.
- 2 Tap Method type and select the method type General Weighing or General Weighing with templates.
- 3 Tap → Next.
 - ⇒ The method wizard opens the section **2. Identification**.
- 4 Define the **Method name** and **Result description** and tap → **Next**.
 - ⇒ The method wizard opens the section **3. Configuration**.
- 5 Select a Tolerance profile and tap → Next.
 - ⇒ The method wizard opens the section **4. Save**.
 - ⇒ When selected General Weighing with templates, the wizard opens the optional section 4. Templates.
- 6 Select a template from the list and define the **Sample ID**, **Unit**, **Target weight**, **—Tolerance**, and **+Tolerance**. Tap → **Next**.
 - ⇒ The method wizard opens the last section **5. Save**.
- 7 Tap **Finish** to save the new method.
- \Rightarrow The method has been created and appears in the list.

5.2.2.2 Performing a "General weighing"

This section describes a **General Weighing** example step by step. Depending on the defined settings and weighing objects, the procedure can be different from this example.

- 1 Open the **Methods** section.
- 2 Select a method from the **Methods list** or define a new method.
- 3 Tap ▶ Start method.
 - ⇒ The main weighing screen appears with the selected method.
- 4 Press $\rightarrow 0 \leftarrow$ to zero the balance.
- 5 Open the draft shield (if applicable) and place the weighing object on the weighing pan.
- 6 Close the draft shield (if applicable) and wait until the weight stabilizes.
 - ⇒ The weighing starts with **Capturing weight...**.

7 Tap + Add to protocol.

- ⇒ The weighing result is saved to the **Protocol**.
- 8 When the weighing process is finished, tap **Complete** in the action bar.
 - ⇒ The window **Complete task** opens. The task-specific information can be printed on a label printer, the protocol can be printed manually or automatically (depending on the method settings), and the result can be exported to an external storage device.
- ⇒ The task **Piece counting** was successfully completed.



It is possible to exclude a weighing results from the protocol by opening the **Protocol** and tapping on **Exclude** result


The window **Complete task** always appears after completing the task, even if the results are saved automatically.

5.2.3 Method "Simple formulation"

With the method **Simple formulation** the concentration of a substance can automatically be calculated.

The parameters of the weighing item, e.g., sample ID and target weight, can either be entered manually or by using a template. Therefore two different methods exist:

- **Simple formulation**: Select this method if you want to weigh a single component in a volumetric flask and have the concentration calculated automatically.
- **Simple formulation with templates**: Select this method if you want to follow a predefined solution recipe of one or several components. Templates are particularly useful when the weighing task consists of a series of weighings, each with its own individual parameters, such as target weight, tolerances, etc. For further information, see [Using method templates ▶ Page 53].



For details about method settings:

See also

■ Settings: method "Simple formulation" ▶ Page 96

5.2.3.1 Creating a method "Simple formulation"

- 1 Tap + New in the action bar.
 - ⇒ The method wizard opens, starting at 1. Method type.
- 2 Tap Method type and select the method type Simple formulation or Simple formulation with templates.
- 3 Tap \rightarrow Next.
 - ⇒ The method wizard opens the section **2. Identification**.
- 4 Define the **Method name** and **Result description** and tap \rightarrow **Next**.
 - ⇒ The method wizard opens the section **3. Configuration**.

- 5 Select the options for Calculate concentration per component, Calculate amount of component and set a Tolerance profile.
- 6 Tap → Next.
 - ⇒ The method wizard opens the section 4. Save.
 - ⇒ When selected Simple formulation with templates, the wizard opens the optional creating section 4. Templates.
- 7 Select a template from the list and define the **Sample ID**, **Unit**, **Target weight**, **—Tolerance**, and **+Tolerance**. Tap → **Next**.
 - ⇒ The method wizard opens the last section **5. Save**.
- 8 Tap **I** Finish to save the new method.
- ⇒ The method has been created and appears in the list.


5.2.3.2 Performing a "Simple formulation"

This example describes how to perform a simple formulation with two different components. It explains the basic functions of the method without the use of any templates. Advanced functions such as the calculation of the concentration of a component can be defined in the method settings.

- 1 Open the **Methods** section.
- 2 Select a method from the **Methods list** or define a new method.
- 3 Tap ▶ Start method.
 - ⇒ The main weighing screen appears with the selected method.
- 4 Define the target weight and the tolerance limits for the first component.
- 5 Select **Component ID** to define the first component.
- 6 Select Task ID to define the whole task.
- 7 Press $\rightarrow 0 \leftarrow$ to zero the balance.
- 8 Open the draft shield (if applicable) and place the weighing object on the weighing pan.
- 9 Press \rightarrow **T** \leftarrow to tare the balance.
- 10 Open the draft shield (if applicable) and place the first component in the sample vessel.
 - ⇒ The measurement starts.
- 11 Tap + Add to protocol.
 - ⇒ The weighing result is saved to the **Protocol**.
- 12 Define the target weight and the tolerance limits for the second component.
- 13 Select **Component ID** to define the second component.
- 14 Open the draft shield (if applicable) and place the second component in the sample vessel.
- 15 Tap + Add to protocol.
 - ⇒ The weighing result is saved to the **Protocol**.
- 16 Tap **Complete** and select if you want to print or export the task protocol.
- ⇒ The weight task is completed and the balance returns to the main weighing screen.

5.2.4 Method "Piece counting"

The method **Piece counting** allows you to determine the number of pieces put on the weighing pan. It is advantageous if all pieces are of approximately equal weight, since the unit quantity is determined on the basis of the average weight of a single piece.



For details about method settings:

See also

Settings: method "Piece counting" ▶ Page 105

5.2.4.1 Creating a method "Piece counting"

Navigation: ▼ Methods > \(\pm\) Methods list

- 1 Tap + New in the action bar.
 - ⇒ The method wizard opens, starting at 1. Method type.
- 2 Tap Method type and select the method type Piece counting.
- 3 Tap → Next.
 - ⇒ The method wizard opens the section **2. Identification**.
- 4 Define the **Method name** and **Result description** and tap → **Next**.
 - ⇒ The method wizard opens the section **3. Configuration**.
- 5 Select a Tolerance profile and tap → Next.
 - ⇒ The method wizard opens the section 4. Weighing item.
- 6 Define a reference for pieces **Reference PCS**, a **Reference average weight**, **Target weight** and tap → **Next**.
 - ⇒ The method wizard opens the last section **5. Save**.
- 7 Tap **Finish** to save the new method.
- ⇒ The method has been created and appears in the list.

5.2.4.2 Performing a "Piece counting"



It is possible to exclude a weighing results from the protocol by opening the **Protocol** and tapping on **Exclude** result.

The window **Complete task** always appears after completing the task, even if the results are saved automatically.

- 1 Open the **Methods** section.
- 2 Select a method from the **Methods list** or define a new method.
- 3 Tap ▶ Start method.
 - ⇒ The main weighing screen appears with the selected method.

- 4 Press $\rightarrow 0 \leftarrow$ to zero the balance.
- 5 Open the draft shield (if applicable) and place the weighing object on the weighing pan.
- 6 Close the draft shield (if applicable) and wait until the weight stabilizes.
 - ⇒ The weighing starts with Capturing weight....
- 7 Tap + Add to protocol.
 - ⇒ The weighing result is saved to the **Protocol**.
- 8 When the weighing process is finished, tap **Example te** in the action bar.
 - ⇒ The window **Complete task** opens. The task-specific information can be printed on a label printer, the protocol can be printed manually or automatically (depending on the method settings), and the result can be exported to an external storage device.
- ⇒ The task **Piece counting** was successfully completed.

5.2.5 Method "Interval weighing"

With the method **Interval weighing**, the number of measurements and the time interval for each measurement can be defined.



For details about method settings:

See also

Settings: method "Interval weighing" ▶ Page 113

5.2.5.1 Creating a method "Interval weighing"

Navigation: ▼ Methods > ₹3 Methods list

- 1 Tap + New in the action bar.
 - ⇒ The method wizard opens, starting at 1. Method type.
- 2 Tap **Method type** and select the method type **Interval weighing**.
- 3 Tap → Next.
 - ⇒ The method wizard opens the section **2. Identification**.
- 4 Define the **Method name** and tap → **Next**.
 - ⇒ The method wizard opens the next creating section 3. Configuration.
- 5 Select a Approximate interval, the number of Measurements, select a Tolerance profile and tap → Next.
 - ⇒ The method wizard opens the next creating section 4. Weighing item.
- 6 Select a **Unit** for the weighing and tap → **Next**.
 - ⇒ The method wizard opens the last section **5. Save**.
- 7 Tap **Y** Finish to save the new method.
- \Rightarrow The method has been created and appears in the list.

5.2.5.2 Performing an "Interval Weighing"

This section describes how the method **Interval weighing** is being used in a task example. In this example we are weighing one single weight with a tare container.

- 1 Open the **Methods** section.
- 2 Select a method from the **Methods list** or define a new method.
- 3 Tap ▶ Start method.
 - ⇒ The main weighing screen appears with the selected method.
- 4 Press $\rightarrow 0 \leftarrow$ to zero the balance.
- 5 Open the draft shield, if applicable.
- 6 If a container is used, place the container on the weighing pan.
- 7 Press \rightarrow **T** \leftarrow to tare the balance.
 - ⇒ The tare-measurement starts with **Taring...**.
- 8 Place the weighing object into the sample vessel.
- 9 Close the draft shield, if applicable.
- 10 Tap ▶ Start.
 - ⇒ The defined method is being executed. The **Protocol** section shows the current counter.
- 11 Wait until the process is finished.
 - ⇒ The **Protocol** opens and shows a summary of the weighing results.
- 12 Tap **Complete** to open the export options.
 - ⇒ The dialog Complete task appears.
- 13 Tap **Export protocol manually** to export the weighing results to an external USB storage device or tap **Complete** to finish the task.
- ⇒ After completing the task, the results are deleted from the **Protocol**.



The current weighing process can be stopped by tapping **Stop**.

5.2.6 Method "Titration"

The method **Titration** enables the interaction between the balance and the titrator via MT-SICS or RFID tag. The optional RFID reader enables data to be read from and written to an RFID tag. The RFID tag serves as a data carrier between the balance and titrator. The RFID tag placed on the base of a titrating beaker easily and reliably transfers the sample data, e.g., sample ID and weight. For available RFID readers, see "Accessories".



For details about method settings:

See also

Settings: method "Titration" ▶ Page 117

5.2.6.1 Creating a method "Titration"

- 1 Tap + New in the action bar.
 - ⇒ The method wizard opens, starting at 1. Method type.
- 2 Tap **Method type** and select the method type **Titration**.
- 3 Tap \rightarrow Next.
 - ⇒ The method wizard opens the section 2. Identification.
- 4 Define the **Method name** and **Result description** and tap → **Next**.
 - ⇒ The method wizard opens the section 3. Configuration.
- 5 Select a **RFID option**, a **Tolerance profile** and tap \rightarrow **Next**.
 - ⇒ The method wizard opens the last section **4. Save**.
- 6 Tap **Finish** to save the new method.
- ⇒ The method has been created and appears in the list.



The maximum text length of the **Sample ID** is 32 characters. If the RFID option activated, only the first 20 characters are transferred to the RFID tag.

5.2.6.2 Performing a "Titration"

This example describes how to prepare a sample for titration and to store the information on the RFID tag of the container using an external RFID reader such as the EasyScan USB. For more information about how to perform the titration, consult the manual of the titrator.

- An RFID tag is fixed under the weighing container.
- The RFID reader is connected to the balance.
- A METTLER TOLEDO titrator is connected to the balance via USB.
- A titration method exists in the Methods list with the RFID option set to Read and write.
- 1 Open the **Methods** section.
- 2 Select the desired titration method from the **Methods list**.
- 3 Tap ▶ Start method.
 - ⇒ The main weighing screen appears with the selected method.
 - ⇒ The wizard indicates the steps to follow to perform the method.
- 4 Place the container with RFID tag on the RFID reader.
 - ⇒ The RFID reader reads the information from the RFID tag
 - ⇒ The available data, if any, are included to the running task.
- 5 If necessary, edit the sample information.
- 6 Press $\rightarrow 0 \leftarrow$ to zero the balance.
- 7 Open the draft shield (if applicable) and place the sample vessel on the weighing pan.
- 8 Close the draft shield (if applicable) and wait until the weight stabilizes.
- 9 Press \rightarrow **T** \leftarrow to tare the balance.
- 10 Open the draft shield (if applicable) and place the sample in the sample vessel.
- 11 Close the draft shield (if applicable) and wait until the weight stabilizes.
- 12 Tap **V OK** to accept the measurement.
 - ⇒ The result is automatically added to the **Protocol**.
 - ⇒ The weighing result is saved to the **Protocol**.
- 13 Take the container and place it on the RFID reader.

- 14 Remove the sample vessel.
 - ⇒ The task **Titration** gets completed automatically and the RFID-tag information is updated.
- 15 Continue your workflow on the titrator.

5.2.7 Method "Density determination"

The method **Density determination** is used for determining the density of solids and liquids. Density determination is carried out based on **Archimedes' principle** according to which a body immersed in a fluid undergoes an apparent loss in weight that is equal to the weight of the fluid it displaces. Furthermore the density method also supports the pycnometer method, which does not rely on **Archimedes' principle**. The method **Density determination** includes three method types:

Solid: determines the density of a solid with the help of a density kit

Liquid (sinker): determines the density of a liquid with the help of a density kit and a sinker **Liquid (pycnometer)**: determines the density of a liquid in a glass vessel, e.g. pycnometer



For details about method settings:

See also

Settings: method "Density determination" ▶ Page 124

5.2.7.1 Creating a method "Density determination"

- 1 Tap + New in the action bar.
 - ⇒ The method wizard opens, starting at 1. Method type.
- 2 Tap **Method type** and select the method type **Density**.
- 3 Tap → Next.
 - ⇒ The method wizard opens the next creating section **2. Identification**.
- 4 Define the **Method name** and **Result description** and tap → **Next**.
 - ⇒ The method wizard opens the section **3. Configuration**.
- 5 Select the **Determination type** and define the corresponding settings, e.g., **Density unit** and **Weighing settings**.
- 6 Tap → Next.
 - ⇒ The method wizard opens the section 4. Weighing item
- 7 Define Initial values for weighing and tap → Next.
 - ⇒ The method wizard opens the last section **5. Save**.
- 8 Tap **I** Finish to save the new method.
- ⇒ The method has been created and appears in the list.



The **Determination type** can only be selected as part of a new created method. If another **Determination type** (solid, liquid) is required, a new method must be created.

5.2.7.2 Performing a "Density determination"

This example describes how to determine the density of a solid using a density kit.

- A density kit is available for the balance.
- 1 Open the **Methods** section.
- 2 Select a method from the **Methods list** or define a new method.
- 3 Tap ▶ Start method.
 - ⇒ The main weighing screen appears with the selected method.
- 4 Tap ▶ Start.
- 5 Specify the **Temperature** and the **Aux. liquid**.
- 6 Tap **✓ OK**.
- 7 Follow the instructions from the wizard.
 - ⇒ The **Protocol** opens and shows a summary of the weighing results.
- 8 Tap **Complete** to open the printing options.
 - ⇒ The dialog Complete task appears.
- 9 Tap Complete.
- ⇒ The task **Density determination** was successfully completed.

5.2.8 Editing a method

To clone a method proceed as follows:

- 1 Open the **Methods** section.
- 2 Select the method that you want to edit.
 - ⇒ The line color of the selected method becomes blue.
- 3 Tap / Edit.

For details about method settings:

See also

Weighing methods settings ▶ Page 85

5.2.9 Cloning a method

To simplify the process to create a method, an existing method can be cloned one or several times. The cloned method will have the same parameter values as the original one. If weighing item templates exist, those will be cloned as well.

To clone a method proceed as follows:

- 1 Open the **Methods** section.
- 2 Tap the method that you want to clone.
 - ⇒ The line color of the selected method becomes blue.
- - A copy of the selected method appears in the list. The cloned method has the same settings as the original method.



A method can be cloned several times. The name of the cloned method is always based on its original name, to which is appended a number.

5.2.10 Deleting a method

Both factory defined methods and user defined methods can be deleted if they are not needed. For this purpose proceed as follows:

- 1 Open the **Methods** section.
- 2 Tap the method that you want to delete.
 - ⇒ The line color of the selected method becomes blue.
- 3 Tap to Delete.
 - ⇒ The message **Delete method and cancel tasks?** appears on the screen.
- 4 Tap **V OK** to delete the selected method.
- ⇒ The system returns to the method list. The method has been deleted and does not appear on the list anymore.



There is always a method activated in the background. This method can not be directly deleted. To delete the method, another method must be started instead. Now the method is not activated anymore and can be deleted.

5.2.11 Deleting a task

A method will be held as a task in the task section of the methods menu. It will be paused as a task if any other method is launched without the current method being completed. The method can be paused if it contains one or more weighing results, or has had certain method settings changed.

Navigation: ▼ Methods > **②** Tasks

A task can only be deleted when not in use. The method that is currently used in the background is labeled with the symbol in the tasks lists. To cancel the task, another task must be activated.

- 1 Select the task to be deleted and tap **a Cancel**.
 - ⇒ The dialog **m Cancel task?** opens.
- 2 To delete the task tap \checkmark **OK**, to cancel the delete procedure tap \times **Cancel**.

5.2.12 Using method templates

Working with templates can simplify the workflow, especially when several weighings with different predefined target weights have to be carried out one after the other. Characteristic information such as a target weight and tolerances can be defined in a template and must not be defined for every single weighing task. This may save time, especially when the weighing process consists of multiple steps.

The methods General Weighing with templates and Simple formulation with templates use templates.

Before a template can be used in the weighing process, it must be defined. There are two ways to define templates:

- The templates can be defined directly in the method creating process.
- The templates can be defined during the execution of a task within a method of the same type, without templates.

5.2.12.1 Defining a template during the method-defining process

This example describes how to define a template for the method **General Weighing with templates**.

- 1 Open the **Methods** section.
- 2 Tap + New method.
- 3 Select Method type General Weighing with templates.
- 4 Step through the method wizard until step 4. Templates.
 - ⇒ The dialog screen **4. Templates** appears, the sample 1 can be defined.
- 5 Tap **Unit** to select the template unit.

- 6 Tap Target weight to define the target weight.
 - ⇒ The options **—Tolerance** and **+Tolerance** appear.
- 7 Tap **—Tolerance** to define the lower tolerance.
- 8 Tap +Tolerance to define the upper tolerance.
- 9 Tap → Next.
- 10 Tap 🗎 Finish.
- ⇒ The method has been created and appears in the method list.



This example only describes how to create templates for the method **General Weighing with templates**. For the other methods there might be several other options that can be defined.

5.2.12.2 Defining a template in a current task

It is also possible to create templates while performing a method without predefined templates, providing that the method type allows it.. This example describes how to create templates for the method **General Weighing**, respectively for the method **General Weighing with templates**. Templates can also be used for **Simple formulation** methods.

- 1 Start a method **General Weighing**.
- 2 Perform three weighings and add the results to the protocol by tapping + Add to protocol.
 - ⇒ The results are saved to the **Protocol**.
- 3 Tap ••• More.
- 4 Tap **Save as method with templates**.
- 5 Define a Method name.
- 6 Tap **✓ OK**.
- A method **General Weighing with templates** including three templates is created and added to the **Methods list** with the name defined by the user.

5.2.12.3 Working with templates

After the template has been created within a method, it can be used in a task.

- 1 Open the **Methods** section.
- 2 Select a method from the **Methods list** or define a new method.
- 3 Tap ▶ Start method.
 - ⇒ The main weighing screen opens. The target weight and the tolerance limits that have been defined in the template appear.

5.3 Tests

Routine tests can be performed to ensure accurate weighing results according to GWP® or other QM systems. Therefore the tests should be performed in fixed, regular intervals depending on your QM system and the results should be documented in a traceable way.


Navigation: ▼ Methods > Tests

5.3.1 Overview routine tests

METTLER TOLEDO can help you to define the routine tests to be performed based on your process requirements. Please contact your local METTLER TOLEDO representative for additional information.

5.3.1.1 Eccentricity test

The purpose of the eccentricity test is to check if every eccentric load deviation (corner load deviation) is within the user SOP tolerances. The corner load is the deviation of the measurement value through off-center (eccentric) loading. The corner load increases with the weight of the load and its distance from the center of the weighing pan support. If the display remains consistent, even when the same load is placed on different parts of the weighing pan, the balance does not have corner load deviation.



The result corresponds to the highest of the four determined eccentric load deviations (2 to 5).

5.3.1.2 Repeatability test

The repeatability test calculates the standard deviation of a series of measurements with a single test weight in order to determine the repeatability of the balance.

Repeatability is a measure of the ability of a balance to supply the same result in repetitive weighings with one and the same load under the same measurement conditions. During the test, the same load is placed and measured in different parts of the weighing pan. Afterwards, the difference between the measured weight values is calculated. The spread of the measured results leads to the repeatability.

Repeatability is highly affected by the ambient conditions (drafts, temperature fluctuations and vibrations) and also by the skill of the person performing the weighing. Therefore, the series of measurements must be carried out by the same operator, in the same location, under constant ambient conditions and without interruption.

The following test types are available:

- Repeatab. 1 TP: To test repeatability of the balance without tare weight.
- Repeatab. Tare 1 TP: To test repeatability of the balance with tare weight. The first test weight (tare weight) is used to simulate a tare container.

5.3.1.3 Sensitivity tests

The sensitivity of the balance defines the deviation between the balance reading and the actual load. The sensitivity test allows you to measure the sensitivity using one or two test points.

The following test types are available:

- Sensitivity 1 TP: To test sensitivity of the balance with one test weight.
- Sensitivity 2 TP: To test sensitivity of the balance with two test weights.
- Sensitivity Tare 1 TP: To test sensitivity of the balance with two test weights. The first test weight (tare weight) is used to simulate a tare container.
- **Sensitivity Tare 2 TP**: To test sensitivity of the balance with three test weights. The first test weight (tare weight) is used to simulate a tare container.

5.3.2 Creating an own new test

Before a test can be performed, the test settings have to be defined. A test wizard is leading you step-by-step through the process.

- 1 Open the **Methods** section.
- 2 Tap **Tests**.
- 3 Tap + New.
 - ⇒ The wizard Create new test starts.
- 4 Select the test type.
- 5 Work through the process by using the button → **Next** to go to the next step or the button ← **Back** to go back to the previous step.

For information concerning the settings for the different test types **see** the following chapters.

For details about test settings:

See also

Tests settings ▶ Page 131

5.3.3 Defining a test weight

The user should enter data related to each test weight based on the corresponding certificate. This enables each external test weight to be clearly assigned to a specific certificate. Up to 12 external test weights can be configured. These test weights can be used to carry out external tests and adjustments.

Navigation: ▼ Methods > 🚡 Tests



An external test weight for an external adjustment has to weigh at least 10% of the balance capacity. External test weights under 10% of the balance capacity are not displayed on the balance.

- 1 Open the **Methods** section.
- 2 Tap 5 Tests.
- 3 Tap # Test weights.
 - ⇒ The dialog **Edit test weights** opens.
- 4 Tap + New test weight.
- 5 Define the test weight settings and confirm with **Finish**.
- ⇒ The test weight is defined and will be available later in the test procedure.

Test weights settings

Parameter	Description	Values
Test weight name	Defines the name of the test weight.	Text (122 characters)
Test weight ID	Defines the test weight ID.	Text (122 characters)
Weight class	Defines the weight class according to OIML or ASTM. Alternatively, a customized tolerance class can be created with Own .	E1 E2 F1 F2 M1 M2 M3 ASTM000 ASTM00 ASTM0 ASTM0 ASTM1 ASTM2 ASTM3 ASTM4 ASTM5 ASTM6 ASTM7 Own*
Actual weight	Defines the actual weight. The actual weight is a specific weight with a specific Conventional Mass Value (CMV) from the weight calibration certificate.	Numeric
Next calibration date	Defines the next date for calibration.	Numeric
Certificate	If the certificate of the test weight is available, set to Active and fill in the additional parameters related to the certificate information (see below).	Active I Inactive*
Certificate ID	Defines the certificate ID.	Text (122 characters)
	This option only appears when the option Certificate ID is set to Active .	
Certificate date	Defines the certificate date.	Date
	This option only appears when the option Certificate ID is set to Active .	
Weight set ID	Defines the weight set ID.	Text (122 characters)

5.3.4 Performing a test



NOTICE

Measurement errors due to deficient handling of the test weights.

Deficient handling of the test weights can lead to incorrect result.

- Only handle test weights with gloves or forks.

You can perform an eccentricity test, a repeatability test or a sensitivity test. Which test you have to perform and when depends on the respective weighing processes. Mettler-Toledo GmbH can help you to define the routine tests to be performed based on your process requirements. Please contact your local METTLER TOLEDO representative for additional information.

Moments when tests could be performed:

- After cleaning
- After a software update
- Daily before putting into operation
- Depending on own SOP

Requirements:

- At least one test weight is defined.
- At least one sensitivity, one repeatability or one eccentricity test is created.

All of the following pictured test weights or vessels are examples. Actual test weights or vessels may look different.

5.3.4.1 Performing an eccentricity test

- 1 Open the **Methods** section.
- 2 Tap **Tests**.
 - ⇒ The test(s) previously defined appear on the list.
- 3 Select the eccentricity test you wish to perform and tap > Start.
 - ⇒ The test sequence starts.
- 4 Ensure that the weighing pan is empty and clear, the test weight is prepared, and weighing forks or gloves are ready.
- 5 When all requirements are fulfilled tap **V OK**.
- 6 Make sure that the weighing pan is empty and tap **JOK**.
- 7 Choose an available test weight
 - or -
 - add a new test weight and tap **VOK**.
- 8 Open the draft shield, if applicable.
- 9 Place the test weight carefully in the middle of the weighing pan.
- 10 Close the draft shield, if applicable.
 - ⇒ The measurement starts with Capturing weight...
 - ⇒ The result of the first measurement is placed in the **Protocol** as **Position 1**.
- 11 Lift the test weight and move to position 2 (front left corner of the weighing pan).
 - ⇒ The measurement starts with Capturing weight...
 - ⇒ The result of the second measurement is placed in the **Protocol** as **Position 2**.
- 12 Lift the test weight and move to position 3 (back left corner of the weighing pan).
 - ⇒ The measurement starts with Capturing weight...
 - ⇒ The result of the third measurement is placed in the Protocol as Position 3.

- 13 Lift the test weight and move to position 4 (back right corner of the weighing pan).
 - ⇒ The measurement starts with Capturing weight...
 - ⇒ The result of the fourth measurement is placed in the **Protocol** as **Position 4**.
- 14 Lift the test weight and move to position 5 (front right corner of the weighing pan).
 - ⇒ The measurement starts with Capturing weight...
 - ⇒ The result of the fifth measurement is placed in the **Protocol** as **Position 5**.
 - ⇒ The eccentricity test is finished.
- 15 Remove the test weight carefully and tap **VOK**
 - ⇒ The door closes automatically (depending on the door settings) and the balance starts an automatic zeroing.
- 16 When the test procedure is finished, tap **Finish**.
 - ⇒ The result dialog opens.
- 17 To print the results tap **Print**, to finish the test tap **Finish**.

Test result

If the test failed, see "Troubleshooting", search the error, remedy it and test again. If the test fails again, contact a METTLER TOLEDO representative.

See also

- Settings: eccentricity test ▶ Page 131
- Troubleshooting ▶ Page 145

5.3.4.2 Performing a repeatability test

In this section, both repeatability tests are described. Which test you use depends on the respective test target.

Repeatability - 1 test point

- 1 Open the **Methods** section.
- 2 Tap Tests.
 - ⇒ The test(s) previously defined appear on the list.
- 3 Select the repeatability test you wish to perform and tap > Start.
 - ⇒ The test sequence starts.
- 4 Ensure that the weighing pan is empty and clear, the test weight is prepared, and weighing forks or gloves are ready.
- 5 When all requirements are fulfilled tap **V OK**.
- 6 Make sure that the weighing pan is empty and tap **JOK**.
 - ⇒ The balance starts an automatic zeroing.
- 7 Choose an available test weight
 - or -
 - add a new test weight and tap **VOK**.
- 8 Open the draft shield, if applicable.
- 9 Place the test weight carefully in the middle of the weighing pan.
- 10 Close the draft shield, if applicable.
 - ⇒ The measurement starts with Capturing weight...
 - ⇒ The result of the measurement is saved to the **Protocol**.
- 11 Remove the test weight carefully and tap • OK
 - ⇒ The balance starts an automatic zeroing.
 - ⇒ Depending on the specified **Number of repetitions** you have to repeat the last four steps x-times.
- 12 When the test procedure is finished, tap **Finish**.
 - ⇒ The result dialog opens.

13 To print the results tap **Print**, to finish the test tap **Finish**.

Repeatability - Tare - 1 test point

- 1 Open the **Methods** section.
- 2 Tap Tests.
 - ⇒ The test(s) previously defined appear on the list.
- 3 Select the repeatability test you wish to perform and tap > Start.
 - ⇒ The test sequence starts.
- 4 Ensure that the weighing pan is empty and clear, the test weight is prepared, and weighing forks or gloves are ready.
- 5 When all requirements are fulfilled tap **V OK**.
- 6 Make sure that the weighing pan is empty and tap **JOK**.
 - ⇒ The balance starts an automatic zeroing.
- 7 Choose an available test weight/test container
 - or -

add a new test weight/test container and tap **V OK** and put it on the weighing pan.

- ⇒ The measurement starts with **Taring...**.
- ⇒ The tare result is saved in the **Protocol**.
- 8 Carefully place the test weight onto the weighing pan or into the tare container.
 - ⇒ The measurement starts with Capturing weight...
 - ⇒ The result of the measurement is saved to the **Protocol**.
- 9 Remove the test weight, leave the container on the weighing pan.
 - ⇒ The measurement starts with **Taring...**.
- 10 Carefully place the test weight onto the weighing pan or into the tare container.
 - ⇒ The measurement starts with Capturing weight...
 - ⇒ The result of the measurement is saved to the **Protocol**.
 - Depending on the specified **Number of repetitions** you have to repeat the last twp steps a certain number of times.
- 11 When the test procedure is finished, tap **Finish**.
 - ⇒ The result dialog opens.
- 12 To print the results tap \blacksquare **Print**, to finish the test tap \checkmark **Finish**.

Test result

If the test failed, see "Troubleshooting", search the error, remedy it and test again. If the test fails again, contact a METTLER TOLEDO representative.

See also

- Settings: repeatability test ▶ Page 133
- Troubleshooting ▶ Page 145

5.3.4.3 Performing a sensitivity test

In this section, two of four possible sensitivity tests are described. Which test you use depends on the respective test target. The procedure for the tests with two test points is similar, but additional test weights and test containers are necessary.

Sensitivity - 1 test point

- 1 Open the **Methods** section.
- 2 Tap & Tests.
 - ⇒ The test(s) previously defined appear on the list.

- 3 Select the sensitivity test you wish to perform and tap > Start.
 - ⇒ The test sequence starts.
- 4 Ensure that the weighing pan is empty and clear, the test weight is prepared, and weighing forks or gloves are ready.
- 5 When all requirements are fulfilled tap **V OK**.
- 6 Make sure that the weighing pan is empty and tap **JOK**.
 - ⇒ The balance starts an automatic zeroing.
- 7 Choose an available test weight
 - or -

add a new test weight and tap **JOK**.

- 8 Open the draft shield, if applicable.
- 9 Place the test weight carefully in the middle of the weighing pan.
- 10 Close the draft shield, if applicable.
 - ⇒ The measurement starts with Capturing weight...
 - ⇒ The result of the measurement is saved to the **Protocol**.
- 11 When the test procedure is finished, tap **Finish**.
 - ⇒ The result dialog opens.
- 12 To print the results tap **Print**, to finish the test tap **Finish**.

Sensitivity - Tare - 1 test point

- 1 Open the **Methods** section.
- 2 Tap Tests.
 - ⇒ The test(s) previously defined appear on the list.
- 3 Select the sensitivity test you wish to perform and tap > Start.
 - ⇒ The test sequence starts.
- 4 Ensure that the weighing pan is empty and clear, the test weight is prepared, and weighing forks or gloves are ready.
- 5 When all requirements are fulfilled tap **V OK**.
- 6 Make sure that the weighing pan is empty and tap **JOK**.
 - ⇒ The balance starts an automatic zeroing.
- 7 Choose an available test weight
 - or

add a new test weight and tap **VOK**.

- ⇒ The measurement starts with Capturing weight...
- ⇒ The tare result is saved in the **Protocol**.
- 8 Carefully place the test weight onto the weighing pan or into the tare container.
 - ⇒ The measurement starts with Capturing weight...
 - ⇒ The result of the measurement is saved to the **Protocol**.
- 9 When the test procedure is finished, tap **Finish**.
 - ⇒ The result dialog opens.
- 10 To print the results tap **Print**, to finish the test tap **Finish**.

Test result

If the test failed, see "Troubleshooting", search the error, remedy it and test again. If the test fails again, contact a METTLER TOLEDO representative.

See also

- Settings: sensitivity test ▶ Page 136
- Troubleshooting ▶ Page 145

5.3.5 Editing a test

A test can only be edited when it is not running.

Navigation: ▼ Methods > Tests

- 1 Select the test to be edited from the list and tap / Edit.
 - ⇒ The test settings open.
- 2 Edit your test parameters, **see** section [Tests settings ▶ Page 131].

See also

Tests settings ▶ Page 131

5.3.6 Printing test results

You can print a test manually, whether the parameter **Automatic print** in the test settings is activated or deactivated. For this purpose proceed as follows:

- 1 Open the **Methods** section.
- 2 Tap **Tests**.
 - ⇒ The test list opens.
- 3 Select the test to print and tap Print all
- ⇒ The test is printed.

5.3.7 Deleting a test

- 1 Open the **Methods** section.
- 2 Tap Tests.
 - ⇒ The test list opens.
- 3 Select the test to delete.
- 4 Tap **m Delete**.
 - ⇒ The section **Delete routine test** opens. The message **Do you really want to delete the selected routine test?** appears.
- 5 Tap **Yes** to delete the test. Tap **X No** to cancel the deleting process.
- After deleting the test, the system returns to the test list. The test has been deleted and does not appear on the list anymore.

Running tests are labeled with the symbol and cannot be deleted. To delete a test, it must be finished or another test must be activated. To delete a test, proceed as follows:

5.3.8 Consulting the test history

Navigation: → Balance menu > ☐ History > 届 Tests

- Select a test.
- ⇒ The test history opens. Specific data are displayed for each test, such as the date and time, type of test, temperature, level state, test weight ID, and weight deviation.

See also

History ▶ Page 71

5.4 Adjustments

This section describes how internal and external adjustments can be defined and performed. Which type of adjustment is performed depends on the defined adjustment **Strategy**.

Navigation: ▼ Methods > Adjustments

See also

Adjustments settings ▶ Page 138

5.4.1 Internal adjustment

5.4.1.1 Editing an internal adjustment

- 1 Open the **Methods** section.
- 2 Tap **Adjustments**.
- 3 Tap /Edit.
- 4 Set the Strategy to Internal adjustment.
- 5 Define the adjustment parameters.
- 6 Tap ✓ Save.
- ⇒ Your internal adjustment has been edited.

For details about adjustment settings:

See also

Adjustments settings ▶ Page 138

5.4.1.2 Performing an internal adjustment

- The adjustment Strategy is set to Internal adjustment.
- Open the **Methods** section, tap **3**, select the adjustment, and tap ▶ **Start** or -

from the main weighing screen, tap ••• More and tap Start adjustment.

- ⇒ Internal adjustment is being executed.
- ⇒ When the adjustment has been completed, an overview of the adjustment results appears.
- 2 Tap Print if you want to print the results.
- 3 Tap **Finish adjustment**.
- ⇒ The balance is ready.

5.4.2 External adjustment

5.4.2.1 Editing an external adjustment

- 1 Open the **Methods** section.
- 2 Tap Adjustments.
- 3 Tap /Edit.
- 4 Set the Strategy to External adjustment.
- 5 Tap **Edit test weights**.
 - ⇒ The dialog **Edit test weights** opens.
- 6 Select a test weight from the list and tap \checkmark **0K**

- or -

- tap + New test weight to define a new test weight.
- 7 Define the test weight settings and confirm with **VOK**.
- 8 Tap Save.
- ⇒ Your external adjustment has been edited.

For details about adjustment settings:

See also

- Adjustments settings ▶ Page 138
- Defining a test weight ▶ Page 56

5.4.2.2 Performing a external adjustment

After the external weights have been defined, the function **External adjustment** can be performed.

- 1 Open the **Methods** section.
- 2 Tap Adjustments.
- 3 Select the external adjustment you wish to perform and tap > Start.
 - ⇒ The adjustment process starts.
- 4 Ensure that the weighing pan is empty and clear, the test weight is prepared, and weighing forks or gloves are ready.
- 5 When all requirements are fulfilled tap **V OK**.
- 6 Make sure that the weighing pan is empty and tap **JOK**.
- 7 Choose an available test weight
 - or -
 - add a new test weight and tap **JOK**.
- 8 Open the draft shield, if applicable.
- 9 Place the test weight carefully in the middle of the weighing pan.
- 10 Close the draft shield, if applicable.
 - ⇒ The adjustment starts.
- 11 Remove the test weight from the weighing pan and tap **VOK**.
 - ⇒ The adjustment is finishing and the adjustment results appear.
- 12 To print the results tap **Print**, to finish the test tap **Finish**.

See also

Defining a test weight ▶ Page 56

5.4.3 Consulting the adjustment history

Navigation: ▶ Balance menu > ☐ History > ☐ Adjustments

- Select an adjustment.
- ⇒ The adjustment history opens. Specific data are displayed for each adjustment such as the date and time, type of adjustment, temperature, level state, and correction.

See also

History ▶ Page 71

5.5 External devices

Navigation: ▶ Balance menu > ♦ Settings > ₹ Devices / Printers

5.5.1 Adding a device

Adding a new device

- 1 To add a new device, tap + Add device
 - ⇒ The **Add device** dialog opens.
- 2 Connect the device to one of the USB-A ports of the balance.
- 3 Follow the instructions from the wizard.



A label printer and a strip printer can be connected simultaneously to the balance.

Example: adding a barcode reader

- 1 To add a new device, tap + Add device
 - ⇒ The Add device dialog opens.
- 2 Connect the device to one of the USB-A ports of the balance.
- 3 If you are installing a barcode reader you can scan the barcode displayed on the balance terminal. Tap **!!!!!**Tools and tap → Next.
 - ⇒ The barcode of the device is shown.
- 4 Scan the barcode from the device.
 - ⇒ The barcode is identified from the balance and the new device is connected.
- 5 To cancel the dialog, tap X Cancel.

5.5.2 Deleting a device

- 1 Select the device from the list of devices and printers.
- 2 Tap **m Delete device**.
 - ⇒ The message of the type "Are you sure you would like to delete the selected device?" is shown.
- 3 To delete, tap **V OK**. To cancel the delete dialog, tap **X Cancel**.
- ⇒ The device is deleted.

5.5.3 Editing device settings

- 1 Select the device from the list of devices and printers.
 - ⇒ Device type, name, status and settings are shown.
- 2 To change the name of the device, tap Name, enter the name and tap .
- 3 Some devices, e.g., printers, have additional editable settings. To edit those settings, tap Printer settings.
 - ⇒ The dialog printer settings opens.

5.5.4 Printing a test page

If you have installed a printer, a test page can be printed.


- 1 Select the printer in the list of devices.
- 2 Tap 🖆 Print test page

5.5.5 Using an RFID reader

5.5.5.1 Testing an RFID reader

1 Select the device from the list of devices and printers.

- 2 Tap in Test device.
 - ⇒ The dialog **Test device** opens.
- 3 Place a RFID tag on the RFID reader.
 - If the RFID reader works correctly the message: "RFID reader has successfully read the RFID tag." is shown.
 - ⇒ The RFID reader has been tested.



Formatting an RFID tag

Navigation: ▶ Balance menu > \(\begin{align*} \text{ Maintenance > 1)} \end{align*} \) Format RFID

- 1 Tap ")) Format RFID.
 - ⇒ The dialog Format RFID tag opens.
- 2 Place the RFID tag on the RFID reader.
 - ⇒ The dialog "Do you want to format the RFID tag and delete all data?" opens.
- 3 To delete the RFID tag tap → Format.
 - ⇒ The RFID tag was formatted.

Reading data from an RFID tag

Navigation: → Balance menu > \(\frac{1}{2} \) Maintenance > \(\dots \)) Format RFID

- 1 Tap v)) Format RFID.
 - ⇒ The dialog Format RFID tag opens.
- 2 Place the RFID tag on the RFID reader.
 - ⇒ The dialog "Do you want to format the RFID tag and delete all data?" opens.
 - ⇒ In the dialog you can read all written data.
- 3 To delete the RFID tag tap \rightarrow Format. To cancel the format dialog tap \times Cancel

5.6 User management



NOTICE

Loss of data due to missing password or ID

Protected menu areas cannot be accessed without ID or password.

Note ID and password and keep them in a safe place.

5.6.1 Activating the user management

The user management is inactivated in the factory settings. To activate the user management follow:

Navigation: > Balance menu > Settings > General > User management.

- 1 Tap : and select Active.
 - ⇒ The dialog **Activate user management** opens.
- 2 Tap → Next.
 - ⇒ The dialog **P** Set administrator password (optional) opens.
- 3 Tap **New password** and enter the new password.

- 4 Confirm the new password again and tap **V OK**.
 - ⇒ The dialog closes.
- 5 Confirm the activated user management in the section **General**, tap **VOK**
- ⇒ The User management is active. The login dialog opens at every system start.

5.6.2 Disabling the user management

Settings > General > User management.

- 1 Tap : and select Inactive.
 - ⇒ The dialog **Deactivate user management** opens.
- 2 Tap → Next.
 - ⇒ The dialog **P** Set unblocking password opens.
- 3 Tap **New password** and enter the new password.
- 4 Confirm the new password again and tap <.
 - ⇒ The dialog closes.
- 5 Tap **V OK** to confirm.
- ⇒ The user management is inactive.

5.6.3 Managing users and user groups

The **Users** settings are only visible when the **User management** is set to **Active**.

Navigation: ▶ Balance menu > ♣ Users

Printing user list

An overview of all users and user groups can be printed by tapping **Print all**.

See also

Activating the user management ▶ Page 65

5.6.3.1 Creating a new user

Navigation: → Balance menu > ♣ Users > ♣ Users

- 1 Tap + New user in the action bar.
- 2 Define the values for the new user.
- 3 To define a user profile password, tap **P** Change password in the action bar.
- 4 Tap New password.
 - ⇒ The keyboard dialogue opens.
- 5 Define the password.
- 6 Tap Confirm new password and fill in the defined password.
- 7 Tap to close the keyboard dialogue.
- 8 Tap **V OK** to confirm the defined password.
 - ⇒ The dialogue User name opens.
- 9 Tap **V OK** to confirm the defined user profile.
- ⇒ The user has been created. The new user profile appears in the list.

5.6.3.2 Creating a new group



This area is only accessible for users with the appropriate rights.

- 1 Tap + New group.
 - ⇒ The dialog opens.
- 2 Define the group properties.
- 3 Tap **✓ OK**.
- ⇒ The group has been created, the system returns to the list of defined groups.

5.6.3.3 Deleting users or user groups

Requirements for deleting:

You logged in as administrator.

Navigation: ▶ Balance menu > ♣ Users > ♣ Users

- 1 Select your User ID.
 - ⇒ The user management dialog opens.
- 2 Tap **m Delete** in the action bar.
 - ⇒ The dialog **Delete user** opens.
- 3 To delete the user tap **V OK**.
- ⇒ The user is deleted irreversibly.

5.7 Tolerance profiles

Navigation: ightharpoonup Balance menu ightharpoonup Settings ightharpoonup Balance ightharpoonup Weighing / Quality ightharpoonup Tolerance profiles

Creating a Tolerance profile

- 1 Tap + New to create a new profile.
- 2 Define the profile settings.
- 3 When all the settings have been defined, tap **✓ OK**.
 - ⇒ The system returns to the profile list and the new profile appears on the list.

By tapping an existing profile, its settings can be changed, the profile can be deleted or it can be set as default value. Several profiles can be created. A default profile must be selected.

5.8 Data management

Navigation: → Balance menu > 🖹 Maintenance > 🗎 Import / Export

The import or export of data can be used to save or transfer data from one balance to another.

The following data can be imported or exported:

- Balance settings
- User management
- Methods
- · Tests and weights

5.8.1 Exporting data and settings

- 1 Select **Export data and settings**.
 - ⇒ The dialog **Export data and settings** opens.
- 2 Select Export and tap → Next
 - ⇒ The window **Export data and settings** appears.
- 3 Select the data type(s) you want to export.
- 4 Plug in the USB storage device to one of the USB-A ports of the balance.
- 5 Tap ✓ Export.
 - ⇒ A list of available USB storage devices opens.

- 6 Select the target USB storage device to store the data.
- 7 Tap → Next.
 - The system exports the data to the USB storage device. If the export was successful, the screen shows with the file name and its target folder.
- 8 Tap X Close to finish the process.

5.8.2 Importing data and settings

With the function **Import data and settings**, settings from other balances can be imported to this balance. It is also possible to re-import settings that have been exported.

- 1 Select | Import data and settings.
- 2 Plug in the USB storage device with the data to import.
- 3 Tap → Next.
 - ⇒ A list of available USB storage devices opens.
- 4 Select the USB storage device with the data to import.
- 5 Tap \rightarrow Next.
- 6 Select the data file you want to import.
- 7 Tap → Next.
- 8 Select the data type(s) you want to import.
 - When importing methods, you can select if all methods or a selection of methods will be imported. Methods of the same name will be overwritten.
- 9 Tap / Import.
- The message **Import of data and settings has been executed.** appears. The import was successful. Tap **X Close** to return to the main weighing screen.

5.9 Password protection and balance reset

5.9.1 Password protection

If user management is active, each user has an individual password.

- Any logged in user can change his own password. See [Changing a password ▶ Page 68].
- Users with permission to configure user management can change the password of any user. See [Changing a password ▶ Page 68].
- If a user with permission to configure user management has forgotten his password (and no other user can change it), a password reset can be requested. See [Requesting a reset password ▶ Page 69]
 Note

If the parameter **Password reset** is set to **Not allowed**, the balance needs to be reset by a service technician.

If user management is inactive, a password can be generated to block the whole balance. See [Creating an unblocking password > Page 69].

5.9.1.1 Changing a password

Any user can change its own password. Additionally, users with permission to configure user management can change the password of other users.

Navigation: → Balance menu > ♣ Users > ♣ Users

- 1 Select the **User name** for which the password should be changed.
 - ⇒ The user management dialog opens.
- 2 Tap P Change password in the action bar.
 - ⇒ The dialog Change password opens.
- 3 Enter a new password and confirm it.

- 4 Tap **✓ OK**.
- ⇒ The password has been changed.

5.9.1.2 Requesting a reset password

If a user with the permission to configure user management has forgotten his password, a reset password can be requested.

- The balance login dialog is open.
- 1 Select the user who needs a password reset. That user needs to have the permission to configure user management.
- 2 Tap ••• More.
 - ⇒ The dialog **More** opens.
- 3 Tap 5 Request reset password.
- 4 The dialog **Request reset password** opens.
- 5 Note the service code and tap Service request.
 - ⇒ Information about your METTLER TOLEDO service representative appears.
- 6 Contact your METTLER TOLEDO service representative via phone or email.
 - ⇒ You get an 8-character reset password with which you can log in once.
- 7 Log in with your reset password and select a new password.

5.9.1.3 Creating an unblocking password

If the user management is inactive, the balance can still be blocked with a unique password, called the unblocking password. This password first need to be generated and needs to be provided to block and unblock the balance.

Navigation: → Balance menu > ♦ Settings > 🖺 Balance > 🤏 General

- 1 To create an unblocking password, tap **P Unblocking password** in the action bar.
 - ⇒ The dialog **Set unblocking password** opens.
- 2 Set a new password, confirm it, and tap **V OK**.
- 3 In the dialog . General, tap \(\strice{\strice{1}} \) Save and \(\strice{\strice{1}} \) OK.
- ⇒ The unblocking password is created.

5.9.2 Logging in and logging out

If the user management is active, users need to log in to use the balance.

5.9.2.1 Logging in

- The balance login dialog is open.
- 1 Select a user and enter the password.
- 2 Tap → Login.
- ⇒ You are logged in and your user name is displayed on the main weighing screen.

5.9.2.2 Logging out

Navigation: ▶ Balance menu > da Exit/ Block balance

- Tap ♠ Logout.
 - ⇒ You are logged out.

5.9.3 Blocking and unblocking the balance

A blocking means closedown of the balance. A reason for such "full blocking" can have a serious background. If the balance has a defect or a loss of the weighing quality, the user can block the balance completely.

If user management is active, users can block the balance if they have the related permission.

If user management is inactive, the balance can still be blocked to prevent any further usage of the balance. If no unblocking password has been set, the balance can get blocked and unblocked without a password. If an unblocking password has been set, the balance can only get blocked and unblocked using this password. See [Creating an unblocking password > Page 69].

5.9.3.1 Blocking the balance

Navigation: → Balance menu > da Blocking

- 1 To block the balance tap A Block balance.
 - ⇒ The dialog **Block balance** opens.
- 2 Tap → Next.
- 3 Enter your unblocking password and tap **J Block balance**.
- ⇒ The balance is blocked and the blocking screen appears.

5.9.3.2 Unblocking the balance

- The balance is blocked and the blocking screen is open.
- The unblocking password is available.
- 1 To unblock the balance, type the unblocking password in the password field.
- 2 Tap Unblock balance.
- 3 Tap **Unblock balance** to confirm.
 - By tapping **X Cancel** instead, the main weighing screen appears, but the balance is still blocked and only a limited number of settings can be edited.
- ⇒ The balance is unblocked and the main weighing screen appears.

5.9.4 Resetting the balance

When user management is active, only users with the appropriate permissions can reset the balance.

Navigation: → Balance menu > \(\subseteq \text{ Maintenance} > \(\subseteq \text{ Reset} \)



NOTICE

Reset causes data loss

Resetting the balance will delete user application data and set the user configuration back to factory state.

- To delete the change history data and the data for test history and adjustment history, activate the option **Also delete change, test and adjustment history**.
- 2 Tap → Next.
 - ⇒ The window **Reset balance** opens and warns that some data will be lost by resetting the balance.
- 3 Tap 5 Reset balance.
 - ⇒ The balance software restarts in factory state.

6 Software description

6.1 Balance menu settings

The **Balance menu** contains general settings and information. To open the section **Balance menu** tap the drawer symbol • on the left side of the screen.

The section **Balance menu** is divided into the following subsections.

- History, see [History > Page 71]
- **Lusers** (only appears when user management is activated), see [Users ▶ Page 74]
- Settings, see Settings
- **\(\mathbb{E}\) Maintenance**, see [Maintenance **\rightarrow** Page 85]
- GE Exit / Blocking, see Exit / Block the balance

See also

- Users ▶ Page 74
- Leveling aid ▶ Page 71
- History ▶ Page 71
- Balance info ▶ Page 74
- Maintenance ▶ Page 85

6.1.1 Leveling aid

Exact horizontal positioning and stable installation is essential for repeatable and accurate weighing results. With the **Leveling aid** the balance can be leveled.

Navigation: ▶ Balance menu > ③ Leveling aid



After leveling the balance an internal adjustment must be performed.

See also

Leveling the balance ▶ Page 36

6.1.2 History

The balance permanently records the tests and adjustments that are performed in the section History

Navigation: ➤ Balance menu > History

The section **History** is divided into the following subsections.

- Adjustments
- Tests
- Alibi memory (only available for specific balance models)
- Z Service
- Changes (only appears when change history is activated)

6.1.2.1 Adjustments

Navigation: → Balance menu > ☐ History > ☐ Adjustments

A maximum of 500 entries can be stored in the adjustments history.

Symbol	Description	Procedure
lacksquare	Filter	Tap to Filter the adjustment history by a defined date range or by a user ID.
	Print	Tap to print the adjustment history list.
(Close	Tap to return to the section History

6.1.2.2 Tests

Navigation: ▶ Balance menu > ☐ History > ☐ Tests

A maximum of 500 entries can be stored in the test history.

Symbol	Description	Procedure
lacksquare	Filter	Tap to Filter the test history by a defined date range or by a user ID.
	Print	Tap to print the test history list.
← □	Close	Tap to return to the section History .

6.1.2.3 Alibi memory

The alibi memory is a tamper-proof data storage device on which weighing data subject to legal control is automatically stored and accessible for a period of time. An alibi memory device operates according to the principle of a "ring" memory: when the capacity limit of the data records and the retention period are reached, the oldest data record in the memory is automatically overwritten by the new data record.

As soon as a result is generated by the balance, it will be stored in the alibi memory of the balance, if the feature is activated. Access to the alibi memory on the balance is provided in stand-alone mode only.

The combination of **Alibi record ID** and **Bridge serial number** ensures the uniqueness of an alibi memory entry. The balance also defines a retention period describing the minimum amount of time during which the results must be stored in the alibi memory. As soon as the retention period for specific alibi entries is exceeded, the balance can reuse these memory slots for new entries.

The alibi memory is only available for specific balance models and needs to be activated by a service technician. Contact your METTLER TOLEDO representative for more details.

When the alibi memory is activated, an alibi record is generated for each result added to the **Protocol**. Each alibi record contains the following information:

- Bridge serial number
- Alibi record ID
- Date/time
- Net weight
- Tare weight
- · Tare weight status
- Verification (CRC-16)



When the **Capture mode** is set to **Immediate**, no alibi record is generated.

Navigation: ▶ Balance menu > ☐ History > ☐ Alibi memory

A maximum of 500'000 entries can be stored in the alibi memory. When the maximum number of entries is reached and no entries are older than the retention period, no new result can be added to the **Protocol**. This can be fixed in service mode, where alibi records can be deleted or the retention period can be shortened.

Symbol	Description	Procedure	
Y	Filter	Tap to Filter the alibi memory by a defined date range or by a record ID range.	
	Export	Tap to Export the content of the alibi memory.	
*	Show alibi memory status	Tap to show information about the alibi memory status: Used memory , Number of remaining records , Retention period , Oldest records , and Newest records .	
o,	Alibi memory retention period	The retention period is the minimum period during which the alibi records are stored in the alibi memory. The retention period can range from 1 to 365 days, with a default value of 100 days.	
	Print	Tap to print the content of the alibi memory.	
€	Close	Tap to return to the section History .	

6.1.2.4 Service

Navigation: ▶ Balance menu > ☐ History > ☑ Service

A maximum of 500 entries can be stored in the service history.

Symbol	Description	Procedure
lacksquare	Filter	Tap to Filter the service history by a defined date range or by technician.
	Print	Tap to print the service history list.
← □	Close	Tap to return to the section History .

6.1.2.5 Changes

The function **Change history** is an administration tool to improve the traceability of the weighing process. Information such as added methods or settings changes are being listed. Tap into the list to display detailed information about the data.

Navigation: ▶ Balance menu > ☐ History > ♠ Changes

Change history is deactivated in the factory settings. To activate **Change history**, see Weighing / Quality. A maximum of 5000 entries can be stored in the change history.

Symbol	Description	Procedure
lacksquare	Filter	Tap to Filter the adjustment history by a defined date range or by a user ID.

Symbol	Description	Procedure
	Print	Tap to print the adjustment history list.
€	Close	Tap to return to the section History

6.1.3 Balance info

Navigation: ▶ Balance menu > \ \begin{align*}
\beg

The section **Balance info** shows numerous information about the specific balance such as:

- Identification
- Hardware
- Software
- Maintenance

Symbol	Description	Procedure
\odot	License agreement	Tap to open the licence agreement.
€	Close	Tap to return to the section History .

6.1.4 Users

In the section **Users**, rights for users and user groups can be defined. Users can be assigned to user groups. When the user management is active, the login dialog opens at every system start.

The Users settings are only visible when the User management is set to Active.

The section **User management** is divided into the following subsections:

- **La General** Settings for all users.
- **Lusers** Settings for all single users.
- A Groups Settings for user groups.

A user is always a part of a user group and has the permissions of the group in which he is. Which user has which permissions can be defined or changed by users with the appropriate permission rights.

See also

Activating the user management ▶ Page 65

6.1.4.1 General

Navigation: ▶ Balance menu > \$\mathbb{L}\$ Users > \$\mathbb{L}\$ General

Parameter	Description	Values
Automatic logout	With the option Automatic logout activated, the balance will automatically log off after a predefined time.	Active* I Inactive
Wait time	With the option Wait time the time until the balance automatically logs off can be defined.	Numeric (15 minutes* I 160 minutes)
	The option Wait time only appears when the option Automatic logout is activated.	

User proposals	The option User proposals defines if a list of users will appear on the login screen.	Active* I Inactive
Password reset	Defines if the password can be reset from the login screen.	Allowed* Not allowed
	If set to Not allowed and the password is lost, a new password cannot be requested. The balance needs to be reset and all data and settings will be lost.	

^{*} Factory setting

6.1.4.2 Users

Navigation: → Balance menu > ♣ Users > ♣ Users

Parameter	Description	Values
User name	Defines the user ID.	Text (122 characters)
	When the user profile has been defined, the value for User name will be fixed and cannot be changed afterwards.	
Last name	Defines the last name of the user.	Text (022 characters)
First name	Defines the first name of the user.	Text (022 characters)
Active	Activates or deactivates the current user.	Active* Inactive
Assigned groups	Assigns user to user groups.	List of defined groups
User language	Defines the language of the user profile.	Available languages

^{*} Factory setting

A user is always a part of a user group and has the permissions of the group in which he is. Which user has which permissions can be defined or changed by users with the appropriate permission rights.

6.1.4.3 Groups



This area is only accessible for users with the appropriate rights.

Parameter	Description	Values
Group name	Defines the name of the group.	Text (1 22 characters)

General permissions

Parameter	Description	Values
Block / unblock balance	Defines if the group is allowed to block or unblock the balance.	Active I Inactive
Configure	Defines if the group is allowed to:	Active I Inactive
methods	create new methods	
	edit methods	
	delete methods	
	lock or unlock methods	
	import or export methods	
Execute service	Defines if the group is allowed to:	Active I Inactive
commands	access service function	
	block/unblock the balance	
	view adjustment state	
	generate support files	

Configure system	Defines if the group is allowed to:	Active I Inactive
Cornigule System		Active i indefive
	modify system settings	
	import system settings	
	configure peripherals	
	perform software updates	
	perform application or factory settings	
Configure user	Defines if the group is allowed to:	Active I Inactive
management	print or export/import user management settings	
	modify user management settings	
	enable or disable user management	
Cancel task	Defines if the group is allowed to cancel a task during the	Active I Inactive
	execution of a method.	
Exclude /	Defines if the group is allowed to exclude or overwrite results in	Active I Inactive
Overwrite result	the Protocol .	

Quality management permissions

Parameter	Description	Values
Start external adjustment	Defines if the group is allowed to perform external adjustments.	Active I Inactive
Show change history	Defines if the group is allowed to see the option Change history .	Active I Inactive
Configure routine	Defines if the group is allowed to:	Active I Inactive
tests / GWP	configure routine tests	
	import or export routine tests	
	configure and import test weights	
	configure tolerance profiles	
	activate/deactivate the GWP approval mode	
Start routine tests	Defines if the group is allowed to perform routine tests.	Active I Inactive

6.1.5 Settings

This section describes the procedure for adapting the balance to suit specific requirements. The system settings apply to the entire weighing system and therefore to all user profiles and applications.

Navigation: ▶ Balance menu > ♦ Settings

The section **Settings** is divided into the following subsections:

- 🄏 Interfaces
- Tale Devices / Printers
- LabX / Services

6.1.5.1 Balance

Navigation: → Balance menu > ♦ Settings > ≗ Balance

The section **Balance** is divided into the following subsections:

- Q_a Weighing / Quality
- Capacita Date / Time / Language / Format
- *4 Screen / StatusLight / Sound
- 👺 General

Weighing / Quality

Navigation: ightharpoonup Balance menu ightharpoonup Settings ightharpoonup Balance ightharpoonup Weighing / Quality

Parameter	Description	Values
Leveling warning	Defines the behaviour of the option Leveling warning .	Inactive I Optional
	When the option Forced leveling is selected and the balance is out of level, a weighing value cannot be added to the protocol (green button disabled).	leveling* I Forced leveling
Tolerance profiles	A tolerance profile stores all the necessary balance settings needed for a certain weighing method. It is possible to create different tolerance profiles for different weighing methods.	
	This option has several subsections and is described later in this chapter.	
Automatic weight value output	Defines if and in which manner (MT-SICS and/or HID) the weighing values should be exported.	
	This option has several subsections and is described later in this chapter.	
GWP Approved mode	Good Weighing Practice (GWP®) is a program started by METTLER TOLEDO to help customers operate their weighing equipment in a safe and efficient way. It covers every relevant step in the life cycle of the instrument and provides clear guidance on how to specify, calibrate and operate weighing instruments.	Active I Inactive*
	The GWP Approved mode observes if the following conditions are given:	
	Use of an appropriate tolerance profile.	
	The internal adjustment was successful.	
	Required tests were successful.	
	Setting up of enforced leveling.	
	No MinWeigh violation.	
	If all conditions are given, the balance adds the GWP Approved sign behind every weighing result.	
	The GWP Approved mode can only be enabled by a METTLER TOLEDO service technician.	
Change history	Activates/Deactivates the option Change history .	Active Inactive*
	The change history is used to log changes to system settings, user management and methods as well as other settings and configurations. The following information is stored:	
	User ID and timestamp	
	Object identifier	
	Old values and new values of attributes	
	A maximum of 5000 entries can be stored in the change history.	
	For more information see section Change History.	
Balance recalib. reminder	Defines whether the user is reminded about the upcoming exipry date of the calibration.	Active* Inactive
Days in advance	Defines the number of days before the reminder informs about the upcoming due date.	0365
Action when	Defines the action when the calibration has expired.	None* I Block
calib. expired	Block : The balance will be blocked. In this case, the balance cannot be used anymore until a user with the appropriate right unblocks the balance.	

Days before blocking	Defines the number of days before the reminder informs about the upcoming expiry date.	Days (30 days* I 0400 days)
Weight recalib. reminder	Defines whether the user is reminded about the upcoming expiry date of the test weight calibration.	Active I Inactive*
Service reminder	Defines whether the user is reminded about the upcoming due date of the service.	Active I Inactive*

^{*} Factory setting

Tolerance profiles

Settings relating to weighing performance and data from balance calibration can be stored in a tolerance profile.

For more information about creating tolerance profiles, see [Tolerance profiles ▶ Page 67]

Parameter	Description	Values
Name	Defines the name of the profile.	Text (022 characters)
Indicator	Defines the color of the indicator icon for the tolerance profile. The icon will appear above the weighing value unit. When a color is selected, a description of max. 3 characters can be added.	None* I Neutral I White I Yellow I Red I Blue I Green I Black
Indicator text	Defines the text of the indicator icon.	Text (03 characters)
Calibration certificate	Selects a calibration certificate from a drop-down list of certificates available on the balance. New certificates can only be created by a service technician based on a performed balance calibration.	Calibration certificate I None*
Environment	Defines the environmental conditions of the balance.	Very stable I Stable I
	Very stable : For an environment that is free from any drafts and vibrations.	Standard* Unstable Very unstable
	Stable : For an environment that is practically free from drafts and vibrations.	
	Standard : For an average working environment subject to moderate variations in the ambient conditions.	
	Unstable : For an environment where the conditions are from time to time changing.	
	Very unstable : For an environment where the conditions are continuously changing.	
Weighing mode	Defines the weighing mode of the balance.	Universal* Sensor
	Universal: For all standard weighing applications.	mode
	Sensor mode : Depending on the setting of the ambient conditions, this setting delivers a filtered weighing signal of varying strength. The filter has a linear characteristic in relation to time (not adaptive) and is suitable for continuous measured value processing.	
Value release	Defines the speed at which the balance regards the measured value as stable and releases it.	Very fast Fast* Fast and reliable Reliable
	Very fast : recommended if you require fast results and repeatability is not very important.	Very reliable
	Very reliable : provides very good repeatability of the measured results but prolongs the stabilization time.	
	Some intermediate settings can also be choose from.	

Display readability	Determines the readability [d] of the balance display. 1d: Shows the maximum resolution 2d: Shows the final digit in increments of 2 5d: Shows the final digit in increments of 5 10d: 10x smaller resolution 100d: 100x smaller resolution 1000d: 1000x smaller resolution	1d* 2d 5d 10d 100d 1000d
Zero drift compensation	The function Zero drift compensation performs ongoing corrections of deviations from zero which may occur, for example, as a result of small amounts of dirt on the weighing pan.	Active* I Inactive
Allowed units	Defines the units that are allowed in this tolerance profile.	The available values are model-specific.

^{*} Factory setting

Automatic weight value output

The balance can be connected to a computer with a USB cable. Weighing results can then be directly transferred to a target application, e.g., Microsoft Excel.

Parameter	Description	Values
Output mode	Defines which weighing values are transferred via the communication interface, e.g., USB, Ethernet.	Protocol* Continuous
	Protocol : The weighing values are transferred only when they are added to the Protocol .	
	Continuous : The weighing values are transferred continuously via the interface defined under LabX / Services > MT-SICS .	
	Additional fields are available, depending on the chosen option.	
Target	Defines the way the weighing values are transferred.	HID* HID / MT-SICS
	HID (Human Interaction Device): Transfers simple character streams (e.g. weight values) to a desktop computer without installing additional drivers (comparable to a keyboard). The format of a transferred weighing value can be configured.	MT-SICS MT-SICS configurable
	MT-SICS: The data is transferred in MT-SICS format (METTLER TOLEDO Standard Interface Command Set). MT-SICS operates bidirectional, i.e. usually balance sends the confirmations to the host and receives commands. A separate reference manual is available for MT-SICS.	
	HID / MT-SICS : The data is transferred in HID and MT-SICS format in parallel.	
	MT-SICS configurable : The data is transferred in a user-defined MT-SICS format.	
	This parameter is only available if Output mode is set to Protocol .	
Weight field length	Defines the number of digits that will be transferred into the application on the computer, e.g., into an Excel field.	Numeric (1* I 020)
	This parameter is only available if Output mode is set to Protocol .	

Sign	Defines if the weighing result is displayed with an algebraic sign. For all values: Each weighing result is preceded by a plus or minus sign. For negative values: Only negative values are preceded by a minus sign. Positive values are transferred without algebraic sign.	For all values I For negative values*
	This parameter is only available if Output mode is set to Protocol .	
Sign position	Defines if the algebraic sign is positioned at the first place of the weight field or directly in front of the weight digits.	Left of weight field I Left of weight digits*
	This parameter is only available if Output mode is set to Protocol .	
Decimal delimiter	Defines the character used to separate the whole and fractional part of a numeric value.	, .*
	This parameter is only available if Output mode is set to Protocol .	
Net indicator	In the standard output format, net weights are not specially marked. To place an N in front of net weights, this function can be activated. The net symbol is left-justified in the field.	Active Inactive*
	This parameter is only available if Output mode is set to Protocol .	
Net indicator field	Defines the field length of the Net indicator.	Numeric (2* 1 2)
length	This parameter is only available if Output mode is set to Protocol and Net indicator is set to Active .	
Unit	Defines if a weighing unit is being shown in the weighing field.	Active* Inactive
	This parameter is only available if Output mode is set to Protocol .	
Unit field length	Defines the field length of the weighing unit.	Numeric (1* I 16)
	This parameter is only available if Output mode is set to Protocol and Unit is set to Active .	
Field delimiter	Defines a character or sequence of characters to separate data fields.	Outside* TAB , ;
	This parameter is only available if Output mode is set to Protocol .	
End of line character	Defines a character or sequence of characters signifying the end of a line.	CRLF* CR LF TAB Outside Enter
	This parameter is only available if Output mode is set to Protocol .	
Updates/sec.	Defines the rate at which data is transferred.	2 5 6* 10
	This parameter is only available if Output mode is set to Continuous .	
Format	Defines the format of the transferred data.	MT-SICS* PM AT/MT
	This parameter is only available if Output mode is set to Continuous .	

^{*} Factory setting

Date / Time / Language / Format

Navigation: → Balance menu > ♦ Settings > ≜ Balance > ♠ Date / Time / Language / Format

Parameter	Description	Values
Date	Defines the current date. Use the pick buttons Increment/ Decrement to define the date.	Date
Time	Defines the current time.	Time
	Use the pick buttons Increment/Decrement to define the time.	
Language	Defines the language of the interface navigation.	English Deutsch Français 日本語 中文 Español Italiano Pусский Português Polski Magyar Čeština
Time zone	Selects a time zone. When the time zone is set, the balance changes automatically between summer and winter time	see list on the screen
Date format	Selects the date format.	D.MMM.YYYY* I MMM D YYYY I DD.MM.YYYY I MM/DD/YYYY I YYYY- MM-DD I YYYY/MM/DD I YYYY年M月D日
Time format	Selects the time format.	24:MM* 12:MM 24.MM 12.MM
Keyboard layout	Defines the language of the keyboard layout.	English I German I French I Spanish I Japanese I Simplified Chinese I Russian I Czech I Polish I Hungarian

^{*} Factory setting

Screen / StatusLight / Sound

Navigation: → Balance menu > ♦ Settings > ≜ Balance > *4 Screen / StatusLight / Sound

Parameter	Description	Values
Screen brightness	Defines the brightness of the display.	20 % 40 % 60 % 80 %* 100 %
Sound volume	Defines the volume of the terminal sound.	Inactive 20 % 40 % 60 %* 80 % 100 %
Sound on key press	Defines if there is a sound when a key is pressed.	Active* I Inactive
Sound on info	Defines if there is a sound when an information appears on the screen.	Active* Inactive
Sound on warning	Defines is there is a sound when a warning appears on the screen.	Active* Inactive
Sound on error	Defines is there is a sound in case of an error.	Active* Inactive

StatusLight	Activates/deactivates the StatusLight .	Active* Active (without
	Active (without green light): All current status of the balance are monitored, the red/yellow lights will turn on if needed, but the green light will stay turned off.	green light) I Inactive
	StatusLight is red: Error. The balance must not be used until the error is corrected.	
	StatusLight is yellow: Warning. For example, the test manager has pushed a test to the balance or you are operating the balance between the date of the calibration reminder and the scheduled date of the next calibration. The balance can still be used.	
	StatusLight is green or off: Ok. No problems detected and the balance is ready to weigh.	
StatusLight brightness	Defines the brightness of the activated status light.	20 % 40 % 60 %*
	This option appears only when the option StatusLight is set to Active or Active (without green light).	80 % 100 %

^{*} Factory setting

General

Navigation: → Balance menu > ♦ Settings > ≗ > Balance > ♦ General

Parameter	Description	Values
Balance ID	Defines the ID of the balance.	Text (022 characters)
Standby	Activates/deactivates the automatic standby mode.	Active* Inactive
	Active : The standby mode becomes active after a configurable time period the balance was not used.	
	Inactive : The standby mode has to be activated manually by tapping the ON/OFF button.	
Software update on system start-up	With this option activated, software update can be performed from a USB storage device on startup.	Active* I Inactive
Automatic export directory	Defines the target directory for the automatic export.	USB storage device*
User management	Activates/Deactivates the option User management .	Active I Inactive*
Wait time	With the option Wait time the time until the balance automatically logs off can be defined.	Numeric (15 minutes* I 160 minutes)
	The option Wait time only appears when the option Automatic logout is activated.	

6.1.5.2 Interfaces

Navigation: ▶ Balance menu > ♠ Settings > ♣ Interfaces

The section **Interfaces** has the following subsection:

- 뫟 Ethernet
- ▶») · Bluetooth

Ethernet

With the option **DHCP** activated, the parameters for the ethernet connection will be automatically set. With the option **Manual** activated, the options for the ethernet connection must be set manually by the user.

Navigation: → Balance menu > ☆ Settings > 爲 Interfaces > 뫔 Ethernet

Parameter	Description	Values
Host name	Defines the balance host name.	Numeric (22* I 0 22)
MAC address	Information on the MAC address (Media Access Control) that is used to uniquely identify the balance in the network.	-
Network configuration	DHCP : The parameters for the ethernet connection will be automatically set. Manual : The options for the ethernet connection must be set manually by the user.	DHCP* Manual
IP address	If the IP is not to be automatically obtained, you can enter it here.	000.000.000.000 255.255.255.255
Subnet mask	Defines the subnet mask that is used by the TCP/IP protocol to determine whether a host is on the local subnet or on a remote network.	000.000.000.000 255.255.255.255
DNS server (primary)	Defines the domain name server address of the primary server.	000.000.000.000 255.255.255.255
DNS server (secondary)	Defines the domain name server address of the secondary DNS server.	000.000.000.000 255.255.255.255
Default gateway	Defines the address of the default gateway that links the host's subnet to other networks.	000.000.000.000 255.255.255.255

^{*} Factory setting

Bluetooth

Navigation: → Balance menu > ♦ Settings > 🚜 Interfaces > ١١) • Bluetooth

Bluetooth identification

Parameter	Description	Values
Activation	With the option Bluetooth you have the possibility to commu-	Inactive* Active
	nicate with a printer via Bluetooth.	

6.1.5.3 Devices / Printers

In this section optional external devices such as printers, barcode scanners, etc. can be added and configured.

Navigation: ▶ Balance menu > ♦ Settings > ♣ Devices / Printers

This section is divided into the following subsections:

- 💂 Label printer
- 💻 Strip printer
- 🔁 Barcode reader
- 🍵 RFID reader
- 📵 ErgoSens
- 📳 Foot switch

Some types of devices are associated with specific settings:

Label printer

Label printers allow printing weighing results on label stickers.

Navigation: → Balance menu > ♦ Settings > 1 Devices / Printers > 1 Label printer

Parameter	Description	Values
Printer category	Defines the type of the printer.	Strip printer I Label
	Strip printer allows the printing of weighing results on strip paper.	printer*

Device Allows to activate or deactivate the device. Activated* I Deactiv	Device
--	--------

^{*} Factory setting

Strip printer

Navigation: → Balance menu > ❖ Settings > 🖪 Devices / Printers > 🗐 Strip printer

Parameter	Description	Values
Printer category	Defines the type of the printer.	Strip printer I Label
	Strip printer allows the printing of weighing results on strip paper.	printer*

^{*} Factory setting

Parameter	Description	Values
Device	Allows to activate or deactivate the device.	Activated* Deactivated
Line end	Defines the line end character for printing. The values set here have to match the printer settings.	<cr> <lf>* <cr> <lf></lf></cr></lf></cr>
Character set	Defines the communication specific character code. The values set here have to match the printer settings.	ANSI/WIN I IBM/DOS I UTF8*

ErgoSens

Navigation: → Balance menu > ♦ Settings > ₱ Devices / Printers > ♠ ErgoSens

Parameter	Description	Values
Function	Defines the function of hands-free operating that can be used to execute certain weighing functions.	None* Doors Zero Tare Add result

Foot switch

Navigation: ▶ Balance menu > ♦ Settings > ♣ Devices / Printers > ♣ Foot switch

Parameter	Description	Values
Function	Defines the function be used to execute certain weighing functions.	None* Doors Zero Tare Add result

6.1.5.4 LabX / Services

To enable communication between LabX and instruments, the appropriate settings in the instruments must correspond with the settings in LabX.

LabX synchronizes the date and time on the instruments with the LabX Server each time a connection is made and each time a task is started. When an instrument is connected, the user interface language on the connected instrument is changed to the language currently installed on the LabX installation.

Navigation: → Balance menu > ♦ Settings > ♣ LabX / Services

Parameter	Description	Values
LabX service	Network : A network connection to LabX will be established on startup.	Network Inactive* USB
	Inactive: No connection to LabX will be established.	
	USB : A USB connection to LabX will be established on startup.	
MT-SICS service	Network: An MT-SICS network port will be opened on startup. Inactive: No MT-SICS port will be opened. USB: An MT-SICS USB port will be opened on startup.	Network Inactive* USB
File server	Allows you to define a file server to import/export data.	Active I Inactive*

^{*} Factory setting

6.1.5.5 Printing the settings

When all the balance settings are configured, you can print the complete list to archive the information.

- To print the balance settings, tap Print the settings
 - ⇒ The complete balance settings are printed.

Navigation: ▶ Balance menu > ♦ Settings

6.1.6 Maintenance

Navigation: → Balance menu > 🖺 Maintenance

The option **Maintenance** only appears if the user has the appropriate user rights.

The section Maintenance is divided into the following subsections:

- ')) Format RFID
- # Software update
- S Reset
- Service menu

See also

- Data management ▶ Page 67
- Using an RFID reader ▶ Page 64
- Software update ▶ Page 143
- Resetting the balance ▶ Page 70

6.1.6.1 Service menu

Navigation: → Balance menu > 🖺 Maintenance > 🔑 Service menu

Symbol	Description	Procedure
T	Show	Tap to open information about:
ā	adjustment	- Temperature correction
_	state	- Production and user linearization
		- User, production and standard calibration
	Save support files	Tap to save support files (all relevant information to an error) on a USB storage device like an USB stick to send it to a METTLER TOLEDO representative.
	Import log configuration	A log configuration file can be provided by METTLER TOLEDO to allow a more comprehensive collection of balance parameters to be stored in the support file. This is only used for troubleshooting purposes.
		Tap to import the log configuration from a USB storage device so that the enhanced list of parameters can be exported and sent to a METTLER TOLEDO representative.

6.2 Weighing methods settings

6.2.1 Settings: method "General weighing"

In this section, the settings of the methods **General Weighing** and **General Weighing with templates** are described. Settings can be edited for a newly created method or an already existing method.

Navigation: ▶ Methods > ₹ Methods list > ★ General Weighing > / Edit



The section **General Weighing** is divided into the following subsections:

- ₹] General
- 40 ID format
- Weighing item (Only available for the method General Weighing)
- La Templates (Only available for the method General Weighing with templates)
- 🕏 Weighing
- Print / Export

See also

- Creating a method "General weighing" ▶ Page 44
- Editing a method ▶ Page 52

6.2.1.1 General

The **Method type** is defined in the wizard while creating the method and cannot be changed.

Parameter	Description	Values
Method name	Defines the name of the method. The system copies the method name that has been defined with the function Method wizard .	Text (122 characters)
Comment	The method can be described with a comment.	Text (0128 characters)
Lock method	Locks the method for other users and from further editing while running.	Active Inactive*

^{*} Factory setting

6.2.1.2 ID format

Task IDs

Parameter	Description	Values
Number of task	Defines the number of task IDs.	0 1* 2 3
IDs	If the value of the option Number of task IDs is larger than 0, the	
	options Task ID, Description and Prefix/Default value appear for	
	every single task ID.	

Task ID 1	Defines the naming type of the task ID.	Manual with default* I
	Manual with default : The value of the task ID can be entered manually at method execution time.	Automatic timestamp
	Automatic timestamp : The system provides a value created from a prefix with the current date and time appended.	
Description	Allows to define a label for each task ID field.	Text (032 characters)
Default value	Defines a default value for the task ID. The value of the task ID can be changed manually while executing the method.	Text (032 characters)
	This option only appears when the option Manual with default is activated.	
Prefix	Defines a prefix for the task ID.	Text (032 characters)
	This option only appears when the option Automatic timestamp is activated.	

^{*} Factory setting

Result IDs

Parameter	Description	Values
Number of result	Defines the number of result IDs.	0 1* 2 3
IDs	If the value of the option Number of result IDs is larger than 0, the options Result ID , Description and Prefix/Default value appear for every single result ID.	
Result ID 1	Defines the naming type of the result ID.	Manual with default* I
	Manual with default : The value of the result ID can be entered manually at method execution time.	Automatic counter
	Automatic counter : The system provides a value created from a prefix with an unique number (counter) appended.	
Description	Allows to define a label for each result ID.	Text (032 characters)
Default value	Defines a default value for the result ID. The value of the result ID can be changed manually while executing the method.	Text (032 characters)
	This option only appears when the option Manual with default is activated.	
Prefix	Defines a prefix for the result ID.	Text (032 characters)
	This option only appears when the option Automatic counter is activated.	

^{*} Factory setting

6.2.1.3 Weighing item

A target weight with tolerance limits can be defined for the method. The method **General Weighing** includes a single item in **Weighing item**, whereas several items can be defined for the method **General Weighing with templates** in **Templates**.

Initial values for weighing

Parameter	Description	Values
Unit	Defines the unit of the primary weighing result.	The available units depend on the balance model.
Target weight	Defines the target weight. The target weight will be shown in the weighing-in aid of the balance (SmartTrac). When a target weight including tolerances is defined, the SmartTrac indicates if the current display weight is in tolerance or not.	Numeric

-Tolerance	Defines the lower tolerance limit.	Numeric
	This option only appears when the option Target weight is activated.	
+Tolerance	Defines the upper tolerance limit.	Numeric
	This option only appears when the option Target weight is activated.	

See also

Creating a method "General weighing" ▶ Page 44

6.2.1.4 Templates

This option is only available for the method **General Weighing with templates**.

Parameter	Description	Values
Sample ID	Defines the name of the sample.	Text (032 characters)
Unit	Defines the unit of the primary weighing result.	The available units depend on the balance model.
Target weight	Defines the target weight. The target weight will be shown in the weighing-in aid of the balance (SmartTrac). When a target weight including tolerances is defined, the SmartTrac indicates if the current display weight is in tolerance or not.	Numeric
-Tolerance	Defines the lower tolerance limit.	Numeric
	This option only appears when the option Target weight is activated.	
+Tolerance	Defines the upper tolerance limit.	Numeric
	This option only appears when the option Target weight is activated.	

See also

- Creating a method "General weighing" ▶ Page 44
- Using method templates ▶ Page 53

6.2.1.5 Weighing

Parameter	Description	Values
Show info weight	With this option activated a secondary info weight appears on the weighing screen on top of the weighing result.	Active I Inactive*
Info unit	Defines the unit of the info weight.	The available units
	This option only appears when the option Show info weight is activated.	depend on the balance model.

^{*} Factory setting

Custom unit

When the parameter **Define custom unit** is activated, additional parameters can be defined.

Parameter	Description	Values
Define custom unit	With this option activated, a specific weighing unit can be defined. This allows calculations, e.g., surfaces or volumes, to be carried out directly during the determination of the weighing result.	Active I Inactive*
	The custom units are available in all menus and input fields in which weighing units can be selected.	

Name	Defines the name of the custom unit.	Text (06 characters)
Formula	Defines how subsequently defined value for Factor is calculated. There are 2 formulae available:	Multiplicative* Divisive
	Multiplicative: Multiplies the net weight by the factor.	
	Divisive: The factor is divided by the net weight.	
	The formula can be used, for example, to simultaneously take into account a known error factor while weighing.	
Factor	Defines the factor with which the effective weighing result (net weight) is calculated via the previously selected Formula .	Numeric
Display	Defines the formatting for the weighing result.	Numeric
readability	Example: A setting of "0.05" defines two places after the decimal point with rounding to 5. A determined result of 123.4777 is consequently displayed as 123.50.	
	This function can only be used to reduce the resolution of the weighing result. No value must therefore be entered that exceeds the maximum balance resolution. Values that are too small are automatically rounded off.	

^{*} Factory setting

Weighing settings

Parameter	Description	Values
Tolerance profile	A tolerance profile stores all the necessary balance settings needed for a certain weighing method. It is possible to create different tolerance profiles for different weighing methods.	Available tolerance profiles are model-specific.
Weight capture mode	Defines the behavior when the button to add the result was tapped or the add result was triggered by the automatic weighing result creation.	Stable* Immediate Dynamic
	Stable: The system waits for a stable weight.	
	Immediate : The system doesn't wait for a stable weight. The system waits for the defined amount of seconds (Weight capture delay). After the weight capture delay, the weight value from the weight stream is captured.	
	Dynamic : The balance calculates the weight as the average of a number of weighing operations over a defined time (Weight capture duration).	
Weight capture delay	Defines the time in seconds the balance waits for capturing the weight after the button to add the result was tapped or the add result was triggered by the automatic weighing result creation.	Numeric (5 seconds* I 060 seconds)
	This option only appears when the Weight capture mode is set to Immediate or Dynamic .	

^{*} Factory setting

Statistics

Parameter	Description	Values
Activate statistics	If Activate statistics is set to Active , the following statistics will be calculated:	Active I Inactive*
	Count: Number of items used for the statistics	
	• Sum : Sum of all value (decimal places and unit according to the method settings)	
	Minimum: Smallest value (decimal places and unit according to the method settings)	
	Maximum: Largest value (decimal places and unit according to the method setting)	
	Range: Difference between the largest and smallest values (decimal places and unit according to the method settings)	
	Average: The values are summed up and divided by the number of values, rounded to 1 digit more than the configured decimal places in the method settings (unit according to the method settings)	
	Standard deviation: Standard deviation rounded to 1 digit more than the configured decimal places in the method settings (unit according to the method settings)	
	Relative standard deviation: Relative standard deviation (rounded to 2 decimal places, in %)	
	The statistical values are calculated and displayed as soon as a result is added or updated.	

^{*} Factory setting

Electrostatic

Parameter	Description	Values
Ionizer	Defines whether the ionizer is activated/deactivated.	Active I Inactive*

^{*} Factory setting

See also

Creating a method "General weighing" ▶ Page 44

6.2.1.6 Automation

Parameter	Description	Values
Barcode data target	If a barcode reader is connected to the balance, this option defines how the data is to be processed.	Keyboard Input* Target weight value Task ID 1 Result ID 1
	Keyboard Input : The data is written in the currently open input window. If no input window is open, the data is ignored.	
	Target weight value : The barcode data is interpreted as a value for the target weight.	
	Task ID 1 : The received barcode data is treated as identification text for this task ID.	
	Result ID 1 : The received barcode data is treated as identification text for this result ID.	
	The available items in the drop-down menu depend on the Number of task IDs and Number of result IDs specified for the method.	
	Make sure that the characters of the scanned barcode are compatible with the format of the field where they should be inserted.	

Automatic feeder support

When the parameter **Automatic feeder support** is activated, additional parameters can be defined to set up the automatic feeder LV12.

Parameter	Description	Values
Automatic feeder	Enables or disables the automatic feeder support.	Active Inactive*
support	To use the automatic feeder support, the automatic feeder has to be connected to the balance by USB and has to be configured correctly.	
Number of weighing items	Defines the number of items the automatic feeder will deliver to the balance.	Numeric 20* (1100)
Plausibility limits	Defines the plausibility limit for measured values.	Numeric (30 %* I
	The plausibility limit relates to the defined target weight.	0100)
	Example: With a plausibility limit of 30%, all weight values that are within $\pm 30\%$ of the target weight are regarded as plausible and are transferred into the statistics. All other weight values are being ignored and excluded from the statistics.	
Discharge feeder	Discharge is used to empty the automatic feeder of all objects.	Active I Inactive*
at the end	Active : The automatic feeder feeds at the configured discharge feed rate and stops 90 seconds after the last object has passed the light barrier.	
	Inactive: No automatic emptying.	
Feed rate	Defines the rate by which the automatic feeder delivers the parts to the balance. Select between the following options:	Slow Normal* Fast Very fast
	Slow: Lowest feed rate	
	Normal: Lower intermediate feed rate	
	Fast: Upper intermediate feed rate	
	Very fast: Highest feed rate	

^{*} Factory setting

Weighing automation

Parameter	Description	Values
Automatic zero	If Automatic zero is set to Active , the balance automatically zeros the balance when the weight falls below a predefined threshold.	Active Inactive*
Automatic zero	Defines the threshold of the option Automatic zero .	Numeric
threshold	This option only appears when the option Automatic zero is activated.	
Tare Mode	Defines the tare mode.	None* Automatic tare
	None: No automatic tare.	Pretare
	Automatic tare : The balance stores automatically the first stable weight as the tare weight.	
	Pretare : Allows you to enter manually a numerical entry of a fixed tare weight.	
Automatic tare	Defines the threshold of the option Tare Mode.	Numeric
threshold	This value defines the minimum weight that must be applied to the weighing pan so that it is automatically stored as the tare weight. If the weight is below the limits, it is not automatically transferred to the tare memory.	
	Instead of entering the weight, the lightest tare container can be placed on the weighing pan and the button \(\frac{1}{4}\) subsequently pressed. The applied weight is directly taken over as a limit.	
	This option only appears when the option Tare Mode is set to Automatic tare .	
Pretare value	Defines a weight value for the pretare function.	Numeric
	Instead of entering the value, the respective tare container can be placed on the weighing pan and the button $\stackrel{1}{=}$ subsequently pressed. The weight is directly taken over as pretare value.	
	This option only appears when the option Tare Mode is set to Pretare .	
Automatic result	Automatically generates a weighing result after a threshold is reached.	None I With sample tare* I Without sample tare
	None: No automatic result will be generated.	
	With sample tare : After a weight value that reached the threshold is being removed from the weighing pan, the balance is being tared.	
	Without sample tare : After a weight value that reached the threshold is being removed from the weighing pan, the balance is not being tared.	
	This parameter is only available if Automatic feeder support is set to Inactive .	
Automatic result threshold	Defines the threshold of the option Automatic result . The result is automatically added to the protocol only if the weight of the sample is larger than this threshold. This option only appears when the option Automatic result is activated.	Numeric

Weight trigger	Defines the behaviour of the option Automatic result threshold .	Exceeding* Falling below
	Exceeding : The weighing result is generated when the weight exceeds the defined threshold.	
	Falling below : The weighing result is generated when the weight falls below the defined threshold.	
	This parameter is only available if Automatic feeder support is set to Inactive and Automatic result is set to Without sample tare .	
Automatic tare after result	If set to Active , the balance is automatically tared when a result is added to the Protocol .	Active I Inactive*
Automatic task completion	If Automatic task completion is set to Active , the balance automatically completes a running task after the last template has been added to the Protocol .	Active I Inactive*
	This option is only available if the method is using templates.	

^{*} Factory setting

See also

Creating a method "General weighing" ▶ Page 44

6.2.1.7 Print / Export

This section is divided into the following subsections:

- Protocol printout and data export
- Label printout for task
- Label printout for weighing item

6.2.1.7.1 Protocol printout and data export

Automatic data output

Parameter	Description	Values
Strip printer	Activates/Deactivates automatic printing of the protocol on a strip printer when the Complete button is tapped. The data to be transmitted to the printer can be defined in the section Template settings .	Active I Inactive*
Protocol export	Activates/Deactivates the automatic data export to a file server or USB storage device when the Complete button is tapped.	Active I Inactive*
Weight value	Activates/Deactivates the option to automatically send the weighing value over USB or Ethernet when tapping Add to protocol .	Active I Inactive*

^{*} Factory setting

Protocol template for printout

This menu item can be used to define information to appear in the **Protocol**. The extensive menu is divided into six submenus in which options for the printout can be defined. Information can be enabled or disabled by activating or deactivating the corresponding checkbox.

Each individual parameter can set to **Inactive** or **Active** via the corresponding check box. To enable or disable all parameters at once, proceed as follows:

- 1 To deselect all check boxes at once, tap To Deselect all
 - ⇒ All parameters are set to **Inactive**.
- 2 To select all check boxes at once, tap To Select all
 - ⇒ All parameters are set to **Active**.

Template settings

Parameter	Description	Values
Header and Footer	Defines the header (with title, date and time) and/or footer (with signature and end line) to be printed/exported.	Header* Title* Date/ time Signature* Separating lines* Group titles
Balance infor- mation	Defines which information about the balance is being printed/exported.	Balance type I Balance ID* I Balance serial number I Software version
Quality infor- mation	Defines which quality information is being printed/exported.	Tolerance profile I Adjustment date/time I Routine test name I Routine test last execution date I Routine test result I GWP Approved state I Level state I MinWeigh state
Task information	Defines which information about the task is being printed/export.	Method name I Method comment I Task IDs I Custom unit settings I Automatic result settings I Count I Sum I Average I Minimum I Maximum I Range I Standard deviation I Relative standard deviation
Weighing item information	Defines which information about the weighing items is being printed/exported.	Show excluded weighing items I Result State I Result IDs* I GWP Approved state I Level state I MinWeigh state I Tolerance state I Target and tolerances state
Result detail information	Defines which information related to the result of the measurement is being printed/exported.	Weight* Tare weight Gross weight Info weight Date/time* Stability

^{*} Factory setting

Label printout for task

Parameter	Description	Values
Automatic label printout for task	When set to Active , the task label is automatically printed when tapping Complete .	Active I Inactive*
Used template	Chooses the label template.	Available labels are shown below.

^{*} Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
	l '	Available entries depend on the method settings.

Barcode settings

The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.

Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries.	TAB I Form feed I
	The option 2D barcode delimiter appears only when the selected Used template contains several 2D codes.	Carriage return Space User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

Label printout for weighing items

Parameter	Description	Values
Automatic label printout for task	When set to Active , the task label is automatically printed when tapping Complete .	Active I Inactive*
Used template	Chooses the label template.	Available labels are shown below.

^{*} Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
Label field 1	Defines which information appears in each label field. The	Available entries depend
	number of label fields depends on the selected template.	on the method settings.


Barcode settings


The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.

Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries.	TAB Form feed
	The option 2D barcode delimiter appears only when the selected Used template contains several 2D codes.	Carriage return Space User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

Available labels

The following label layouts can be selected:





6.2.2 Settings: method "Simple formulation"



The section **Simple formulation** is divided into the following subsections:

- **₹**] General
- **₩**Formulation
- 🕶 ID format
- Weighing item (Only available for the method Simple formulation)
- Templates (Only available for the method Simple formulation with templates)
- 🕏 Weighing

• 📮 Print / Export

See also

- Creating a method "Simple formulation" ▶ Page 45
- Editing a method ▶ Page 52

6.2.2.1 General

The **Method type** is defined in the wizard while creating the method and cannot be changed.

Parameter	Description	Values
Method name	Defines the name of the method. The system copies the method name that has been defined with the function Method wizard .	Text (122 characters)
Comment	The method can be described with a comment.	Text (0128 characters)
Lock method	Locks the method for other users and from further editing while running.	Active I Inactive*

^{*} Factory setting

6.2.2.2 Formulation

Parameter	Description	Values
Calculate target	In this section the flask volume and the concentration of the target can be defined.	None* I Flask volume I Target concentration
	Flask volume : Calculates the target weight according to the reference flask volume and the actual flask volume.	
	Target concentration : Calculates the target weight according to the desired target concentration.	
	This option only appears for the method Simple formulation with templates .	
Calculate concentration per component	Calculates the concentration of the substance based on the molecular weight, purity volume and dosed amount of substance, e.g. mmol/l.	Active Inactive*
	If this option is activated, the sub-options Reference weight (100%) and Concentration unit appear in the list.	
Calculate amount of component	Calculates the effective amount of a component based on the current weighing value.	Active I Inactive*
Concentration unit	Defines the concentration unit.	mol/l* mmol/l mg/ml mg/l µg/ml g/ml g/l %
Reference flask	Defines the volume of the reference flask.	Numeric (1 ml* l
volume	This parameter is only available if the ${\bf Concentration\ unit}$ is not set to ${\bf \%}.$	1999999 ml)
Reference weight	Defines the reference weight.	Depending on the
(100%)	Instead of entering the reference weight manually, press subsequently the button 🛓. The applied weight is directly taken over as a reference weight.	capacity of the balance.
	This parameter is only available if the Concentration unit is set to $\%$.	

^{*} Factory setting

Production and expiry date

Parameter	Description	Values
Production date	Defines the production date.	None I Current date* I Manual input
	Current date : The production date is set automatically to the date when starting the weighing task.	
	Manual input : The production date can be entered manually when starting the weighing task.	
Expiry date	Defines the expiry date of the substance.	None* Period Manual input
	Period : The expiry date is set automatically when starting the weighing task (expiry date = date when starting the weighing task + number of days defined in the field Period .	
	Manual input : The expiry date can be entered manually when starting the weighing task.	
Period	Defines the period of the expiry date.	Numeric (1 day* I 19999 days)
	This option only appears when the option Expiry date is set to Period .	

^{*} Factory setting

See also

Creating a method "Simple formulation" ▶ Page 45

6.2.2.3 ID format

Task IDs

Parameter	Description	Values
Number of task	Defines the number of task IDs.	0 1* 2 3
IDs	If the value of the option Number of task IDs is larger than 0, the options Task ID , Description and Prefix/Default value appear for every single task ID.	
Task ID 1	Defines the naming type of the task ID.	Manual with default* I
	Manual with default : The value of the task ID can be entered manually at method execution time.	Automatic timestamp
	Automatic timestamp : The system provides a value created from a prefix with the current date and time appended.	
Description	Allows to define a label for each task ID field.	Text (032 characters)
Default value	Defines a default value for the task ID. The value of the task ID can be changed manually while executing the method.	Text (032 characters)
	This option only appears when the option Manual with default is activated.	
Prefix	Defines a prefix for the task ID.	Text (032 characters)
	This option only appears when the option Automatic timestamp is activated.	

^{*} Factory setting

Result IDs

Parameter	Description	Values
Number of result	Defines the number of result IDs.	0 1* 2 3
IDs	If the value of the option Number of result IDs is larger than 0,	
	the options Result ID, Description and Prefix/Default value	
	appear for every single result ID.	

Result ID 1	Defines the naming type of the result ID.	Manual with default* Automatic counter
	Manual with default : The value of the result ID can be entered manually at method execution time.	
	Automatic counter : The system provides a value created from a prefix with an unique number (counter) appended.	
Description	Allows to define a label for each result ID.	Text (032 characters)
Default value	Defines a default value for the result ID. The value of the result ID can be changed manually while executing the method.	Text (032 characters)
	This option only appears when the option Manual with default is activated.	
Prefix	Defines a prefix for the result ID.	Text (032 characters)
	This option only appears when the option Automatic counter is activated.	

^{*} Factory setting

6.2.2.4 Weighing item

A target weight with tolerance limits can be defined for the method. The method Simple formulation includes a single item in Weighing item, whereas several items can be defined for the method Simple formulation with templates in Templates.

Initial values for weighing

Parameter	Description	Values
Unit	Defines the unit of the primary weighing result.	The available units depend on the balance model.
Target weight	Defines the target weight. The target weight will be shown in the weighing-in aid of the balance (SmartTrac). When a target weight including tolerances is defined, the SmartTrac indicates if the current display weight is in tolerance or not.	Numeric
—Tolerance	Defines the lower tolerance limit. This option only appears when the option Target weight is activated.	Numeric
+Tolerance	Defines the upper tolerance limit. This option only appears when the option Target weight is activated.	Numeric

See also

Creating a method "Simple formulation" ▶ Page 45

6.2.2.5 Templates



Note

Detailed information about how to create templates and the use of templates can be found in the section Using templates.

Parameter	Description	Values
Component ID	Assigns a name to the component ID	Text (032 characters)
Purity	To define the purity of the component.	Numeric
	This parameter is only accessible if Calculate amount of component is set to Active .	(0.001100%)

Unit	Defines the unit of the primary weighing result.	The available units depend on the balance model.
Target weight	Defines the target weight. The target weight will be shown in the weighing-in aid of the balance (SmartTrac). When a target weight including tolerances is defined, the SmartTrac indicates if the current display weight is in tolerance or not.	Numeric
Target concen- tration	To define the concentration of the component.	Numeric (0.001100%)
-Tolerance	Defines the lower tolerance limit.	Numeric
	This option only appears when the option Target weight is activated.	
+Tolerance	Defines the upper tolerance limit.	Numeric
	This option only appears when the option Target weight is activated.	

See also

- Creating a method "Simple formulation" ▶ Page 45
- Using method templates ▶ Page 53

6.2.2.6 Weighing

Parameter	Description	Values
Show info weight	With this option activated a secondary info weight appears on the weighing screen on top of the weighing result.	Active I Inactive*
Info unit	Defines the unit of the info weight.	The available units
	This option only appears when the option Show info weight is activated.	depend on the balance model.

^{*} Factory setting

Weighing settings

Parameter	Description	Values
'	A tolerance profile stores all the necessary balance settings needed for a certain weighing method. It is possible to create different tolerance profiles for different weighing methods.	Available tolerance profiles are model-specific.

Electrostatic

Parameter	Description	Values
Ionizer	Defines whether the ionizer is activated/deactivated.	Active Inactive*

^{*} Factory setting

See also

Creating a method "Simple formulation" ▶ Page 45

6.2.2.7 Automation

Parameter	Description	Values
Barcode data target	If a barcode reader is connected to the balance, this option defines how the data is to be processed.	Keyboard Input* Target weight value Task ID 1 Result ID 1
	Keyboard Input : The data is written in the currently open input window. If no input window is open, the data is ignored.	
	Target weight value : The barcode data is interpreted as a value for the target weight.	
	Task ID 1 : The received barcode data is treated as identification text for this task ID.	
	Result ID 1 : The received barcode data is treated as identification text for this result ID.	
	The available items in the drop-down menu depend on the Number of task IDs and Number of result IDs specified for the method.	
	Make sure that the characters of the scanned barcode are compatible with the format of the field where they should be inserted.	

^{*} Factory setting

Weighing automation

Parameter	Description	Values
Automatic zero	If Automatic zero is set to Active , the balance automatically zeros the balance when the weight falls below a predefined threshold.	Active I Inactive*
Automatic zero	Defines the threshold of the option Automatic zero .	Numeric
threshold	This option only appears when the option Automatic zero is activated.	
Tare Mode	Defines the tare mode.	None* Automatic tare
	None: No automatic tare.	Pretare
	Automatic tare : The balance stores automatically the first stable weight as the tare weight.	
	Pretare : Allows you to enter manually a numerical entry of a fixed tare weight.	
Automatic tare	Defines the threshold of the option Tare Mode.	Numeric
threshold	This value defines the minimum weight that must be applied to the weighing pan so that it is automatically stored as the tare weight. If the weight is below the limits, it is not automatically transferred to the tare memory.	
	Instead of entering the weight, the lightest tare container can be placed on the weighing pan and the button \(\frac{1}{4}\) subsequently pressed. The applied weight is directly taken over as a limit.	
	This option only appears when the option Tare Mode is set to Automatic tare .	
Pretare value	Defines a weight value for the pretare function.	Numeric
	Instead of entering the value, the respective tare container can be placed on the weighing pan and the button \(\delta\) subsequently pressed. The weight is directly taken over as pretare value.	
	This option only appears when the option Tare Mode is set to Pretare .	

Automatic tare after result	If set to Active , the balance is automatically tared when a result is added to the Protocol .	Active I Inactive*
completion	If Automatic task completion is set to Active , the balance automatically completes a running task after the last template has been added to the Protocol .	Active I Inactive*
	This option is only available if the method is using templates.	

^{*} Factory setting

See also

Creating a method "Simple formulation" ▶ Page 45

6.2.2.8 Print / Export

This section is divided into the following subsections:

- Protocol printout and data export
- Label printout for task
- · Label printout for weighing item

Protocol printout and data export

Automatic data output

Parameter	Description	Values
Strip printer	Activates/Deactivates automatic printing of the protocol on a strip printer when the Complete button is tapped. The data to be transmitted to the printer can be defined in the section Template settings .	Active I Inactive*
Protocol export	Activates/Deactivates the automatic data export to a file server or USB storage device when the Complete button is tapped.	Active I Inactive*
Weight value	Activates/Deactivates the option to automatically send the weighing value over USB or Ethernet when tapping Add to protocol .	Active I Inactive*

^{*} Factory setting

Protocol template for printout

This menu item can be used to define information to appear in the **Protocol**. The extensive menu is divided into six submenus in which options for the printout can be defined. Information can be enabled or disabled by activating or deactivating the corresponding checkbox.

Each individual parameter can set to **Inactive** or **Active** via the corresponding check box. To enable or disable all parameters at once, proceed as follows:

- 1 To deselect all check boxes at once, tap To Deselect all
 - ⇒ All parameters are set to **Inactive**.
- 2 To select all check boxes at once, tap To Select all
 - ⇒ All parameters are set to **Active**.

Template settings

Parameter	Description	Values
Header and Footer	Defines the header (with title, date and time) and/or footer (with signature and end line) to be printed/exported.	Header* Title* Date/ time Signature* Separating lines* Group titles

Balance infor- mation	Defines which information about the balance is being printed/exported.	Balance type I Balance ID* I Balance serial number I Software version
Quality infor- mation	Defines which quality information is being printed/exported.	Tolerance profile I Adjustment date/time I Routine test name I Routine test last execution date I Routine test result I GWP Approved state I Level state I MinWeigh state
Task information	Defines which information about the task is being printed/export.	Method name I Method comment I Task ID I Flask volume* I Reference weight* I Expiry date* I Production date*
Weighing item information	Defines which information about the weighing items is being printed/exported.	Show excluded weighing items Result State* Result IDs* Molar mass Purity Amount of substance* Concentration* GWP Approved state Level state* MinWeigh state Tolerance state* Target and tolerances state*
Result detail information	Defines which information related to the result of the measurement is being printed/exported.	Weight* Tare weight Gross weight Info weight Date/time* Stability

^{*} Factory setting

Label printout for task

Parameter	Description	Values
Automatic label printout for task	When set to Active , the task label is automatically printed when tapping Complete .	Active I Inactive*
Used template	Chooses the label template.	Available labels are shown below.

^{*} Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
Label field 1	· ·	Available entries depend on the method settings.

Barcode settings

The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.

Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries.	TAB I Form feed I
	The option 2D barcode delimiter appears only when the selected Used template contains several 2D codes.	Carriage return Space User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

Label printout for weighing items

Parameter	Description	Values
Automatic label printout for task	When set to Active , the task label is automatically printed when tapping Complete .	Active I Inactive*
Used template	Chooses the label template.	Available labels are shown below.

^{*} Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
Label field 1	Defines which information appears in each label field. The	Available entries depend
	number of label fields depends on the selected template.	on the method settings.

Barcode settings


The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.

Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries.	TAB I Form feed I
	The option 2D barcode delimiter appears only when the selected Used template contains several 2D codes.	Carriage return Space User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

Availlable Labels

The following label layouts can be selected:





6.2.3 Settings: method "Piece counting"

Navigation: ▶ Methods > ₹ Methods list > ♣ Piece counting > ✓ Edit



The section **Piece counting** is divided into the following subsections:

- ₹] General
- • ID format
- Weighing item
- 🕏 Weighing
- Print / Export

See also

- Creating a method "Piece counting" ▶ Page 47
- Editing a method ▶ Page 52

6.2.3.1 General

The **Method type** is defined in the wizard while creating the method and cannot be changed.

Parameter	Description	Values
Method name	Defines the name of the method. The system copies the method name that has been defined with the function Method wizard .	Text (122 characters)
Comment	The method can be described with a comment.	Text (0128 characters)
Lock method	Locks the method for other users and from further editing while running.	Active I Inactive*

^{*} Factory setting

6.2.3.2 ID format

Task IDs

Parameter	Description	Values
Number of task IDs	Defines the number of task IDs.	0 1* 2 3
	If the value of the option Number of task IDs is larger than 0, the options Task ID , Description and Prefix/Default value appear for every single task ID.	
Task ID 1	Defines the naming type of the task ID.	Manual with default* I Automatic timestamp
	Manual with default : The value of the task ID can be entered manually at method execution time.	
	Automatic timestamp : The system provides a value created from a prefix with the current date and time appended.	
Description	Allows to define a label for each task ID field.	Text (032 characters)
Default value	Defines a default value for the task ID. The value of the task ID can be changed manually while executing the method.	Text (032 characters)
	This option only appears when the option Manual with default is activated.	
Prefix	Defines a prefix for the task ID.	Text (032 characters)
	This option only appears when the option Automatic timestamp is activated.	

^{*} Factory setting

Result IDs

Parameter	Description	Values
Number of result IDs	Defines the number of result IDs.	0 1* 2 3
	If the value of the option Number of result IDs is larger than 0, the options Result ID , Description and Prefix/Default value appear for every single result ID.	
Result ID 1	Defines the naming type of the result ID.	Manual with default* Automatic counter
	Manual with default : The value of the result ID can be entered manually at method execution time.	
	Automatic counter : The system provides a value created from a prefix with an unique number (counter) appended.	
Description	Allows to define a label for each result ID.	Text (032 characters)
Default value	Defines a default value for the result ID. The value of the result ID can be changed manually while executing the method.	Text (032 characters)
	This option only appears when the option Manual with default is activated.	

Prefix	Defines a prefix for the result ID.	Text (032 characters)
	This option only appears when the option Automatic counter is activated.	

^{*} Factory setting

6.2.3.3 Weighing item

Initial values for weighing

Parameter	Description	Values
Reference PCS	Defines a reference unit quantity. This allows you to determine the reference unit weight with a defined, fixed number of pieces.	Numeric (10* I 110000)
Reference average weight	Defines the average weight for one piece. The average weight of one piece serves as basis for the piece counting. During task execution, the balance calculates the actual number of pieces on the weighing pan based on the measured weight and the average weight of one piece.	Numeric
Target weight	Defines the target weight. The target weight will be shown in the weighing-in aid of the balance (SmartTrac). When a target weight including tolerances is defined, the SmartTrac indicates if the current display weight is in tolerance or not.	Numeric
-Tolerance	Defines the lower tolerance limit.	Numeric
	This option only appears when the option Target weight is activated.	
+Tolerance	Defines the upper tolerance limit.	Numeric
	This option only appears when the option Target weight is activated.	

^{*} Factory setting

See also

Creating a method "Piece counting" ▶ Page 47

6.2.3.4 Weighing

Parameter	Description	Values
Show info weight	With this option activated a secondary info weight appears on the weighing screen on top of the weighing result.	Active I Inactive*
Info unit	Defines the unit of the info weight.	The available units
	This option only appears when the option Show info weight is activated.	depend on the balance model.

^{*} Factory setting

Weighing settings

Parameter	Description	Values
•	A tolerance profile stores all the necessary balance settings needed for a certain weighing method. It is possible to create different tolerance profiles for different weighing methods.	Available tolerance profiles are model-specific.

Weight capture mode	Defines the behavior when the button to add the result was tapped or the add result was triggered by the automatic weighing result creation.	Stable* I Immediate
	Stable: The system waits for a stable weight.	
	Immediate: The system doesn't wait for a stable weight. The system waits for the defined amount of seconds (Weight capture delay). After the weight capture delay, the weight value from the weight stream is captured.	
Weight capture delay	Defines the time in seconds the balance waits for capturing the weight after the button to add the result was tapped or the add result was triggered by the automatic weighing result creation.	Numeric (5 seconds* I 060 seconds)
	This option only appears when the Weight capture mode is set to Immediate .	

^{*} Factory setting

Statistics

Parameter	Description	Values
Activate statistics	If Activate statistics is set to Active , the following statistics will be calculated:	Active I Inactive*
	Count: Number of items used for the statistics	
	Sum: Sum of all value (decimal places and unit according to the method settings)	
	Minimum: Smallest value (decimal places and unit according to the method settings)	
	Maximum: Largest value (decimal places and unit according to the method setting)	
	Range: Difference between the largest and smallest values (decimal places and unit according to the method settings)	
	Average: The values are summed up and divided by the number of values, rounded to 1 digit more than the configured decimal places in the method settings (unit according to the method settings)	
	Standard deviation: Standard deviation rounded to 1 digit more than the configured decimal places in the method settings (unit according to the method settings)	
	Relative standard deviation: Relative standard deviation (rounded to 2 decimal places, in %)	
	The statistical values are calculated and displayed as soon as a result is added or updated.	

^{*} Factory setting

See also

Creating a method "Piece counting" ▶ Page 47

6.2.3.5 Automation

Parameter	Description	Values
Barcode data target	If a barcode reader is connected to the balance, this option defines how the data is to be processed.	Keyboard Input* Target weight value Task ID 1
	Keyboard Input : The data is written in the currently open input window. If no input window is open, the data is ignored.	I Result ID 1 I
	Target weight value : The barcode data is interpreted as a value for the target weight.	
	Task ID 1 : The received barcode data is treated as identification text for this task ID.	
	Result ID 1 : The received barcode data is treated as identification text for this result ID.	
	The available items in the drop-down menu depend on the Number of task IDs and Number of result IDs specified for the method.	
	Make sure that the characters of the scanned barcode are compatible with the format of the field where they should be inserted.	

^{*} Factory setting

Weighing automation

Parameter	Description	Values
Automatic zero	If Automatic zero is set to Active , the balance automatically zeros the balance when the weight falls below a predefined threshold.	Active I Inactive*
Automatic zero	Defines the threshold of the option Automatic zero .	Numeric
threshold	This option only appears when the option Automatic zero is activated.	
Tare Mode	Defines the tare mode.	None* Automatic tare
	None: No automatic tare.	Pretare
	Automatic tare : The balance stores automatically the first stable weight as the tare weight.	
	Pretare : Allows you to enter manually a numerical entry of a fixed tare weight.	
Automatic tare	Defines the threshold of the option Tare Mode.	Numeric
threshold	This value defines the minimum weight that must be applied to the weighing pan so that it is automatically stored as the tare weight. If the weight is below the limits, it is not automatically transferred to the tare memory.	
	Instead of entering the weight, the lightest tare container can be placed on the weighing pan and the button $\stackrel{1}{=}$ subsequently pressed. The applied weight is directly taken over as a limit.	
	This option only appears when the option Tare Mode is set to Automatic tare .	
Pretare value	Defines a weight value for the pretare function.	Numeric
	Instead of entering the value, the respective tare container can be placed on the weighing pan and the button $\stackrel{1}{=}$ subsequently pressed. The weight is directly taken over as pretare value.	
	This option only appears when the option Tare Mode is set to Pretare .	

Automatic result	Automatically generates a weighing result after a threshold is reached.	None* Without sample tare
	None: No automatic result will be generated.	
	Without sample tare : After a weight value that reached the threshold is being removed from the weighing pan, the balance is not being tared.	
Automatic result threshold	Defines the threshold of the option Automatic result . The result is automatically added to the protocol only if the weight of the sample is larger than this threshold. This option only appears when the option Automatic result is activated.	Numeric
Weight trigger	Defines the behaviour of the option Automatic result threshold .	Exceeding* Falling
	Exceeding : The weighing result is generated when the weight exceeds the defined threshold.	below
	Falling below : The weighing result is generated when the weight falls below the defined threshold.	
	This parameter is only available if Automatic result is set to Without sample tare .	
Automatic tare after result	If set to Active , the balance is automatically tared when a result is added to the Protocol .	Active I Inactive*

^{*} Factory setting

When using **Automatic result**, make sure that the **Reference average weight** of one piece is larger than the **Automatic result threshold**.

See also

Creating a method "Piece counting" ▶ Page 47

6.2.3.6 Print / Export

This section is divided into the following subsections:

- Protocol printout and data export
- Label printout for task
- Label printout for weighing item

Protocol printout and data export

Automatic data output

Parameter	Description	Values
Strip printer	Activates/Deactivates automatic printing of the protocol on a strip printer when the Complete button is tapped. The data to be transmitted to the printer can be defined in the section Template settings .	Active I Inactive*
Protocol export	Activates/Deactivates the automatic data export to a file server or USB storage device when the Complete button is tapped.	Active I Inactive*
Weight value	Activates/Deactivates the option to automatically send the weighing value over USB or Ethernet when tapping Add to protocol .	Active I Inactive*

^{*} Factory setting

Protocol template for printout

This menu item can be used to define information to appear in the **Protocol**. The extensive menu is divided into six submenus in which options for the printout can be defined. Information can be enabled or disabled by activating or deactivating the corresponding checkbox.

Each individual parameter can set to **Inactive** or **Active** via the corresponding check box. To enable or disable all parameters at once, proceed as follows:

- 1 To deselect all check boxes at once, tap 🕞 Deselect all
 - ⇒ All parameters are set to **Inactive**.
- 2 To select all check boxes at once, tap 🖺 Select all
 - ⇒ All parameters are set to **Active**.

Template settings

Parameter	Description	Values
Header and Footer	Defines the header (with title, date and time) and/or footer (with signature and end line) to be printed/exported.	Header* Title* Date/ time Signature* Separating lines* Group titles
Balance infor- mation	Defines which information about the balance is being printed/ exported.	Balance type I Balance ID* I Balance serial number I Software version
Quality infor- mation	Defines which quality information is being printed/exported.	Tolerance profile I Adjustment date/time I Routine test name I Routine test last execution date I Routine test result I GWP Approved state I Level state I MinWeigh state
Task information	Defines which information about the task is being printed/export.	Method name I Method comment I Task IDs I Automatic result settingsI Count I Sum I Average I Minimum I Maximum I Standard deviation I Relative standard deviation I PCS below —Tolerance I PCS above +Tolerance
Weighing item information	Defines which information about the weighing items is being printed/exported.	Show excluded weighing items Result State* Result IDs* GWP Approved state Level state* MinWeigh state Tolerance state* Target and tolerances state* Reference PCS Reference average weight*
Result detail information	Defines which information related to the result of the measurement is being printed/exported.	Weight* Tare weight Gross weight Info weight Date/time* Stability

^{*} Factory setting

Label printout for task

Parameter	Description	Values
Automatic label printout for task	When set to Active , the task label is automatically printed when tapping Complete .	Active I Inactive*
Used template	Chooses the label template.	Available labels are shown below.

^{*} Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
Label field 1	Defines which information appears in each label field. The	Available entries depend
	number of label fields depends on the selected template.	on the method settings.

Barcode settings

The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.

Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries.	TAB I Form feed I
	The option 2D barcode delimiter appears only when the selected Used template contains several 2D codes.	Carriage return Space User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

Label printout for weighing items

Parameter	Description	Values
Automatic label printout for task	When set to Active , the task label is automatically printed when tapping Complete .	Active I Inactive*
Used template	Chooses the label template.	Available labels are shown below.

^{*} Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
	l ·	Available entries depend
	number of label fields depends on the selected template.	on the method settings.


Barcode settings

The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.

Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries.	TAB Form feed
	The option 2D barcode delimiter appears only when the selected Used template contains several 2D codes.	Carriage return Space User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

Available Labels

The following label layouts can be selected:



6.2.4 Settings: method "Interval weighing"

Navigation: → Methods > ₹ Methods list > 6 Interval weighing > ✓ Edit



The section **Interval weighing** is divided into the following subsections:

• ₹] General

- **&** Interval
- • ID format
- ≝ Weighing item
- 🕏 Weighing
- & Automation
- Print / Export

See also

- Creating a method "Interval weighing" ▶ Page 48
- Editing a method ▶ Page 52

6.2.4.1 General

The Method type is defined in the wizard while creating the method and cannot be changed.

Parameter	Description	Values
Method name	Defines the name of the method. The system copies the method name that has been defined with the function Method wizard .	Text (122 characters)
Comment	The method can be described with a comment.	Text (0128 characters)
Lock method	Locks the method for other users and from further editing while running.	Active I Inactive*

^{*} Factory setting

6.2.4.2 Interval

Parameter	Description	Values
Approximate interval	Defines the duration of a single weighing interval	Numeric (1 s* I 0.560 s)
Measurements	Defines the total number of measurements.	Numeric (3600* I 15000)

^{*} Factory setting



The parameter **Duration** shows the duration of the method based on the values defined for the parameters **Approximate interval** and **Measurements**.

See also

Creating a method "Interval weighing" ▶ Page 48

6.2.4.3 ID format

Task IDs

Parameter	Description	Values
Number of task	Defines the number of task IDs.	0 1* 2 3
IDs	If the value of the option Number of task IDs is larger than 0, the options Task ID , Description and Prefix/Default value appear for every single task ID.	
Task ID 1	Defines the naming type of the task ID. Manual with default: The value of the task ID can be entered manually at method execution time.	Manual with default* I Automatic timestamp
	Automatic timestamp : The system provides a value created from a prefix with the current date and time appended.	

Description	Allows to define a label for each task ID field.	Text (032 characters)
Default value	Defines a default value for the task ID. The value of the task ID can be changed manually while executing the method.	Text (032 characters)
	This option only appears when the option Manual with default is activated.	
Prefix	Defines a prefix for the task ID.	Text (032 characters)
	This option only appears when the option Automatic timestamp is activated.	

^{*} Factory setting

6.2.4.4 Weighing item

Initial values for weighing

Parameter	Description	Values
Unit	Defines the unit of the primary weighing result.	The available units depend on the balance model.

See also

Creating a method "Interval weighing" ▶ Page 48

6.2.4.5 Weighing

Parameter	Description	Values
Show info weight	With this option activated a secondary info weight appears on the weighing screen on top of the weighing result.	Active I Inactive*
Info unit	Defines the unit of the info weight.	The available units
	This option only appears when the option Show info weight is activated.	depend on the balance model.

^{*} Factory setting

Weighing settings

Parameter	Description	Values
•	A tolerance profile stores all the necessary balance settings needed for a certain weighing method. It is possible to create different tolerance profiles for different weighing methods.	Available tolerance profiles are model-specific.

See also

Creating a method "Interval weighing" ▶ Page 48

6.2.4.6 Automation

Parameter	Description	Values
Barcode data target	If a barcode reader is connected to the balance, this option defines how the data is to be processed.	Keyboard Input* Task ID 1
	Keyboard Input : The data is written in the currently open input window. If no input window is open, the data is ignored.	
	Task ID 1 : The received barcode data is treated as identification text for this task ID.	
	The available items in the drop-down menu depend on the Number of task IDs specified for the method.	
	Make sure that the characters of the scanned barcode are compatible with the format of the field where they should be inserted.	

^{*} Factory setting

See also

Creating a method "Interval weighing" ▶ Page 48

6.2.4.7 Print / Export

Protocol printout and data export

Automatic data output

Parameter	Description	Values
Protocol export	Activates/Deactivates the automatic data export to a file server or	Active Inactive*
	USB storage device when the Complete button is tapped.	

^{*} Factory setting

6.2.5 Settings: method "Titration"

Navigation: \blacktriangleright Methods \gt \boxdot Methods list \gt \biguplus Titration \gt \diagup Edit



The section **Titration** is divided into the following subsections:

- ₹] General
- 🗹 Titration
- • ID format
- Weighing item
- 🕏 Weighing
- **&** Automation
- Print / Export

See also

- Creating a method "Titration" ▶ Page 50
- Editing a method ▶ Page 52

6.2.5.1 General

The **Method type** is defined in the wizard while creating the method and cannot be changed.

Parameter	Description	Values
Method name	Defines the name of the method. The system copies the method name that has been defined with the function Method wizard .	Text (122 characters)
Comment	The method can be described with a comment.	Text (0128 characters)
Lock method	Locks the method for other users and from further editing while running.	Active I Inactive*

^{*} Factory setting

6.2.5.2 Titration

Parameter	Description	Values
RFID option	Defines the behaviour of the RFID Reader.	Inactive* Write only
	Write only: The Reader only can write content of the RFID tag.	Read and write
	Read and write : The Reader can read the content of the RFID tag and write data on the RFID tag.	
Density	Defines the density. This option only appears when the option Write only or Read and write is activated.	Numeric (1.0000g/ml* I 0100m/mg)

Parameter	Description	Values
Correction factor	Defines the titration correction factor. This option only appears when the option Write only or Read and write is activated.	Numeric (1.0000* I 01000000)

^{*} Factory setting

See also

Creating a method "Titration" ▶ Page 50

6.2.5.3 ID format

Task IDs

Parameter	Description	Values
Number of task	Defines the number of task IDs.	0 1* 2 3
IDs	If the value of the option Number of task IDs is larger than 0, the options Task ID , Description and Prefix/Default value appear for every single task ID.	
Task ID 1	Defines the naming type of the task ID.	Manual with default* I
	Manual with default : The value of the task ID can be entered manually at method execution time.	Automatic timestamp
	Automatic timestamp : The system provides a value created from a prefix with the current date and time appended.	
Default value	Defines a default value for the task ID. The value of the task ID can be changed manually while executing the method.	Text (032 characters)
	This option only appears when the option Manual with default is activated.	
Prefix	Defines a prefix for the task ID.	Text (032 characters)
	This option only appears when the option Automatic timestamp is activated.	

^{*} Factory setting

Result IDs

Parameter	Description	Values
Number of result	Defines the number of result IDs.	0 1* 2 3
IDs	If the value of the option Number of result IDs is larger than 0, the options Result ID , Description and Prefix/Default value appear for every single result ID.	
Result ID 1	Defines the naming type of the result ID.	Manual with default* I
	Manual with default : The value of the result ID can be entered manually at method execution time.	Automatic counter
	Automatic counter : The system provides a value created from a prefix with an unique number (counter) appended.	
Description	Allows to define a label for each result ID.	Text (032 characters)
Default value	Defines a default value for the result ID. The value of the result ID can be changed manually while executing the method.	Text (032 characters)
	This option only appears when the option Manual with default is activated.	
Prefix	Defines a prefix for the result ID.	Text (032 characters)
	This option only appears when the option Automatic counter is activated.	

^{*} Factory setting



The maximum text length of the **Sample ID** is 32 characters. If the RFID option activated, only the first 20 characters are transferred to the RFID tag.

6.2.5.4 Weighing item

Initial values for weighing

Parameter	Description	Values
Unit	Defines the unit of the primary weighing result.	The available units depend on the balance model.
Target weight	Defines the target weight. The target weight will be shown in the weighing-in aid of the balance (SmartTrac). When a target weight including tolerances is defined, the SmartTrac indicates if the current display weight is in tolerance or not.	Numeric
—Tolerance	Defines the lower tolerance limit. This option only appears when the option Target weight is activated.	Numeric
+Tolerance	Defines the upper tolerance limit. This option only appears when the option Target weight is activated.	Numeric

6.2.5.5 Automation

Parameter	Description	Values
Barcode data target	If a barcode reader is connected to the balance, this option defines how the data is to be processed.	Keyboard Input* I Target weight value I Task ID 1 I Result ID 1 I
	Keyboard Input : The data is written in the currently open input window. If no input window is open, the data is ignored.	
	Target weight value : The barcode data is interpreted as a value for the target weight.	
	Task ID 1 : The received barcode data is treated as identification text for this task ID.	
	Result ID 1 : The received barcode data is treated as identification text for this result ID.	
	The available items in the drop-down menu depend on the Number of task IDs and Number of result IDs specified for the method.	
	Make sure that the characters of the scanned barcode are compatible with the format of the field where they should be inserted.	

Weighing automation

Parameter	Description	Values
Automatic zero	If Automatic zero is set to Active , the balance automatically zeros the balance when the weight falls below a predefined threshold.	Active I Inactive*
Automatic zero	Defines the threshold of the option Automatic zero .	Numeric
threshold	This option only appears when the option Automatic zero is activated.	

Tare Mode	Defines the tare mode.	None* I Automatic tare I
	None: No automatic tare.	Pretare
	Automatic tare : The balance stores automatically the first stable weight as the tare weight.	
	Pretare : Allows you to enter manually a numerical entry of a fixed tare weight.	
Automatic tare	Defines the threshold of the option Tare Mode .	Numeric
threshold	This value defines the minimum weight that must be applied to the weighing pan so that it is automatically stored as the tare weight. If the weight is below the limits, it is not automatically transferred to the tare memory.	
	Instead of entering the weight, the lightest tare container can be placed on the weighing pan and the button \(\frac{1}{4}\) subsequently pressed. The applied weight is directly taken over as a limit.	
	This option only appears when the option Tare Mode is set to Automatic tare .	
Pretare value	Defines a weight value for the pretare function.	Numeric
	Instead of entering the value, the respective tare container can be placed on the weighing pan and the button $\stackrel{\star}{=}$ subsequently pressed. The weight is directly taken over as pretare value.	
	This option only appears when the option Tare Mode is set to Pretare .	
Automatic result	Automatically generates a weighing result after a threshold is reached.	None* Without sample tare
	None: No automatic result will be generated.	
	Without sample tare : After a weight value that reached the threshold is being removed from the weighing pan, the balance is not being tared.	
Automatic result threshold	Defines the threshold of the option Automatic result . The result is automatically added to the protocol only if the weight of the sample is larger than this threshold. This option only appears when the option Automatic result is activated.	Numeric
Weight trigger	Defines the behaviour of the option Automatic result threshold .	Exceeding* Falling
	Exceeding : The weighing result is generated when the weight exceeds the defined threshold.	below
	Falling below : The weighing result is generated when the weight falls below the defined threshold.	
	This parameter is only available if Automatic result is set to Without sample tare .	
Automatic tare after result	If set to Active , the balance is automatically tared when a result is added to the Protocol .	Active I Inactive*

^{*} Factory setting

See also

Creating a method "Titration" ▶ Page 50

6.2.5.6 Print / Export

This section is divided into the following subsections:

• Protocol printout and data export

- Label printout for task
- Label printout for weighing item

Protocol printout and data export

Automatic data output

Parameter	Description	Values
Strip printer	Activates/Deactivates automatic printing of the protocol on a strip printer when the Complete button is tapped. The data to be transmitted to the printer can be defined in the section Template settings .	Active I Inactive*
Protocol export	Activates/Deactivates the automatic data export to a file server or USB storage device when the Complete button is tapped.	Active I Inactive*
Weight value	Activates/Deactivates the option to automatically send the weighing value over USB or Ethernet when tapping Add to protocol .	Active I Inactive*

^{*} Factory setting

Protocol template for printout

This menu item can be used to define information to appear in the **Protocol**. The extensive menu is divided into six submenus in which options for the printout can be defined. Information can be enabled or disabled by activating or deactivating the corresponding checkbox.

Each individual parameter can set to **Inactive** or **Active** via the corresponding check box. To enable or disable all parameters at once, proceed as follows:

- 1 To deselect all check boxes at once, tap 🝙 Deselect all
 - ⇒ All parameters are set to **Inactive**.
- 2 To select all check boxes at once, tap To Select all
 - ⇒ All parameters are set to **Active**.

Template settings

Parameter	Description	Values
Header and Footer	Defines the header (with title, date and time) and/or footer (with signature and end line) to be printed/exported.	Header* Title* Date/ time Signature* Separating lines* Group titles
Balance infor- mation	Defines which information about the balance is being printed/ exported.	Balance type I Balance ID* I Balance serial number I Software version
Quality infor- mation	Defines which quality information is being printed/exported.	Tolerance profile I Adjustment date/time I Routine test name I Routine test last execution date I Routine test result I GWP Approved state I Level state I MinWeigh state

Task information	Defines which information about the task is being printed/export.	Method name I Method comment I Task IDs I Custom unit settings I Automatic result settings I Count I Sum I Average I Minimum I Maximum I Range I Standard deviation I Relative standard deviation
Weighing item information	Defines which information about the weighing items is being printed/exported.	Show excluded weighing items Result State Result IDs* GWP Approved state Electrostatic charge Level state MinWeigh state Tolerance state Target and tolerances state
Result detail information	Defines which information related to the result of the measurement is being printed/exported.	Weight* Tare weight Gross weight Info weight Date/time* Stability

^{*} Factory setting

Parameter	Description	Values
Weighing item information	Defines which information about the weighing items is being printed/exported.	Show excluded weighing items Result State* Result IDs* Density Correction factor GWP Approved state Level state* MinWeigh state Tolerance state* Target and tolerances state*
Task information	Defines which information about the task is being printed/export.	Method name I Method comment I Task IDs I Automatic result settings I

Label printout for task

Parameter	Description	Values
Automatic label printout for task	When set to Active , the task label is automatically printed when tapping Complete .	Active I Inactive*
Used template	Chooses the label template.	Available labels are shown below.

^{*} Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
Label field 1	Defines which information appears in each label field. The	Available entries depend
	number of label fields depends on the selected template.	on the method settings.

Barcode settings

The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.

Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries. The option 2D barcode delimiter appears only when the selected Used template contains several 2D codes.	TAB I Form feed I Carriage return I Space I User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

Label printout for weighing items

Parameter	Description	Values
Automatic label printout for task	When set to Active , the task label is automatically printed when tapping Complete .	Active I Inactive*
Used template	Chooses the label template.	Available labels are shown below.

^{*} Factory setting

Field settings

The content of each label field can be defined individually.

Parameter	Description	Values
	· ·	Available entries depend
	number of label fields depends on the selected template.	on the method settings.

Barcode settings


The content of each barcode field can be defined individually. This section is only available when the selected **Used template** contains at least one 2D code.

Parameter	Description	Values
Delimiter	Defines the delimiter between the barcode entries.	TAB I Form feed I
	The option 2D barcode delimiter appears only when the selected Used template contains several 2D codes.	Carriage return Space User defined
Barcode field 1	Defines which information appears in each barcode. The number of the barcode fields depends on the selected template.	Available entries depend on the method settings.

Available Labels

The following label layouts can be selected:





6.2.6 Settings: method "Density determination"

Navigation: ▶ Methods > ₹ Methods list > ★ Density determination > ✓ Edit



The section **Density determination** is divides into the following subsections:

- **∑**] General
- b Density
- 🖅 ID format
- Weighing item
- 🕏 Weighing
- Export / Export

See also

- Creating a method "Density determination" ▶ Page 51
- Editing a method ▶ Page 52

6.2.6.1 General

The **Method type** is defined in the wizard while creating the method and cannot be changed.

Parameter	Description	Values
Method name	Defines the name of the method. The system copies the method name that has been defined with the function Method wizard .	Text (122 characters)
Comment	The method can be described with a comment.	Text (0128 characters)
Lock method	Locks the method for other users and from further editing while running.	Active Inactive*

^{*} Factory setting

6.2.6.2 Density

The **Determination type** is defined in the wizard while creating the method and cannot be changed. If another **Determination type** is required, a new method must be created. All settings for all types of density determination are described here.

Parameter	Description	Values
Determination	Defines the type of density determination measurement.	Liquid (pycnometer) I
type	Solid determines the density of a solid with the help of a density kit.	Liquid (sinker) Solid*
	Liquid (sinker): determines the density of a liquid.	
	Liquid (pycnometer) : determines the density of a liquid in a glass vessel like a pycnometer.	
Density unit	Defines the unit to be used for density determination.	g/cm3* kg/m3 g/l
	g/cm3 = grams per cm ³ .	
	kg/m3 = kilograms per m ³ .	
	g/I = grams per liter.	
Density value	Defines the number of decimal places.	1 2 3* 4 5
decimal places	The density determination result can be displayed and recorded with 1 to 5 decimal places.	
Air density	Defines the correction factor for force calibration.	Active* Inactive
compensation	Active = the density determination result is corrected by the force calibration correction factor and mean air density.	
	Inactive = no correction takes place.	

^{*} Factory setting

See also

Creating a method "Density determination" ▶ Page 51

6.2.6.3 ID format

Task IDs

Parameter	Description	Values
Number of task	Defines the number of task IDs.	0 1* 2 3
IDs	If the value of the option Number of task IDs is larger than 0, the	
	options Task ID, Description and Prefix/Default value appear for	
	every single task ID.	

Task ID 1	Defines the naming type of the task ID.	Manual with default* I Automatic timestamp
	Manual with default : The value of the task ID can be entered manually at method execution time.	
	Automatic timestamp : The system provides a value created from a prefix with the current date and time appended.	
Description	Allows to define a label for each task ID field.	Text (032 characters)
Default value	Defines a default value for the task ID. The value of the task ID can be changed manually while executing the method.	Text (032 characters)
	This option only appears when the option Manual with default is activated.	
Prefix	Defines a prefix for the task ID.	Text (032 characters)
	This option only appears when the option Automatic timestamp is activated.	

^{*} Factory setting

Result IDs

Parameter	Description	Values
Number of result	Defines the number of result IDs.	0 1* 2 3
IDs	If the value of the option Number of result IDs is larger than 0, the options Result ID , Description and Prefix/Default value appear for every single result ID.	
Result ID 1	Defines the naming type of the result ID.	Manual with default* I
	Manual with default : The value of the result ID can be entered manually at method execution time.	Automatic counter
	Automatic counter : The system provides a value created from a prefix with an unique number (counter) appended.	
Description	Allows to define a label for each result ID.	Text (032 characters)
Default value	Defines a default value for the result ID. The value of the result ID can be changed manually while executing the method.	Text (032 characters)
	This option only appears when the option Manual with default is activated.	
Prefix	Defines a prefix for the result ID.	Text (032 characters)
	This option only appears when the option Automatic counter is activated.	

^{*} Factory setting

6.2.6.4 Weighing item

The weighing item settings are different between the three types of density determination. The settings for **Initial** values for weighing are presented for each type individually.

Initial values for weighing (Determination Type: Solid)

Parameter	Description	Values
Unit	Defines the unit.	The available units depend on the balance model.
Temperature	Defines the temperature of the solid.	Numeric (10°C30.9°C)
Aux. liquid	Defines the type of auxiliary liquid used for the determination of the density of a solid.	Distilled water* I Custom

Aux. liquid name	Defines the name of the custom liquid.	Text (032 character)
	This option only appears when Aux. liquid is set to Custom.	
Aux. liquid	Defines the liquid density of the custom liquid.	Numeric I 1.00000 g/
density	This option only appears when Aux. liquid is set to Custom.	cm3* (0.00001100 g/cm3)

^{*} Factory setting

Initial values for weighing (Determination Type: Sinker)

Parameter	Description	Values
Unit	Defines the unit.	The available units depend on the balance model.
Temperature	Defines the temperature of the auxiliary liquid (distilled water or custom).	Numeric (10°C30.9°C)
Sinker volume	Defines the volume of the sinker in cm ³ .	Numeric (0.0001500 cm3)

Initial values for weighing (Determination Type: Pycnometer)

Parameter	Description	Values
Unit	Defines the unit.	The available units depend on the balance model.
Temperature	Defines the temperature of the auxiliary liquid (distilled water or custom).	Numeric (10°C30.9°C)
Pycnometer volume	Defines volume of the pycnometer in cm ³ .	Numeric (0.000110000 cm3)
Pycnometer weight	Defines the weight of the pycnometer.	Numeric (0.00001222.009 g)

See also

Creating a method "Density determination" ▶ Page 51

6.2.6.5 Weighing

Parameter	Description	Values
Show info weight	With this option activated a secondary info weight appears on the weighing screen on top of the weighing result.	Active I Inactive*
Info unit	Defines the unit of the info weight.	The available units
	This option only appears when the option Show info weight is activated.	depend on the balance model.

^{*} Factory setting

Weighing settings

Parameter	Description	Values
	needed for a certain weighing method. It is possible to create	Available tolerance profiles are model-
	different tolerance profiles for different weighing methods.	specific.

Weight capture mode	Defines the behavior when the button to add the result was tapped or the add result was triggered by the automatic weighing result creation.	Stable* I Immediate
	Stable: The system waits for a stable weight.	
	Immediate: The system doesn't wait for a stable weight. The system waits for the defined amount of seconds (Weight capture delay). After the weight capture delay, the weight value from the weight stream is captured.	
Weight capture delay	Defines the time in seconds the balance waits for capturing the weight after the button to add the result was tapped or the add result was triggered by the automatic weighing result creation.	Numeric (5 seconds* I 060 seconds)
	This option only appears when the Weight capture mode is set to Immediate .	

^{*} Factory setting

Statistics

Parameter	Description	Values
Activate statistics	If Activate statistics is set to Active , the following statistics will be calculated:	Active I Inactive*
	Count: Number of items used for the statistics	
	Sum: Sum of all value (decimal places and unit according to the method settings)	
	Minimum: Smallest value (decimal places and unit according to the method settings)	
	Maximum: Largest value (decimal places and unit according to the method setting)	
	Range: Difference between the largest and smallest values (decimal places and unit according to the method settings)	
	Average: The values are summed up and divided by the number of values, rounded to 1 digit more than the configured decimal places in the method settings (unit according to the method settings)	
	Standard deviation: Standard deviation rounded to 1 digit more than the configured decimal places in the method settings (unit according to the method settings)	
	Relative standard deviation: Relative standard deviation (rounded to 2 decimal places, in %)	
	The statistical values are calculated and displayed as soon as a result is added or updated.	

^{*} Factory setting

See also

Creating a method "Density determination" ▶ Page 51

6.2.6.6 Automation

Parameter	Description	Values
Barcode data target	If a barcode reader is connected to the balance, this option defines how the data is to be processed.	Keyboard Input* Task ID 1 Result ID 1
	Keyboard Input : The data is written in the currently open input window. If no input window is open, the data is ignored.	
	Task ID 1 : The received barcode data is treated as identification text for this task ID.	
	Result ID 1 : The received barcode data is treated as identification text for this result ID.	
	The available items in the drop-down menu depend on the Number of task IDs and Number of result IDs specified for the method.	
	Make sure that the characters of the scanned barcode are compatible with the format of the field where they should be inserted.	

^{*} Factory setting

See also

Creating a method "Density determination" ▶ Page 51

6.2.6.7 Print / Export

Protocol printout and data export

Automatic data output

Parameter	Description	Values
Strip printer	Activates/Deactivates automatic printing of the protocol on a strip printer when the Complete button is tapped. The data to be transmitted to the printer can be defined in the section Template	Active I Inactive*
	settings.	

^{*} Factory setting

Protocol template for printout

This menu item can be used to define information to appear in the **Protocol**. The extensive menu is divided into six submenus in which options for the printout can be defined. Information can be enabled or disabled by activating or deactivating the corresponding checkbox.

Each individual parameter can set to **Inactive** or **Active** via the corresponding check box. To enable or disable all parameters at once, proceed as follows:

- 1 To deselect all check boxes at once, tap To Deselect all
 - ⇒ All parameters are set to **Inactive**.
- 2 To select all check boxes at once, tap To Select all
 - ⇒ All parameters are set to **Active**.

Template settings

Parameter	Description	Values
Header and Footer	Defines the header (with title, date and time) and/or footer (with signature and end line) to be printed/exported.	Header* Title* Date/ time Signature* Separating lines* Group titles

Balance infor- mation	Defines which information about the balance is being printed/exported.	Balance type I Balance ID* I Balance serial number I Software version
Quality infor- mation	Defines which quality information is being printed/exported.	Tolerance profile I Adjustment date/time I Routine test name I Routine test last execution date I Routine test result I GWP Approved state I Level state I MinWeigh state
Task information	Defines which information about the task is being printed/export.	Method name I Method comment I Task IDs I Count I Average I Minimum I MaximumI Standard deviation I Relative standard deviation I Type of density determination I Decimal places for density weighing results I Include air density compensation in calculation of density
Weighing item information	Defines which information about the weighing items is being printed/exported.	Show excluded weighing items I Result State I Result IDs I GWP Approved state I Level state I MinWeigh state I Temperature I Auxiliary liquid name and density I Volume of sample I Weight of sample in air I Weight of sample in liquid
Result detail information	Defines which information related to the result of the measurement is being printed/exported.	Weight* I Tare weight I Gross weight I Info weight I Date/time* I Stability

^{*} Factory setting

6.3 Tests settings

6.3.1 Settings: eccentricity test

1. Name and type

Parameter	Description	Values
Test type	The test type has been pre-defined and cannot be changed in this menu.	Available test types
Name	Defines the name of the test.	Text (122 characters)
Test activated	Enables/disables the test.	Active* Inactive
Show preparation instructions	If activated, a predefined preparatory instruction is displayed in the test sequence.	Active* Inactive
Automatic print	When activated test results are immediately printed after the test result has been calculated on the enabled printer.	Active I Inactive*

^{*} Factory setting

2. Test specification

Parameter	Description	Values
Result calculation	Select whether the nominal weight or the conventional mass value (CMV) is used for the result calculation.	On nominal weight* I On actual weight (CMV)
	On nominal weight : Nominal value of a weight with a specific weight class.	
	On actual weight (CMV) : Conventional mass value (CMV) of a weight from the weight calibration certificate.	

^{*} Factory setting

Test point

Parameter	Description	Values
Nominal weight	Defines the value for the nominal weight. The nominal weight is defined as the expected weight of the measured object.	Numeric
Weight class	Defines the weight class according to OIML or ASTM. Alternatively, a customized tolerance class can be created with Own .	E1 E2 F1 F2 M1 M2 M3 ASTM000 ASTM00 ASTM0 ASTM0 ASTM1 ASTM2 ASTM3 ASTM4 ASTM5 ASTM6 ASTM7 Own*

^{*} Factory setting

Eccentricity limits

Parameter	Description	Values
Control limit	Defines the control limit. The control limit is the error tolerance of a process with respect to	Numeric 0.2 %* (0.001 100%)
	its set value. Exceeding the control limit is a violation of quality requirements and therefore requires a correction of the process.	
	Result if the control limit is exceeded: The test failed, the balance is out of specification.	

Warning limit	Defines the warning limit.	Numeric I (0.001
	The warning limit is an upper or lower limit, which if exceeded or not reached, makes more stringent process monitoring necessary. The warning limit has to be smaller than the control limit.	100%)
	Result if the warning limit is exceeded: The test is passed, but the difference is higher than expected.	

^{*} Factory setting

3. Test weights

4. Error management

Parameter	Description	Values
Block balance	Defines the behavior of the balance if a test has failed.	Active I Inactive*
	Active : The balance will be blocked after a specified amount of failed tests. In this case, the balance cannot be used anymore until a user with the appropriate right unblocks the balance.	
	Inactive: Blocking is not activated.	
Allowed number of retries	Defines the maximum allowed retries until the balance will be blocked.	Numeric (3* I 09)

^{*} Factory setting

5. Test planning

Parameter	Description	Values
Planning type	Specifies the schedule for the test to be performed.	Manually* Daily
	Manually: The test must be performed manually.	Weekly Monthly
	Daily : The test will be performed automatically every day at the specified time.	Quarterly I Annually
	Weekly : The test is performed automatically at least once a week. Additional days can be selected if required.	
	Monthly : The test will be performed automatically every month at the specified day and time.	
	Quarterly : The test will be performed automatically every three months at the specified time.	
	Annually : The test will be performed automatically once a year at the specified time.	
Start time	Defines the start time for executing the task.	Time

^{*} Factory setting

Notification

This section does not appear when the option **Planning type** is set to **Manually**.

Parameter	Description	Values
(x) hours before test	Defines the time period before the notification informs about the upcoming expiry date.	Different values depending on the selected frequency (Planning type).
Notification every (x) hours	Defines the time interval before the next notification is issued.	Different values depending on the selected frequency (Planning type).

Preferred days

This option only appears when the option Planning type is set to Weekly.

Parameter	Description	Values
Preferred days	Defines the preferred weekday for the execution of the test.	Monday I Tuesday I Wednesday I Thursday I Friday I Saturday I Sunday

Preferred day for execution

This section only appears when the option Planning type is set to Monthly.

Parameter	Description	Values
Preferred day for execution	Defines the preferred day for execution of the test.	None* Monday Tuesday Wednesday Thursday Friday Saturday Sunday
Occurrence of day	Defines the occurrence of a given day of week within a month.	First* Second Third Fourth

^{*} Factory setting

See also

- Creating an own new test ▶ Page 55
- Defining a test weight ▶ Page 56

6.3.2 Settings: repeatability test

When parameter settings are different for the four repeatability tests you will be informed by a Note.

Parameter	Description	Values
Test type	The test type has been pre-defined and cannot be changed in this menu.	Available test types
Name	Defines the name of the test.	Text (122 characters)
Test activated	Enables/disables the test.	Active* Inactive
Show preparation instructions	If activated, a predefined preparatory instruction is displayed in the test sequence.	Active* I Inactive
Automatic print	When activated test results are immediately printed after the test result has been calculated on the enabled printer.	Active I Inactive*

^{*} Factory setting

2. Test specification

Parameter	Description	Values
Result calculation	Select whether the nominal weight or the conventional mass value (CMV) is used for the result calculation.	On nominal weight* I On actual weight (CMV)
	On nominal weight : Nominal value of a weight with a specific weight class.	
	On actual weight (CMV) : Conventional mass value (CMV) of a weight from the weight calibration certificate.	
Number of repetitions	Defines the number of weight measurements of a series.	Numeric 10* I (215)

^{*} Factory setting

Tare

This section only appears when the option Test type is set to Repeatab. - Tare - 1 TP.

Parameter	Description	Values
Tare name	Defines a name for the tare weight.	Text (122 characters)
Minimum tare weight	Defines the minimum weight for the tare container. The test is only continued if a tare container with at least this weight is placed on the balance.	Numeric

^{*} Factory setting

Test point

Parameter	Description	Values
Nominal weight	Defines the value for the nominal weight. The nominal weight is defined as the expected weight of the measured object.	Numeric
Weight class	Defines the weight class according to OIML or ASTM. Alternatively, a customized tolerance class can be created with Own .	E1 E2 F1 F2 M1 M2 M3 ASTM000 ASTM0 ASTM0 ASTM0 ASTM2 ASTM2 ASTM3 ASTM4 ASTM5 ASTM6 ASTM7 Own*

^{*} Factory setting

Test limits

Parameter	Description	Values
Control limit	Defines the control limit. The control limit is the error tolerance of a process with respect to its set value. Exceeding the control limit is a violation of quality	Numeric I 0.2 %* (0.001 100%)
	requirements and therefore requires a correction of the process.	
	Result if the control limit is exceeded: The test failed, the balance is out of specification.	
Warning limit	Defines the warning limit.	Numeric I (0.001 100%)
	The warning limit is an upper or lower limit, which if exceeded or not reached, makes more stringent process monitoring necessary. The warning limit has to be smaller than the control limit.	
	Result if the warning limit is exceeded: The test is passed, but the difference is higher than expected.	

^{*} Factory setting

3. Test weights

4. Error management

Parameter	Description	Values
Block balance	Defines the behavior of the balance if a test has failed.	Active I Inactive*
	Active : The balance will be blocked after a specified amount of failed tests. In this case, the balance cannot be used anymore until a user with the appropriate right unblocks the balance.	
	Inactive: Blocking is not activated.	
Allowed number of retries	Defines the maximum allowed retries until the balance will be blocked.	Numeric (3* I 09)

^{*} Factory setting

5. Test planning

Parameter	Description	Values
Planning type	Specifies the schedule for the test to be performed.	Manually* I Daily I Weekly I Monthly I Quarterly I Annually
	Manually: The test must be performed manually.	
	Daily : The test will be performed automatically every day at the specified time.	
	Weekly : The test is performed automatically at least once a week. Additional days can be selected if required.	
	Monthly : The test will be performed automatically every month at the specified day and time.	
	Quarterly : The test will be performed automatically every three months at the specified time.	
	Annually : The test will be performed automatically once a year at the specified time.	
Start time	Defines the start time for executing the task.	Time

^{*} Factory setting

Notification

This section does not appear when the option Planning type is set to Manually.

Parameter	Description	Values
(x) hours before test	Defines the time period before the notification informs about the upcoming expiry date.	Different values depending on the selected frequency (Planning type).
Notification every (x) hours	Defines the time interval before the next notification is issued.	Different values depending on the selected frequency (Planning type).

^{*} Factory setting

Preferred day for execution

This option only appears when the option Planning type is set to Weekly.

Parameter	Description	Values
Preferred day for execution	Defines the preferred day for execution of the test.	None* Monday Tuesday Wednesday
		Thursday Friday Saturday Sunday

Preferred days

This section only appears when the option Planning type is set to Monthly.

Parameter	Description	Values
Preferred day for execution	Defines the preferred day for execution of the test.	None* Monday Tuesday Wednesday Thursday Friday Safurday Sunday
Occurrence of day	Defines the occurrence of a given day of week within a month.	First* I Second I Third I Fourth

^{*} Factory setting

See also

- Creating an own new test ▶ Page 55
- Defining a test weight ▶ Page 56

6.3.3 Settings: sensitivity test

When parameter settings are different for the four sensitivity tests you will be informed by a Note.

1. Name and Type

Parameter	Description	Values
Test type	The test type has been pre-defined and cannot be changed in this menu.	Available test types
Name	Defines the name of the test.	Text (122 characters)
Test activated	Enables/disables the test.	Active* Inactive
Show preparation instructions	If activated, a predefined preparatory instruction is displayed in the test sequence.	Active* I Inactive
Automatic print	When activated test results are immediately printed after the test result has been calculated on the enabled printer.	Active I Inactive*

^{*} Factory setting

2. Test specification

Parameter	Description	Values
Result calculation	Select whether the nominal weight or the conventional mass value (CMV) is used for the result calculation.	On nominal weight* I On actual weight (CMV)
	On nominal weight : Nominal value of a weight with a specific weight class.	
	On actual weight (CMV) : Conventional mass value (CMV) of a weight from the weight calibration certificate.	

^{*} Factory setting

Tare



This section only appears when the option **Test type** is set to **Sensitivity - Tare - 1 TP** or **Sensitivity - Tare - 2 TP**.

Parameter	Description	Values
Tare name	Defines a name for the tare weight.	Text (122 characters)
Minimum tare weight	Defines the minimum weight for the tare container. The test is only continued if a tare container with at least this weight is placed on the balance.	Numeric

Test point

Depending on the selected test, the following options can be defined for one or two test points:

Parameter	Description	Values
	Defines the value for the nominal weight. The nominal weight is defined as the expected weight of the measured object.	Numeric

Weight class	Defines the weight class according to OIML or ASTM. Alternatively, a customized tolerance class can be created with Own .	E1 E2 F1 F2 M1 M2 M3 ASTM000 ASTM0 ASTM0 ASTM0 ASTM0 ASTM2 ASTM3 ASTM4 ASTM5 ASTM6 ASTM7 Own*
Control limit	Defines the control limit. The control limit is the error tolerance of a process with respect to its set value. Exceeding the control limit is a violation of quality requirements and therefore requires a correction of the process. Result if the control limit is exceeded: The test failed, the balance is out of specification.	Numeric I 0.2 %* (0.001 100%)
Warning limit	Defines the warning limit. The warning limit is an upper or lower limit, which if exceeded or not reached, makes more stringent process monitoring necessary. The warning limit has to be smaller than the control limit. Result if the warning limit is exceeded: The test is passed, but the difference is higher than expected.	Numeric I (0.001 100%)

^{*} Factory setting

3. Test weights

4. Error management

Parameter	Description	Values
Block balance	Defines the behavior of the balance if a test has failed.	Active Inactive*
	Active : The balance will be blocked after a specified amount of failed tests. In this case, the balance cannot be used anymore until a user with the appropriate right unblocks the balance.	
	Inactive: Blocking is not activated.	
Allowed number of retries	Defines the maximum allowed retries until the balance will be blocked.	Numeric (3* I 09)

5. Test planning

^{*} Factory setting

Parameter	Description	Values
Planning type	Specifies the schedule for the test to be performed.	Manually* Daily
	Manually: The test must be performed manually.	Weekly I Monthly I
	Daily : The test will be performed automatically every day at the specified time.	Quarterly I Annually
	Weekly : The test is performed automatically at least once a week. Additional days can be selected if required.	
	Monthly : The test will be performed automatically every month at the specified day and time.	
	Quarterly : The test will be performed automatically every three months at the specified time.	
	Annually : The test will be performed automatically once a year at the specified time.	
Start time	Defines the start time for executing the task.	Time

^{*} Factory setting

Notification

This section does not appear when the option **Planning type** is set to **Manually**.

Parameter	Description	Values
(x) hours before test	Defines the time period before the notification informs about the upcoming expiry date.	Different values depending on the selected frequency (Planning type).
Notification every (x) hours	Defines the time interval before the next notification is issued.	Different values depending on the selected frequency (Planning type).

Preferred days

This option only appears when the option Planning type is set to Weekly.

Parameter	Description	Values
Preferred days	Defines the preferred weekday for the execution of the test.	Monday I Tuesday I Wednesday I Thursday I Friday I Saturday I Sunday

Preferred day for execution

This section only appears when the option Planning type is set to Monthly.

Parameter	Description	Values
Preferred day for execution	Defines the preferred day for execution of the test.	None* Monday Tuesday Wednesday Thursday Friday Safurday Sunday
Occurrence of day	Defines the occurrence of a given day of week within a month.	First* I Second I Third I Fourth

^{*} Factory setting

See also

- Creating an own new test ▶ Page 55
- Defining a test weight ▶ Page 56

6.4 Adjustments settings

1. Strategy

Parameter	Description	Values
Strategy	Defines the adjustment method.	Internal adjustment* I
	When the options No adjustment or External adjustment are activated other options are not available.	External adjustment I No adjustment
Automatic print	When activated adjustment results are immediately printed after the result has been calculated on the enabled strip printer.	Active I Inactive*

^{*} Factory setting

2. Specification

Parameter	Description	Values
'As found' test	At the start of the adjustment sequence, an internal test (sensitivity) is performed to ascertain the current status. The input test has automatically started when the adjustment sequence is activated and the result is displayed and recorded.	Active I Inactive*

'As left' test	When the adjustment is complete, an internal test (sensitivity) is	Active I Inactive*
	performed.	



This settings only appear when one of the options 'As found' test or 'As left' test is activated.

Parameter	Description	Values
Control limit	Defines the control limit.	Numeric I 0.1 %*
	The control limit is the error tolerance of a process with respect to its set value. Exceeding the control limit is a violation of quality requirements and therefore requires a correction of the process.	(0.001 100%)
	Result if the control limit is exceeded: The adjustment failed, the balance is out of specification.	
Warning limit	Defines the warning limit.	Numeric
	The warning limit is an upper or lower limit, which if exceeded or not reached, makes more stringent process monitoring necessary. The warning limit has to be smaller than the control limit.	(0.001100%)
	Result if the warning limit is exceeded: The adjustment is passed, but the difference is higher than expected.	

^{*} Factory setting

3. Error management

Parameter	Description	Values
Block balance	Defines the behavior of the balance if the adjustment has failed.	Active I Inactive*
	Active : The balance will be blocked after the adjustment has failed. In this case, the balance can not be used anymore until a user with the appropriate right unblocks the balance.	
	Inactive: The balance will not be blocked.	

^{*} Factory setting

4. Planning

Parameter	Description	Values
Start after leveling	Defines if the internal adjustment starts after leveling.	Active Inactive*
Start after temperature change	Defines if the internal adjustment starts automatically after a temperature change of 1°C.	Active I Inactive*
Schedule	Defines when the adjustment is being performed. It is possible to define several start times (1-3) per day. It can also be defined on what day/s the adjustment is being performed.	Inactive 1 start time 2 start times* 3 start times
Start time 1	Defines the start time for execution of the task.	Time
Start time 2	Defines the start time for second execution of the task	Time
Preferred days	Defines the days for the scheduled adjustments. This section only appears with a defined start time.	Monday I Tuesday I Wednesday I Thursday I Friday I Saturday I Sunday

^{*} Factory setting

See also

- Defining a test weight ▶ Page 56
- Editing an internal adjustment ▶ Page 62
- Editing an external adjustment ▶ Page 62

7 Maintenance

To guarantee the functionality of the balance and the accuracy of the weighing results, a number of maintenance actions must be performed by the user.

7.1 Maintenance tasks

Maintenance action	Recommended interval	Remarks
Performing an internal adjustment	 Daily After cleaning After leveling After changing the location 	see "Adjustments"
Performing routine tests (eccentricity test, repeatability test, sensitivity test). METTLER TOLEDO recommends to at least perform a sensitivity test.	 After cleaning After assembling the balance After a software update Depending on your internal regulations (SOP) 	see "Tests"
Cleaning	 After every use After changing the substance Depending on the degree of pollution Depending on your internal regulations (SOP) 	see "Cleaning"
Updating the software	 Depending on your internal regulations (SOP). After a new software release. 	see "Software update"

See also

- Adjustments ▶ Page 61
- Tests ▶ Page 54
- Cleaning ▶ Page 140
- Software update ▶ Page 143

7.2 Cleaning

7.2.1 Disassembling the Pro draft shield for cleaning





A CAUTION

Injury due to sharp objects or broken glass


Instrument components, e.g., glass, can break and lead to injuries.

- Always proceed with focus and care.





- 1 Remove the weighing pan and/or SmartPan weighing pan.
- 2 Lift the Pro draft shield off the weighing platform and place it on a clean surface.
- 3 Remove the DripTray.
- 4 Turn the cover (1) to the front.
- 5 Pull the top glass back and out of the housing.
- 6 Pull the side glasses back out of the housing.
- ⇒ The Pro draft shield is ready for cleaning.



7.2.2 Cleaning agents

In the following table, cleaning tool and cleaning agents recommended by METTLER TOLEDO are listed. Pay attention to the concentration of the agents specified in the table.

			Tools		Cleaning agents							
		Paper fissue	Brush	Dishwasher	Water	Acetone	Ethanol (70%)	Isopropanol (70%)	Hydrochloric acid (3-10%)	Sodium hydroxide (0.2-1.0 M)	Peracetic acid (2-3%)	
Around the balance	Balance housing	1	R	_	R	_	R	1	R	R	R	
	Feet	1	R	_	R	_	R	✓	R	R	R	
Balance terminal	Terminal	1	R	_	√	PR	R	R	R	R	R	
	Display	1	_	_	✓	PR	R	R	R	R	R	
	Terminal cover	✓	R	_	√	_	R	R	R	PR	PR	

		Paper tissue	Brush	Dishwasher	Water	Acetone	Ethanol (70%)	Isopropanol (70%)	Hydrochloric acid (3-10%)	Sodium hydroxide (0.2-1.0 M)	Peracetic acid (2-3%)
Balance draft shield	Glass panels	✓	R	R	R	PR	1	1	R	R	R
	Glass-free panels	1	R	_	R	_	✓	√	R	R	R
	Non- removable handles and frames	✓	R	_	R	PR	√	√	R	R	R
Weighing area	Weighing pan	R	R	1	R	R	1	1	R	R	R
	Drip tray	R	R	1	R	R	1	1	_	_	R

Legend

- ✓ Best recommendation by METTLER TOLEDO; can be used without limitation.
- R Recommended by METTLER TOLEDO; can be used without limitation.
- PR Partially recommended by METTLER TOLEDO: individual resistance to acid and alkali must be evaluated, including dependence to the time exposure.
- Not recommend. High risk for damage.

7.2.3 Cleaning the balance



MARNING

Death or serious injury due to electric shock

Contact with parts carrying a live current can lead to injury and death.

- 1 Disconnect the instrument from the power supply prior to cleaning and maintenance.
- 2 Prevent liquid from entering the instrument, terminal or AC/DC adapter.



NOTICE

Damage due to improper cleaning

Improper cleaning can damage the load cell or other essential parts.

- 1 Do not use any cleaning agents other than the ones specified in the "Reference Manual" or "Cleaning Guide".
- 2 Do not spray or pour liquids on the instrument. Always use a moistened lint-free cloth or a tissue.
- 3 Always wipe out from inside to outside of the instrument.

Cleaning around the balance

Remove any dirt or dust around the balance and avoid further contaminations.

Cleaning the terminal

Clean the terminal with a damp cloth or a tissue and a mild cleaning agent.

Cleaning the removable parts

 Clean the removed part with a damp cloth or a tissue and a mild cleaning agent or clean in a dishwasher up to 80 °C.

Cleaning the weighing unit

- 1 Disconnect the balance from the AC/DC adapter.
- 2 Use a lint-free cloth moistened with a mild cleaning agent to clean the surface of the balance.
- 3 Remove powder or dust with a disposable tissue first.
- 4 Remove sticky substances with a damp lint-free cloth and a mild solvent, e.g., isopropanol or ethanol 70%.



Useful details to avoid soiling the instrument are described in the Mettler-Toledo GmbH "SOP for Cleaning a Balance".

7.2.4 Putting into operation after cleaning

- 1 Reassemble the balance.
- 2 Check that the draft shield doors (top, sides) open and close normally.
- 3 Check if the terminal is connected to the balance.
- 4 Reconnect the balance to the AC/DC adapter.
- 5 Check the level status, level the balance if necessary.
- 6 Respect the warm-up time specified in the "Technical Data".
- 7 Perform an internal adjustment.
- 8 Perform a routine test according to the internal regulations of your company. METTLER TOLEDO recommends to perform a sensitivity test after cleaning the balance.
- 9 Press \rightarrow **0** \leftarrow to zero the balance.
- ⇒ The balance is ready to be used.

See also

- Leveling the balance ▶ Page 36
- Performing an internal adjustment ▶ Page 37
- Performing a sensitivity test ▶ Page 59
- Technical Data ▶ Page 148

7.3 Software update

Search for software downloads

www.mt.com/labweighing-software-download

Please contact a METTLER TOLEDO service representative if you need support updating the software. METTLER TOLEDO recommends saving the data on a storage device before updating the software.

Navigation: ▶ Balance menu > 🖹 Maintenance > # Software update

See also

Exporting data and settings ▶ Page 67

7.3.1 Updating the software

- A USB storage device containing the software installer (zip file format) is connected to the balance.
- 1 Tap → Balance menu > 🖹 Maintenance > ## Software update
- 2 Select **Update software** and tap →Next.
 - ⇒ An update wizard opens and will lead you step-by-step through the procedure.

7.3.2 Restoring the software to the previous version

The current software version can be rolled back to the previous software version.

1 Tap → Balance menu > \(\frac{1}{2} \) Maintenance > \(\frac{1}{2} \) Software update

2 Select Restore the software to the previous version. and tap → Next

⇒ An update wizard opens and will lead you step-by-step through the procedure.

7.3.3 Putting into operation after software update

- 1 Press **(**) to switch on the balance.
- 2 Check the level status, level the balance if necessary.
- 3 Perform an internal adjustment.
- 4 Perform a routine test according to the internal regulations of your company.
- 5 Press \rightarrow **0** \leftarrow to zero the balance.
- ⇒ The balance is ready to be used.

See also

- Leveling the balance ▶ Page 36
- Performing an internal adjustment ▶ Page 37

8 Troubleshooting

Possible errors with their cause and remedy are described in the following chapter. If there are errors that cannot be corrected through these instructions, contact METTLER TOLEDO.

8.1 Error messages

Error message	Possible cause	Diagnostic	Remedy
Balance reset failed	Communication failure	_	Disconnect the power cable and reconnect after a few seconds.
The system has no valid date and time set	Low battery	_	Connect to the power outlet and let the battery charge for two to three days.
Weight cannot be determined	Data signal problems of electronics.	_	Disconnect the power cable and reconnect after a few seconds.
	Bad connection between the terminal and the weighing unit.	Check the cable for damage (kinked, twisted or broken pins).	Replace the terminal cable.
Cannot start adjustment	Initial zero was not reached when the balance was switched on.	_	Disconnect the power cable and reconnect after a few seconds.
Preventive performance optimization	The balance memory (RAM) is too ful.	_	Complete the current task. Disconnect the power cable and reconnect after a few seconds.

8.2 Error symptoms

Error symptom	Possible cause	Diagnostic	Remedy
The display is dark.	The instrument is on standby.	_	Switch on the instrument.
	There is no power	Check the connection to the AC/DC adapter and the power outlet.	Connect the weighing unit to the power outlet. See "Connecting the balance"
	The terminal is not connected to the instrument.	Check the terminal cable connection.	Connect the terminal cable to the instrument.
	The terminal cable is defective.	Check the cable for damage (kinked, twisted or broken pins).	Replace the terminal cable.
	The wrong AC/DC adapter is connected to the instrument.	Check it, see "Technical Data".	Use the correct AC/DC adapter.
	The AC/DC adapter is defective.	The LED on the AC/DC adapter does not turn on.	Replace the AC/DC adapter.
The value on the display oscillates.	Vibrations on the weighing bench, e.g., building vibrations, foot traffic	Place a beaker with water on the weighing bench. Vibrations cause ripples on the water surface.	Protect the weighing location against vibrations, e.g. with an absorber.
			Find a different weighing location.

Error symptom	Possible cause	Diagnostic	Remedy
The value on the display oscillates.	Draff due to untight draft shield and/or open window.	Check the draft shield for gaps.	Fix the draft shield. Close the window.
	The weighing sample is electrostatically charged.	Check if the weighing result is stable when using	Increase the air humidity in the weighing chamber.
		a test weight.	Use an ionizer. See "Accessories".
	The location is not suitable for weighing.	_	Follow the requirements for the location. See "Selecting the location".
	Something is touching the weighing pan.	Check for touching parts or dirt.	Remove touching parts. Clean the balance.
The value on the display is drifting towards plus or minus.	The weighing sample absorbs moisture or evaporates moisture.	Check if the weighing result is stable when using a test weight.	Cover the weighing sample.
	The weighing sample is electrostatically charged.	Check if the weighing result is stable when using	Increase the air humidity in the weighing chamber.
		a test weight.	Use an ionizer. See "Accessories".
	The weighing sample is warmer or colder than the air in the weighing chamber.	Check if the weighing result is stable when using an acclimatized test weight.	Bring the sample to room temperature.
	The balance has not yet warmed up.		Let the balance warm up. Adequate warm up time is specified in the "General data".
The display shows overload or underload.	The wrong weighing pan is installed.	Slightly lift or press the weighing pan to see if the weight appears on the display.	Install the proper weighing pan.
	No weighing pan is installed.	_	Install the proper weighing pan.
	Incorrect zero point at power on.	_	Disconnect the power cable and reconnect after a few seconds.
	The balance is not adjusted.	_	Perform a internal adjustment. See "Internal adjustment".
The draft shield front panel is not exactly 90° from the weighing platform	The draft shield front panel is not perfectly adjusted.	_	Contact METTLER TOLEDO representative to adjust the front panel.
The draft shield side doors are not exactly closed.	The draft shield side doors are not perfectly adjusted.	_	Contact METTLER TOLEDO representative to adjust the side doors.
The user interface responds slowly.	Too many results are included in the Protocol of a task.	Check the Protocol of every running and pending task.	Complete all tasks: For each task in the list of Tasks , select the task, tap Continue task , and tap Complete .

8.3 Putting into operation after fixing an error

After fixing an error, perform the following steps to put the balance into operation:

- Ensure that the balance is completely reassembled and cleaned.
- Reconnect the balance to the AC/DC adapter.

9 Technical Data

9.1 General data

Power supply

AC/DC adapter: Primary: 100 – 240 V~, 50/60 Hz

Secondary: 12 V DC, 5 A, LPS, SELV

Cable for AC/DC adapter: 3-core, with country-specific plug

Balance power consumption: $12 \text{ V DC} \pm 10\%$, 2.25 A

Protection and standards

Overvoltage category: II
Degree of pollution: 2

Standards for safety and EMC: See Declaration of Conformity

Range of application: Use only indoors in dry locations

Environmental conditions

The limit values apply when the balance is used under the following environmental conditions:

Height above mean sea level: Up to 5000 m Ambient temperature: +10 - +30 °C

Temperature change, max.: 5 °C/h

Relative air humidity: 30 – 70%, non-condensing

Warm-up time: At least 30 minutes after connecting the balance to the power

supply. When switched on from standby, the instrument is ready

for operation immediately.

The balance can be used under the following environmental conditions. However, the weighing performances of

the balance may be outside the limit values:

Ambient temperature: $+5 - +40 \,^{\circ}\text{C}$

Relative air humidity: 20% to max. 80% at 31 °C, decreasing linearly to 50% at

40 °C, non-condensing

The balance can be disconnected and stored in its packaging under the following conditions:

Ambient temperature: $-25 - +70 \, ^{\circ}\text{C}$

Relative air humidity: 10 - 90%, non-condensing

Environmental conditions for comparators

Comparators need to be used under the following environmental conditions to reach the specified perfor-

mances:

Warm-up time: At least **60 minutes** after connecting the balance to the power

supply. When switched on from standby, the instrument is ready

for operation immediately.

Air speed, max.: 0.15 m/s


9.2 Explanatory notes for the METTLER TOLEDO AC/DC adapter

The certified external AC/DC adapter complies to the requirements for Class II double insulated equipment. It is not provided with a protective earth connection but with a functional earth connection for EMC purposes. This earth connection **is not** a safety feature. Further information about the compliance of our products can be found in the "Declaration of Conformity" delivered with every product.

In case of testing with regard to the European Directive 2001/95/EC, the AC/DC adapter and the instrument have to be handled as Class II double insulated equipment.

Consequently, a grounding test is not required. It is not necessary to carry out a grounding test between the earth connector of the power plug and any exposed part of the metallic housing of the instrument.

Because the instrument is sensitive to static charges, a leakage resistor of 10 k Ω is connected between the earth connector (1) and the negative pole (2) of the AC/DC adapter. The arrangement is shown in the equivalent circuit diagram. This resistor is not part of the electrical safety arrangement and does not require testing at regular intervals.



9.3 Model-specific data

9.3.1 Balances with S weighing platform

9.3.1.1 Readability 0.1 mg, with Pro draft shield

	XPR204S	XPR404S
Limit values		
Capacity	210 g	410 g
Nominal load	200 g	400 g
Readability	0.1 mg	0.1 mg
Capacity of fine range	-	-
Readability in fine range	-	-
Repeatability	0.2 mg	0.1 mg
Repeatability in fine range	-	-
Linearity deviation	0.2 mg	0.2 mg
Eccentricity deviation (at test load)	0.3 mg (100 g)	0.3 mg (200 g)
Sensitivity offset (at nominal load) 1)	0.6 mg	2 mg
Sensitivity temperature drift	0.0001%/°C	0.00015%/°C
Typical values		
Repeatability	0.12 mg	0.06 mg
Repeatability in fine range	_	-
Linearity deviation	0.06 mg	0.06 mg
Eccentricity deviation (at test load)	0.1 mg (100 g)	0.1 mg (200 g)
Sensitivity offset (at nominal load) 1)	0.4 mg	0.48 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	240 mg	120 mg
Minimum weight (tolerance = 1%)	24 mg	12 mg
Settling time	2 s	2 s
Dimensions & other specifications		
Balance dimensions (W×D×H)	214×411×368 mm	214×411×368 mm
Weighing pan dimensions (W×D)	68×68 mm	68×68 mm
Usable height of draft shield	245 mm	245 mm
Balance weight	7.8 kg	7.8 kg
Weights for routine testing		
Weights (OIML class)	10 g (F2)/ 200 g (F2)	20 g (F2)/ 200 g (F2)
Weights (ASTM class)	10 g (ASTM 1)/ 200 g (ASTM 1)	20 g (ASTM 1)/ 200 g (ASTM 1)

after adjustment with internal weight

determined at 5% load, k = 2

	XPR504S	XPR504SDR	
Limit values			
Capacity	510 g	510 g	
Nominal load	500 g	500 g	
Readability	0.1 mg	1 mg	
Capacity of fine range	-	101 g	
Readability in fine range	-	0.1 mg	
Repeatability	0.1 mg	0.5 mg	
Repeatability in fine range	-	0.1 mg	
Linearity deviation	0.3 mg	0.4 mg	
Eccentricity deviation (at test load)	0.4 mg (200 g)	1 mg (200 g)	
Sensitivity offset (at nominal load) 1)	2 mg	2.5 mg	
Sensitivity temperature drift	0.00015%/°C	0.0002%/°C	
Typical values			
Repeatability	0.07 mg	0.4 mg	
Repeatability in fine range	-	0.08 mg	
Linearity deviation	0.2 mg	0.2 mg	
Eccentricity deviation (at test load)	0.1 mg (200 g)	0.8 mg (200 g)	
Sensitivity offset (at nominal load) 1)	0.3 mg	0.3 mg	
Minimum weight (USP, tolerance = 0.10%) ²⁾	140 mg	820 mg	
Minimum weight (tolerance = 1%)	14 mg	82 mg	
Settling time	2 s	1.5 s	
Dimensions & other specifications			
Balance dimensions (W×D×H)	214×411×368 mm	214×411×368 mm	
Weighing pan dimensions (W×D)	68×68 mm	68×68 mm	
Usable height of draft shield	245 mm	245 mm	
Balance weight	7.8 kg	7.8 kg	
Weights for routine testing			
Weights (OIML class)	10 g (F2)/ 200 g (F2)	20 g (F2)/ 200 g (F2)	
Weights (ASTM class)	10 g (ASTM 1)/ 200 g (ASTM 1)	20 g (ASTM 1)/ 200 g (ASTM 1)	

after adjustment with internal weight

determined at 5% load, k = 2

9.3.1.2 Readability 1 mg, with Pro draft shield and SmartPan weighing pan

, ,		• • •	
	XPR303S	XPR603S	XPR603SDR
Limit values	'		'
Capacity	310 g	610 g	610 g
Nominal load	300 g	600 g	600 g
Readability	1 mg	1 mg	10 mg
Capacity of fine range	-	-	120 g
Readability in fine range	-	-	1 mg
Repeatability	0.9 mg	0.9 mg	6 mg
Repeatability in fine range	-	-	1 mg
Linearity deviation	2 mg	2 mg	6 mg
Eccentricity deviation (at test load)	3 mg (100 g)	3 mg (200 g)	5 mg (200 g)
Sensitivity offset (at nominal load) 1)	6 mg	4.5 mg	6 mg
Sensitivity temperature drift	0.0005%/°C	0.0002%/°C	0.0002%/°C
Typical values			
Repeatability	0.5 mg	0.5 mg	4 mg
Repeatability in fine range	-	-	0.8 mg
Linearity deviation	0.6 mg	0.6 mg	1.5 mg
Eccentricity deviation (at test load)	1 mg (100 g)	1 mg (200 g)	1.5 mg (200 g)
Sensitivity offset (at nominal load) 1)	1.2 mg	1.2 mg	6 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	1 g	1 g	8.2 g
Minimum weight (tolerance = 1%)	100 mg	100 mg	820 mg
Settling time	1.5 s	1.5 s	1.5 s
Dimensions & other specifications			
Balance dimensions (W×D×H)	214×411×368 mm	214×411×368 mm	214×411×368 mm
Weighing pan dimensions (W×D)	127×127 mm	127×127 mm	127×127 mm
Usable height of draft shield	245 mm	245 mm	245 mm
Balance weight	8.4 kg	8.4 kg	8.4 kg
Weights for routine testing			
Weights (OIML class)	10 g (F2)/ 200 g (F2)	20 g (F2)/ 500 g (F2)	20 g (F2)/ 500 g (F2)
Weights (ASTM class)	10 g (ASTM 1)/ 200 g (ASTM 1)	20 g (ASTM 1)/ 500 g (ASTM 1)	20 g (ASTM 1)/ 500 g (ASTM 1)

after adjustment with internal weight

determined at 5% load, k = 2

	XPR1203S	XPR3003S	XPR5003S
Limit values			
Capacity	1210 g	3.1 kg	5.1 kg
Nominal load	1200 g	3 kg	5 kg
Readability	1 mg	1 mg	1 mg
Capacity of fine range	-	-	-
Readability in fine range	-	-	-
Repeatability	0.8 mg	1 mg	1.5 mg
Repeatability in fine range	-	-	-
Linearity deviation	2 mg	6 mg	6 mg
Eccentricity deviation (at test load)	3 mg (500 g)	10 mg (1000 g)	10 mg (2 kg)
Sensitivity offset (at nominal load) 1)	6 mg	9 mg	12.5 mg
Sensitivity temperature drift	0.0002%/°C	0.0003%/°C	0.0003%/°C
Typical values		'	'
Repeatability	0.4 mg	0.6 mg	1 mg
Repeatability in fine range	-	-	-
Linearity deviation	0.6 mg	2 mg	2 mg
Eccentricity deviation (at test load)	1 mg (500 g)	3 mg (1000 g)	3 mg (2 kg)
Sensitivity offset (at nominal load) 1)	1.5 mg	1.8 mg	3 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	820 mg	1.2 g	2 g
Minimum weight (tolerance = 1%)	82 mg	120 mg	200 mg
Settling time	1.5 s	2 s	2 s
Dimensions & other specifications			
Balance dimensions (W×D×H)	214×411×368 mm	214×411×368 mm	214×411×368 mm
Weighing pan dimensions (W×D)	127×127 mm	127×127 mm	127×127 mm
Usable height of draft shield	245 mm	245 mm	245 mm
Balance weight	8.4 kg	8.4 kg	8.5 kg
Weights for routine testing			
Weights (OIML class)	50 g (F2)/ 1000 g (F2)	100 g (F2)/ 2000 g (F2)	200 g (F2)/ 5000 g (F2)
Weights (ASTM class)	50 g (ASTM 1)/ 1000 g (ASTM 1)	100 g (ASTM 1)/ 2000 g (ASTM 1)	200 g (ASTM 4)/ 5000 g (ASTM 4)

after adjustment with internal weight

determined at 5% load, k = 2

9.3.1.3 Readability 1 mg, with SmartPan weighing pan

, , , , , , , , , , , , , , , , , , , ,			
	XPR303SN	XPR603SN	XPR603SNDR
Limit values			
Capacity	310 g	610 g	610 g
Nominal load	300 g	600 g	600 g
Readability	1 mg	1 mg	10 mg
Capacity of fine range	-	-	120 g
Readability in fine range	-	-	1 mg
Repeatability	0.9 mg	0.9 mg	6 mg
Repeatability in fine range	-	-	1 mg
Linearity deviation	2 mg	2 mg	6 mg
Eccentricity deviation (at test load)	3 mg (100 g)	3 mg (200 g)	5 mg (200 g)
Sensitivity offset (at nominal load) 1)	6 mg	4.5 mg	6 mg
Sensitivity temperature drift	0.0005%/°C	0.0002%/°C	0.0002%/°C
Typical values			
Repeatability	0.5 mg	0.5 mg	4 mg
Repeatability in fine range	-	-	0.8 mg
Linearity deviation	0.6 mg	0.6 mg	1.5 mg
Eccentricity deviation (at test load)	1 mg (100 g)	1 mg (200 g)	0.8 mg (200 g)
Sensitivity offset (at nominal load) 1)	1.2 mg	1.2 mg	6 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	1 g	1 g	8.2 g
Minimum weight (tolerance = 1%)	100 mg	100 mg	820 mg
Settling time	1.5 s	1.5 s	1.5 s
Dimensions & other specifications			
Balance dimensions (W×D×H)	194×411×102 mm	194×411×102 mm	194×411×102 mm
Weighing pan dimensions (W×D)	129×129 mm	129×129 mm	129×129 mm
Usable height of draft shield	-	-	-
Balance weight	5.7 kg	5.7 kg	5.7 kg
Weights for routine testing			
Weights (OIML class)	10 g (F2)/ 200 g (F2)	20 g (F2)/ 500 g (F2)	20 g (F2)/ 500 g (F2)
Weights (ASTM class)	10 g (ASTM 1)/ 200 g (ASTM 1)	20 g (ASTM 1)/ 500 g (ASTM 1)	20 g (ASTM 1)/ 500 g (ASTM 1)
·		-	

after adjustment with internal weight

determined at 5% load, k = 2

9.3.1.4 Readability 5 mg, with SmartPan weighing pan

	XPR3003SD5	XPR6003SD5
Limit values		
Capacity	3.1 kg	6.1 kg
Nominal load	3 kg	5 kg
Readability	5 mg	5 mg
Capacity of fine range	-	-
Readability in fine range	-	-
Repeatability	6 mg	6 mg
Repeatability in fine range	-	-
Linearity deviation	6 mg	7 mg
Eccentricity deviation (at test load)	20 mg (1000 g)	30 mg (2 kg)
Sensitivity offset (at nominal load) 1)	18 mg	21 mg
Sensitivity temperature drift	0.0003%/°C	0.0003%/°C
Typical values		
Repeatability	3 mg	3 mg
Repeatability in fine range	-	-
Linearity deviation	2 mg	2 mg
Eccentricity deviation (at test load)	5 mg (1000 g)	10 mg (2 kg)
Sensitivity offset (at nominal load) 1)	4 mg	5 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	6 g	6 g
Minimum weight (tolerance = 1%)	600 mg	600 mg
Settling time	2 s	2 s
Dimensions & other specifications		
Balance dimensions (W×D×H)	194×411×102 mm	194×411×102 mm
Weighing pan dimensions (W×D)	172×205 mm	172×205 mm
Usable height of draft shield	-	-
Balance weight	7.6 kg	7.6 kg
Weights for routine testing		
Weights (OIML class)	100 g (F2)/ 2000 g (F2)	200 g (F2)/ 5000 g (F2)
Weights (ASTM class)	100 g (ASTM 1)/ 2000 g (ASTM 1)	200 g (ASTM 4)/ 5000 g (ASTM 4)

after adjustment with internal weight

determined at 5% load, k = 2

9.3.1.5 Readability 10 mg, with SmartPan weighing pan

	XPR1202S	XPR2002S	XPR4002S
Limit values		<u>'</u>	
Capacity	1210 g	2.1 kg	4.1 kg
Nominal load	1200 g	2 kg	4 kg
Readability	10 mg	10 mg	10 mg
Capacity of fine range	-	-	-
Readability in fine range	-	-	-
Repeatability	8 mg	8 mg	8 mg
Repeatability in fine range	-	-	-
Linearity deviation	20 mg	20 mg	20 mg
Eccentricity deviation (at test load)	20 mg (500 g)	30 mg (1 kg)	30 mg (2 kg)
Sensitivity offset (at nominal load) 1)	60 mg	60 mg	60 mg
Sensitivity temperature drift	0.0003%/°C	0.0003%/°C	0.0003%/°C
Typical values			
Repeatability	4 mg	4 mg	4 mg
Repeatability in fine range	-	-	-
Linearity deviation	6 mg	6 mg	6 mg
Eccentricity deviation (at test load)	6 mg (500 g)	10 mg (1 kg)	10 mg (2 kg)
Sensitivity offset (at nominal load) 1)	12 mg	25 mg	16 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	8.2 g	8.2 g	8.2 g
Minimum weight (tolerance = 1%)	820 mg	820 mg	820 mg
Settling time	1.2 s	1.2 s	1.2 s
Dimensions & other specifications			
Balance dimensions (W×D×H)	194×411×102 mm	194×411×102 mm	194×411×102 mm
Weighing pan dimensions (W×D)	172×205 mm	172×205 mm	172×205 mm
Usable height of draft shield	-	-	-
Balance weight	8.2 kg	8.2 kg	8.2 kg
Weights for routine testing			
Weights (OIML class)	50 g (F2)/ 1000 g (F2)	100 g (F2)/ 2000 g (F2)	200 g (F2)/ 2000 g (F2)
Weights (ASTM class)	50 g (ASTM 1)/ 1000 g (ASTM 1)	100 g (ASTM 1)/ 2000 g (ASTM 1)	200 g (ASTM 4)/ 2000 g (ASTM 4)

after adjustment with internal weight

determined at 5% load, k = 2

	XPR6002S	XPR6002SDR
Limit values		
Capacity	6.1 kg	6.1 kg
Nominal load	6 kg	6 kg
Readability	10 mg	100 mg
Capacity of fine range	-	1200 g
Readability in fine range	-	10 mg
Repeatability	8 mg	60 mg
Repeatability in fine range	-	8 mg
Linearity deviation	20 mg	60 mg
Eccentricity deviation (at test load)	30 mg (2 kg)	100 mg (2 kg)
Sensitivity offset (at nominal load) 1)	60 mg	150 mg
Sensitivity temperature drift	0.0003%/°C	0.0003%/°C
Typical values		
Repeatability	4 mg	40 mg
Repeatability in fine range	-	5 mg
Repeatability (at 5% load)	-	-
Linearity deviation	6 mg	20 mg
Eccentricity deviation (at test load)	10 mg (2 kg)	30 mg (2 kg)
Sensitivity offset (at nominal load) 1)	12 mg	30 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	8.2 g	82 g
Minimum weight (tolerance = 1%)	820 mg	8.2 g
Settling time	1.2 s	1.2 s
Dimensions & other specifications		
Balance dimensions (W×D×H)	194×411×102 mm	194×411×102 mm
Weighing pan dimensions (W×D)	172×205 mm	172×205 mm
Usable height of draft shield	-	-
Balance weight	8.2 kg	8.2 kg
Weights for routine testing		
Weights (OIML class)	200 g (F2)/ 5000 g (F2)	200 g (F2)/ 5000 g (F2)
Weights (ASTM class)	200 g (ASTM 4)/ 5000 g (ASTM 4)	200 g (ASTM 4)/ 5000 g (ASTM 4)

after adjustment with internal weight

determined at 5% load, k = 2

	XPR8002S	XPR10002S
Limit values		
Capacity	8.1 kg	10.1 kg
Nominal load	8 kg	10 kg
Readability	10 mg	10 mg
Capacity of fine range	-	-
Readability in fine range	-	-
Repeatability	8 mg	8 mg
Repeatability in fine range	-	-
Linearity deviation	20 mg	20 mg
Eccentricity deviation (at test load)	40 mg (5 kg)	40 mg (5 kg)
Sensitivity offset (at nominal load) 1)	60 mg	50 mg
Sensitivity temperature drift	0.00025%/°C	0.00025%/°C
Typical values		
Repeatability	4 mg	4 mg
Repeatability in fine range	-	-
Linearity deviation	6 mg	6 mg
Eccentricity deviation (at test load)	12 mg (5 kg)	12 mg (5 kg)
Sensitivity offset (at nominal load) 1)	12 mg	12 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	8.2 g	8.2 g
Minimum weight (tolerance = 1%)	820 mg	820 mg
Settling time	1.5 s	1.5 s
Dimensions & other specifications		
Balance dimensions (W×D×H)	194×411×102 mm	194×411×102 mm
Weighing pan dimensions (W×D)	172×205 mm	172×205 mm
Usable height of draft shield	-	-
Balance weight	7.7 kg	7.7 kg
Weights for routine testing		
Weights (OIML class)	200 g (F2)/ 5000 g (F2)	500 g (F2)/ 10000 g (F2)
Weights (ASTM class)	200 g (ASTM 4)/ 5000 g (ASTM 4)	500 g (ASTM 4)/ 10000 g (ASTM 4)

after adjustment with internal weight

determined at 5% load, k = 2

9.3.1.6 Readability 100 mg

	XPR4001S	XPR6001S
Limit values		
Capacity	4.1 kg	6.1 kg
Nominal load	4 kg	6 kg
Readability	100 mg	100 mg
Capacity of fine range	-	-
Readability in fine range	-	-
Repeatability	80 mg	80 mg
Repeatability in fine range	-	-
Linearity deviation	60 mg	60 mg
Eccentricity deviation (at test load)	200 mg (2 kg)	200 mg (2 kg)
Sensitivity offset (at nominal load) 1)	240 mg	240 mg
Sensitivity temperature drift	0.0015%/°C	0.0015%/°C
Typical values		
Repeatability	40 mg	40 mg
Repeatability in fine range	-	-
Linearity deviation	20 mg	20 mg
Eccentricity deviation (at test load)	60 mg (2 kg)	60 mg (2 kg)
Sensitivity offset (at nominal load) 1)	50 mg	50 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	82 g	82 g
Minimum weight (tolerance = 1%)	8.2 g	8.2 g
Settling time	0.8 s	0.8 s
Dimensions & other specifications		
Balance dimensions (W×D×H)	194×411×100 mm	194×411×100 mm
Weighing pan dimensions (W×D)	194×223 mm	194×223 mm
Usable height of draft shield	-	-
Balance weight	6.6 kg	6.6 kg
Weights for routine testing		
Weights (OIML class)	200 g (F2)/ 2000 g (F2)	200 g (F2)/ 5000 g (F2)
Weights (ASTM class)	200 g (ASTM 4)/ 2000 g (ASTM 4)	200 g (ASTM 4)/ 5000 g (ASTM 4)

after adjustment with internal weight

determined at 5% load, k = 2

	XPR8001S	XPR10001S
Limit values		
Capacity	8.1 kg	10.1 kg
Nominal load	8 kg	10 kg
Readability	100 mg	100 mg
Capacity of fine range	-	-
Readability in fine range	-	-
Repeatability	80 mg	80 mg
Repeatability in fine range	-	-
Linearity deviation	100 mg	100 mg
Eccentricity deviation (at test load)	200 mg (5 kg)	200 mg (5 kg)
Sensitivity offset (at nominal load) 1)	600 mg	500 mg
Sensitivity temperature drift	0.0015%/°C	0.0015%/°C
Typical values		
Repeatability	40 mg	40 mg
Repeatability in fine range	-	-
Linearity deviation	30 mg	30 mg
Eccentricity deviation (at test load)	60 mg (5 kg)	60 mg (5 kg)
Sensitivity offset (at nominal load) 1)	120 mg	120 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	82 g	82 g
Minimum weight (tolerance = 1%)	8.2 g	8.2 g
Settling time	1 s	1 s
Dimensions & other specifications		
Balance dimensions (W×D×H)	194×411×100 mm	194×411×100 mm
Weighing pan dimensions (W×D)	194×223 mm	194×223 mm
Usable height of draft shield	-	-
Balance weight	6.6 kg	6.6 kg
Weights for routine testing		
Weights (OIML class)	200 g (F2)/ 5000 g (F2)	500 g (F2)/ 10000 g (F2)
Weights (ASTM class)	200 g (ASTM 4)/ 5000 g (ASTM 4)	500 g (ASTM 4)/ 10000 g (ASTM 4)

after adjustment with internal weight

determined at 5% load, k = 2

9.3.2 Comparators with S weighing platform

9.3.2.1 Redability 0.1 mg, with Pro draft shield

	XPR2004SC	XPR5004SC
Limit values		<u> </u>
Capacity	2.3 kg	5.1 kg
Nominal load	2 kg	5 kg
Readability	0.1 mg	0.1 mg
Capacity of fine range	-	-
Readability in fine range	_	_
Repeatability	0.6 mg	1.5 mg
Repeatability in fine range	-	-
Repeatability ABA (5 cycles at nominal load)	0.25 mg	0.5 mg
Repeatability ABA (5 cycles at 5% load)	0.1 mg	0.3 mg
Linearity deviation	1 mg	3 mg
Eccentricity deviation (at test load)	2 mg (1000 g)	10 mg (2 kg)
Eccentricity deviation with LevelMatic or hanging pan (at test load)	0 mg (1000 g)	0 mg (2 kg)
Sensitivity offset (at nominal load) 1)	10 mg	12.5 mg
Sensitivity temperature drift	0.0003%/°C	0.0003%/°C
Typical values		
Repeatability	0.3 mg	1 mg
Repeatability in fine range	-	-
Repeatability ABA (5 cycles at nominal load)	0.15 mg	0.4 mg
Repeatability ABA (5 cycles at 5% load)	0.1 mg	0.3 mg
Linearity deviation	0.5 mg	1.8 mg
Eccentricity deviation (at test load)	0 mg (1000 g)	0 mg (2 kg)
Sensitivity offset (at nominal load) 1)	6.8 mg	3 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	600 mg	2 g
Minimum weight (tolerance = 1%)	60 mg	200 mg
Settling time	3.5 s	10 s
Dimensions & other specifications		
Balance dimensions (W×D×H)	214×411×368 mm	214×411×368 mm
Weighing pan dimensions (W×D)	ø 126 mm	ø 126 mm
Usable height of draft shield	235 mm	235 mm
Balance weight	8.6 kg	8.7 kg
Weights for routine testing		
Weights (OIML class)	100 g (F2)/ 2000 g (F2)	200 g (F2)/ 5000 g (F2)
Weights (ASTM class)	100 g (ASTM 1)/ 2000 g (ASTM 1)	200 g (ASTM 4)/ 5000 g (ASTM 4)

after adjustment with internal weight

determined at 5% load, k = 2

2)

9.3.2.2 Readability 1 mg

	XPR2003SC	XPR5003SC	XPR10003SC
Limit values			
Capacity	2.3 kg	5.1 kg	10.1 kg
Nominal load	2 kg	5 kg	10 kg
Readability	1 mg	1 mg	1 mg
Capacity of fine range	-	-	-
Readability in fine range	-	-	-
Repeatability	1 mg	2 mg	3.5 mg
Repeatability in fine range	-	-	-
Repeatability ABA (5 cycles at nominal load)	0.8 mg	0.8 mg	1.5 mg
Repeatability ABA (5 cycles at 5% load)	0.6 mg	0.7 mg	1.2 mg
Linearity deviation	2 mg	3 mg	7 mg
Eccentricity deviation (at test load)	4 mg (1000 g)	10 mg (2 kg)	20 mg (5 kg)
Eccentricity deviation with LevelMatic or hanging pan (at test load)	0 g (1000 g)	0 mg (2 kg)	0 mg (5 kg)
Sensitivity offset (at nominal load) 1)	10 mg	12.5 mg	50 mg
Sensitivity temperature drift	0.0003%/°C	0.0003%/°C	0.00025%/°C
Typical values			
Repeatability	0.6 mg	1 mg	2 mg
Repeatability in fine range	-	-	-
Repeatability ABA (5 cycles at nominal load)	0.5 mg	0.5 mg	0.8 mg
Repeatability ABA (5 cycles at 5% load)	0.6 mg	0.7 mg	1.2 mg
Linearity deviation	0.7 mg	1.8 mg	3.2 mg
Eccentricity deviation (at test load)	2.6 mg (1000 g)	0 mg (2 kg)	0 mg (5 kg)
Sensitivity offset (at nominal load) 1)	6.8 mg	3 mg	34 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	1.2 g	2 g	4 g
Minimum weight (tolerance = 1%)	120 mg	200 mg	400 mg
Settling time	3.5 s	3.5 s	3.5 s
Dimensions & other specifications			
Balance dimensions (W×D×H)	214×411×368 mm	214×411×368 mm	214×411×368 mm
Weighing pan dimensions (W×D)	68×68 mm	ø 126 mm	ø 126 mm
Usable height of draft shield	245 mm	235 mm	-
Balance weight	8.7 kg	8.7 kg	5.7 kg
Weights for routine testing			
Weights (OIML class)	10 g (F2)/ 200 g (F2)	20 g (F2)/ 500 g (F2)	20 g (F2)/ 500 g (F2)
Weights (ASTM class)	10 g (ASTM 1)/ 200 g (ASTM 1)	20 g (ASTM 1)/ 500 g (ASTM 1)	20 g (ASTM 1)/ 500 g (ASTM 1)

after adjustment with internal weight

determined at 5% load, k = 2

9.3.3 Balances with L weighing platform

9.3.3.1 Readability 10 mg, with SmartPan weighing pan

	XPR15002L	XPR20002LDR
Limit values		'
Capacity	15.1 kg	20.1 kg
Nominal load	15 kg	20 kg
Readability	10 mg	100 mg
Capacity of fine range	-	4.2 kg
Readability in fine range	-	10 mg
Repeatability	15 mg	80 mg
Repeatability in fine range	-	30 mg
Linearity deviation	20 mg	60 mg
Eccentricity deviation (at test load)	80 mg (5 kg)	120 mg (10 kg)
Sensitivity offset (at nominal load) 1)	60 mg	100 mg
Sensitivity temperature drift	0.0015%/°C	0.0015%/°C
Typical values		
Repeatability	10 mg	60 mg
Repeatability in fine range	-	18 mg
Linearity deviation	6 mg	20 mg
Eccentricity deviation (at test load)	25 mg (5 kg)	40 mg (10 kg)
Sensitivity offset (at nominal load) 1)	12 mg	25 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	20 g	120 g
Minimum weight (tolerance = 1%)	2 g	12 g
Settling time	1.5 s	1.5 s
Dimensions & other specifications		
Balance dimensions (W×D×H)	360×435×147 mm	360×435×147 mm
Weighing pan dimensions (W×D)	205×172 mm	205×172 mm
Usable height of draft shield	-	-
Balance weight	12.7 kg	12.7 kg
Weights for routine testing		
Weights (OIML class)	500 g (F2)/ 10000 g (F2)	1000 g (F2)/ 20000 g (F2)
Weights (ASTM class)	500 g (ASTM 4)/ 10000 g (ASTM 4)	1000 g (ASTM 4)/ 20000 g (ASTM 4)

after adjustment with internal weight

determined at 5% load, k = 2

9.3.3.2 Readability 100 mg

	XPR10001L	XPR16001L
Limit values		'
Capacity	10.1 kg	16.1 kg
Nominal load	10 kg	16 kg
Readability	100 mg	100 mg
Capacity of fine range	-	-
Readability in fine range	-	-
Repeatability	80 mg	80 mg
Repeatability in fine range	-	-
Linearity deviation	200 mg	200 mg
Eccentricity deviation (at test load)	300 mg (5 kg)	300 mg (5 kg)
Sensitivity offset (at nominal load) 1)	500 mg	800 mg
Sensitivity temperature drift	0.0015%/°C	0.0015%/°C
Typical values		
Repeatability	40 mg	40 mg
Repeatability in fine range	-	-
Linearity deviation	60 mg	60 mg
Eccentricity deviation (at test load)	100 mg (5 kg)	100 mg (5 kg)
Sensitivity offset (at nominal load) 1)	120 mg	200 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	82 g	82 g
Minimum weight (tolerance = 1%)	8.2 g	8.2 g
Settling time	1.5 s	1.5 s
Dimensions & other specifications		
Balance dimensions (W×D×H)	360×434×122 mm	360×434×122 mm
Weighing pan dimensions (W×D)	360×280 mm	360×280 mm
Usable height of draft shield	-	-
Balance weight	10.3 kg	10.3 kg
Weights for routine testing		
Weights (OIML class)	500 g (F2)/ 10000 g (F2)	500 g (F2)/ 10000 g (F2)
Weights (ASTM class)	500 g (ASTM 4)/ 10000 g (ASTM 4)	500 g (ASTM 4)/ 10000 g (ASTM 4)

after adjustment with internal weight

determined at 5% load, k = 2

	XPR32001L	XPR64001L
Limit values		
Capacity	32.1 kg	64.1 kg
Nominal load	32 kg	64 kg
Readability	100 mg	100 mg
Capacity of fine range	-	-
Readability in fine range	-	-
Repeatability	80 mg	100 mg
Repeatability in fine range	-	-
Linearity deviation	300 mg	500 mg
Eccentricity deviation (at test load)	300 mg (10 kg)	500 mg (20 kg)
Sensitivity offset (at nominal load) 1)	960 mg	1.28 g
Sensitivity temperature drift	0.001%/°C	0.001%/°C
Typical values		
Repeatability	40 mg	40 mg
Repeatability in fine range	-	-
Linearity deviation	100 mg	150 mg
Eccentricity deviation (at test load)	100 mg (10 kg)	150 mg (20 kg)
Sensitivity offset (at nominal load) 1)	250 mg	300 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	82 g	82 g
Minimum weight (tolerance = 1%)	8.2 g	8.2 g
Settling time	1.5 s	1.8 s
Dimensions & other specifications		
Balance dimensions (W×D×H)	360×434×122 mm	360×434×122 mm
Weighing pan dimensions (W×D)	360×280 mm	360×280 mm
Usable height of draft shield	-	-
Balance weight	10.3 kg	12 kg
Weights for routine testing		
Weights (OIML class)	1000 g (F2)/ 20000 g (F2)	2000 g (F2)/ 50000 g (F2)
Weights (ASTM class)	1000 g (ASTM 4)/ 20000 g (ASTM 4)	2000 g (ASTM 4)/ 50000 g (ASTM 4)

after adjustment with internal weight

determined at 5% load, k = 2

9.3.3.3 Readability 1 g

	XPR32000L	XPR64000L
Limit values		
Capacity	32.1 kg	64.1 kg
Nominal load	30 kg	60 kg
Readability	1 g	1 g
Capacity of fine range	-	-
Readability in fine range	-	-
Repeatability	600 mg	600 mg
Repeatability in fine range	-	-
Linearity deviation	600 mg	600 mg
Eccentricity deviation (at test load)	1 g (10 kg)	1 g (20 kg)
Sensitivity offset (at nominal load) 1)	1.6 g	1.92 g
Sensitivity temperature drift	0.0015%/°C	0.0015%/°C
Typical values		
Repeatability	400 mg	400 mg
Repeatability in fine range	-	-
Linearity deviation	200 mg	200 mg
Eccentricity deviation (at test load)	300 mg (10 kg)	300 mg (20 kg)
Sensitivity offset (at nominal load) 1)	320 mg	320 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	820 g	820 g
Minimum weight (tolerance = 1%)	82 g	82 g
Settling time	1.2 s	1.5 s
Dimensions & other specifications		
Balance dimensions (W×D×H)	360×434×122 mm	360×434×122 mm
Weighing pan dimensions (W×D)	360×280 mm	360×280 mm
Usable height of draft shield	-	-
Balance weight	10.3 kg	12 kg
Weights for routine testing		
Weights (OIML class)	1000 g (F2)/ 20000 g (F2)	2000 g (F2)/ 50000 g (F2)
Weights (ASTM class)	1000 g (ASTM 4)/ 20000 g (ASTM 4)	2000 g (ASTM 4)/ 50000 g (ASTM 4)

after adjustment with internal weight

determined at 5% load, k = 2

9.3.4 Comparators with L weighing platform

9.3.4.1 Redability 1 mg

	XPR26003LC
Limit values	
Capacity	26.1 kg
Nominal load	26 kg
Readability	1 mg
Capacity of fine range	-
Readability in fine range	-
Repeatability	6 mg
Repeatability in fine range	-
Repeatability ABA (5 cycles at nominal load)	2.5 mg
Repeatability ABA (5 cycles at 5% load)	2 mg
Linearity deviation	20 mg
Eccentricity deviation (at test load)	300 mg (10 kg)
Eccentricity deviation with LevelMatic or hanging pan (at test load)	0 mg (10 kg)
Sensitivity offset (at nominal load) 1)	200 mg
Sensitivity temperature drift	0.0003%/°C
Typical values	
Repeatability	4 mg
Repeatability in fine range	-
Repeatability ABA (5 cycles at nominal load)	2 mg
Repeatability ABA (5 cycles at 5% load)	2 mg
Linearity deviation	11.4 mg
Eccentricity deviation (at test load)	0 mg (10 kg)
Sensitivity offset (at nominal load) 1)	140 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	8 g
Minimum weight (tolerance = 1%) ²⁾	800 mg
Settling time	8 s
Dimensions & other specifications	
Balance dimensions (W×D×H)	360×280×185 mm
Weighing pan dimensions (W×D)	ø 220 mm
Usable height of draft shield	-
Balance weight	13.7 kg
Weights for routine testing	
Weights (OIML class)	10 g (F2)/ 200 g (F2)
Weights (ASTM class)	10 g (ASTM 1)/ 200 g (ASTM 1)

after adjustment with internal weight

determined at 5% load, k = 2

9.3.4.2 Readability 5 mg

	XPR32003LD5C	XPR64003LD5C
Limit values		
Capacity	32.1 kg	64.1 kg
Nominal load	32 kg	64 kg
Readability	5 mg	5 mg
Capacity of fine range	-	-
Readability in fine range	-	-
Repeatability	15 mg	15 mg
Repeatability in fine range	-	-
Repeatability ABA (5 cycles at nominal load)	8 mg	8 mg
Repeatability ABA (5 cycles at 5% load)	5 mg	5 mg
Linearity deviation	20 mg	50 mg
Eccentricity deviation (at test load)	250 mg (10 kg)	500 mg (20 kg)
Eccentricity deviation with LevelMatic or hanging pan (at test load)	0 g (10 kg)	0 g (20 kg)
Sensitivity offset (at nominal load) 1)	320 mg	1.6 g
Sensitivity temperature drift	0.0003%/°C	0.0005%/°C
Typical values		
Repeatability	6.5 mg	10 mg
Repeatability in fine range	-	-
Repeatability ABA (5 cycles at nominal load)	5 mg	7 mg
Repeatability ABA (5 cycles at 5% load)	5 mg	5 mg
Linearity deviation	18 mg	28 mg
Eccentricity deviation (at test load)	160 mg (10 kg)	0 g (20 kg)
Sensitivity offset (at nominal load) 1)	140 mg	650 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	13 g	20 g
Minimum weight (tolerance = 1%)	1.3 g	2 g
Settling time	8 s	8 s
Dimensions & other specifications		
Balance dimensions (W×D×H)	360×280×122 mm	360×280×185 mm
Weighing pan dimensions (W×D)	360×280 mm	ø 220 mm
Usable height of draft shield	-	-
Balance weight	12.1 kg	13.7 kg
Weights for routine testing		
Weights (OIML class)	100 g (F2)/ 2000 g (F2)	200 g (F2)/ 5000 g (F2)
	100 g (ASTM 1)/ 2000 g (ASTM 1)	

after adjustment with internal weight

determined at 5% load, k = 2

9.3.4.3 Readability 10 mg

	XPR64002LC	XPR64002LC-T
Limit values		
Capacity	64.1 kg	64.1 kg
Nominal load	64 kg	64 kg
Readability	10 mg	10 mg
Capacity of fine range	-	-
Readability in fine range	-	-
Repeatability	35 mg	35 mg
Repeatability in fine range	-	-
Repeatability ABA (5 cycles at nominal load)	25 mg	25 mg
Repeatability ABA (5 cycles at 5% load)	10 mg	10 mg
Linearity deviation	50 mg	50 mg
Eccentricity deviation (at test load)	400 mg (20 kg)	500 mg (20 kg)
Eccentricity deviation with LevelMatic or hanging pan (at test load)	0 g (20 kg)	0 g (20 kg)
Sensitivity offset (at nominal load) 1)	1.6 g	1.6 g
Sensitivity temperature drift	0.0003%/°C	0.0003%/°C
Typical values		·
Repeatability	18 mg	18 mg
Repeatability in fine range	-	-
Repeatability ABA (5 cycles at nominal load)	20 mg	7 mg
Repeatability ABA (5 cycles at 5% load)	10 mg	10 mg
Linearity deviation	28 mg	28 mg
Eccentricity deviation (at test load)	240 mg (20 kg)	240 mg (20 kg)
Sensitivity offset (at nominal load) 1)	650 mg	650 mg
Minimum weight (USP, tolerance = 0.10%) ²⁾	36 g	36 g
Minimum weight (tolerance = 1%)	3.6 g	3.6 g
Settling time	8 s	8 s
Dimensions & other specifications		
Balance dimensions (W×D×H)	360×280×122 mm	360×280×122 mm
Weighing pan dimensions (W×D)	360×280 mm	360×280 mm
Usable height of draft shield	-	-
Balance weight	12.1 kg	12.1 kg
Weights for routine testing		
Weights (OIML class)	100 g (F2)/ 2000 g (F2)	100 g (F2)/ 2000 g (F2)
Weights (ASTM class)	100 g (ASTM 1)/ 2000 g (AST	M 1) 100 g (ASTM 1)/ 2000 g (ASTM 1

after adjustment with internal weight


determined at 5% load, k = 2

9.4 Dimensions

9.4.1 Balances with S weighing platform


9.4.1.1 Readability 0.1 mg, with Pro draft shield and SmartPan weighing pan

Models: XRP204S, XPR404S, XPR504S, XPR504SDR




9.4.1.2 Readabilty 1 mg, with Pro draft shield and SmartPan weighing pan

Models: XPR303S, XPR603S, XPR603SDR, XPR1203S, XPR3003S, XPR5003S




9.4.1.3 Readabilty 1 mg, with SmartPan weighing pan

Models: XPR303SN, XPR603SN, XPR603SNDR




9.4.1.4 Readabilty 5 mg / 10 mg, with SmartPan weighing pan

Models: XPR3003SD5, XPR6003SD5, XPR1202S, XPR2002S, XPR4002S, XPR6002SDR, XPR8002S, XPR10002S



9.4.1.5 Readability 100 mg


Models: XPR4001S, XPR6001S, XPR8001S, XPR10001S



9.4.2 Comparators with S weighing platform


9.4.2.1 Readability 0.1 mg, with Pro draft shield and LevelMatic weighing pan

Models: XPR2004SC, XPR5004SC



9.4.2.2 Readability 1 mg, with Pro draft shield and LevelMatic weighing pan

Models: XPR5003SC




9.4.2.3 Readability 1 mg, with XP-W12 draft shield and LevelMatic weighing pan

Position of the weighing hook axle


Models: XPR10003SC

3



9.4.2.4 Readability 1 mg, with Pro draft shield


Models: XPR2003SC



9.4.3 Balances with L weighing platform


9.4.3.1 Readability 10 mg, with SmartPan weighing pan

Models: XPR15002L, XPR20002LDR



9.4.3.2 Readability 100 mg / 1 g


Models: XPR10001L, XPR16001L, XPR32001L, XPR64001L, XPR32000L, XPR64000L



9.4.4 Comparators with L weighing platform


9.4.4.1 Readability 1 mg / 5 mg, with XP-W64 draft shield and LevelMatic weighing pan

Models: XPR26003LC, XPR64003LD5C




9.4.4.2 Readability 5 mg / 10 mg


Models: XPR32003LD5C, XPR64002LC



9.4.5 Draft shield XP-W12 (for models with S weighing platform)



9.4.6 Draft shield XP-W64 (for models with L weighing platform))



10 Disposal

In conformance with the European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE) this device may not be disposed of in domestic waste. This also applies to countries outside the EU, per their specific requirements.



Please dispose of this product in accordance with local regulations at the collecting point specified for electrical and electronic equipment. If you have any questions, please contact the responsible authority or the distributor from which you purchased this device. Should this device be passed on to other parties, the content of this regulation must also be related.

11 Accessories and Spare Parts

11.1 Accessories

	Description	Part No.
Density determination	n	
	Density kit	30300933
â	Sinker 10 mL	210260
*	Calibrated Sinker 10mL	210672
Ô		
	Calibrated Thermometer	11132685
Printers		
	P-52RUE dot matrix printer RS232C, USB and Ethernet connections, simple print-outs	30237290
	Paper roll (length: 20 m), set of 5 pcs	00072456
-/	Paper roll (length: 13 m), self-adhesive, set of 3 pcs	11600388
	Ribbon cartridge, black, set of 2 pcs	00065975
LE MI	P-56RUE thermal printer with RS232C, USB and Ethernet connections, simple print-outs, date and time	30094673

Paper roll, white (length: 27 m), set of 10 pcs

of 10 pcs

Paper roll, white, self-adhesive (length: 13 m), set

30094723

30094724



P-58RUE thermal printer with RS232C, USB and Ethernet				
connections, simple print-outs, date and time, label printing,				
palance applications, e.g., statistics, formulation, totaling, SQC				
Paper roll, white (length: 27 m), set of 10 pcs				

30094674

Paper roll, white (length: 27 m), set of 10 pcs 30094723 Paper roll, white, self-adhesive (length: 13 m), set 30094724

of 10 pcs

Paper roll, white, self-adhesive labels (550 labels), set of 6 pcs

30094725

Dimension of the label 56×18 mm



Citizen CLS631 label printer

11141820

Anti-theft devices



Anti-theft cable with lock

11600361

Barcode readers



Corded USB barcode reader

30417466

Draft shields



Pro draft shield for 0.1 mg and 1 mg models, height: 248 mm

30300926



Pro draft shield glass free (food industry) for 0.1 mg and 1 mg models, height: 248 mm

30409092




MagicCube draft shield for 1 mg models, height: 175 mm

30300928





Bullion Weighing Kit to load or unload heavy items, only for 30300944 models with L weighing platform



MPS (Magnetic Protection Shield) weighing pan for 0.1 g models 190 × 223 mm, "S" platform

11132625

Cables for RS232C interface



USB-RS232 cable (to connect a balance via RS232C to a USB port)

64088427



USB-RS232 cable with null modem (to connect peripherals via RS232C to a balance)

30364315

Antistatic kits



Universal AntiStatic Kit complete (U-shaped), including electrode and power supply

11107767

Optional: Second U-electrode* for universal AntiStatic Kit 11107764 * Power supply for optional, second U-elektrode (11107764) 11107766

30499859



Compact ionizer with stand (USB)



Additional compact ionizer (USB) for Compact ionizer with stand (30499859)

30496446

Hands-free accessories



Foot switch, optional switch for remote operation (USB connection)

30312558



ErgoSens, optical sensor for remote operation (USB connection)

30300915

Wireless interfaces



Bluetooth RS232C serial adapter ADP-BT-S for wireless connection between:

30086494

- Balance and PC (depending on the balance model)
- Printer and balance



Bluetooth USB adapter for wireless connection to P-5x printer (additional Bluetooth RS232 serial adapter 30086494 required)

30416089

Filling-process control



LV12 automatic feeder


30374389



LV12 Pro draft shield door for 0.1 mg and 1 mg models with S weighing platform

11132711

Software




LabX balance express (standalone system)

11153120



LabX balance server (server edition)

11153121



MC Link mass calibration software

MC Link license – 1 Instrument	30208285
MC Link Upgrade Multi Place	30208289
MC Link Option – Barcode Package	30212767
MC Link Option — Audit Trail	30208283
MC Link Validation Handbook	30212634
MC Link Remote Installation Service	30212635

Various



EasyHub USB 30468768



Protective cover for XPR terminal 30125377



Terminal cable, extended, length: 4.5 m 30300920



USB (A - B) cable for connection to PC (length: 1 m) 12310716



Transport case for 5 mg, 10 mg and 100 mg models, S platform

11132565

30113497



Hook for Platform L


30061260



SmartPrep, single-use funnel for quick and easy sample preparation. For flask sizes 10/19, 12/21, 14/23. 50 pcs

11.2 Spare parts

11.2.1 Balances S weighing platform



	Pos.	Description	Models	Part No.
5 mg / 10 mg	1	Protective cover for weighing pan (172 x 205 mm)	5 mg / 10 mg	30106207
	2	Weighing pan (172 x 205 mm)	5 mg / 10 mg	30215056
	3	SmartPan weighing pan (172 x 205 mm)	5 mg / 10 mg	30215057
	4	DripTray	5 mg / 10 mg	30113501
1——	5	Stop screws (2 pieces)	5 mg / 10 mg	30215373
2	6	Weighing pan support cap	5 mg / 10 mg	11131029
	7	Platform protective cover	5 mg / 10 mg	30300966
3	8	Protective cover for weighing pan (190 x 223 mm)	100 mg	30106204
4	9	Weighing pan (190 x 223 mm)	100 mg	11131031
5	10	Weighing pan support	100 mg	11131037
6	11	Weighing pan support cap	100 mg	11131029
7	12	Stop screw (2 pieces)	100 mg	11131073
	13	Fastening plate	100 mg	11131067
100 mg				
9				
10				
11 12 13				
14				

11.2.2 Comparators S weighing platform

	Pos.	Description	Models	Part No.
0.1 mg, 1 mg	1	LevelMatic weighing pan complete	0.1 mg, 1 mg	11131123
	2	Protective cover for weighing platform	0.1 mg, 1 mg	30300967
	3	Weighing pan (127 x 127 mm)	1 mg	30215433
	4	SmartPan weighing pan (127 x 127 mm)	1 mg	30215431
1	5	DripTray	1 mg	30416102
2	6	Protective cover for weighing platform	1 mg	30300967
1 mg				

11.2.3 S Platform miscellaneous

	Pos.	Description	Models	Part No.
	1	Protective cover for XPR terminal	all models	30125377
1——	2	XPR terminal	all models	30317506
	3	Terminal connection cable	all models	30416123
2——	4	Terminal holder	all models	30215058
	5	Leveling foot	all models	30072531
	6	AC/DC Power adapter	all models	30388323
	7	Country-specific power cable	all models	
		Power cable AU	all models	00088751
3		Power cable BR	all models	30015268
		Power cable CH	all models	00087920
^ ^		Power cable CN	all models	30047293
		Power cable DK	all models	00087452
		Power cable EU	all models	00087925
		Power cable GB	all models	00089405
2		Power cable IL	all models	00225297
4		Power cable IN	all models	11600569
		Power cable IT	all models	00087457
A		Power cable JP	all models	11107881
5 ————		Power cable TH, PE	all models	11107880
and the second s		Power cable US	all models	00088668
		Power cable ZA	all models	00089728
6				
7				

11.2.4 Balances L weighing platform

	Pos.	Description	Models	Part No.
10 mg	1	Protective cover for weighing pan (172 x 205 mm)	10 mg	30106207
1	2	Weighing pan (172 x 205 mm)	10 mg	30215056
2	3	SmartPan weighing pan (172 x 205 mm)	10 mg	30215057
3	4	Draft shield element	10 mg	30215365
	5	Adapter plate	10 mg	30215366
	6	Weighing pan support cap	10 mg	11131029
	7	Adapter plate support cap	10 mg	30416106
	8	Weighing pan (280 x 360 mm)	100 mg, 1 g	239105
5 6 9	8	Weighing pan (280 x 360 mm) for balances with capacity of 64 kg	100 mg, 1 g	11102124
	9	Weighing pan support cap	100 mg, 1 g	30416105
	9	Weighing pan support cap for balances with capacity of 64 kg	100 mg, 1 g	30416107
100 mg / 1 g				
9				

11.2.5 Comparators L weighing platform

	Pos.	Description	Models	Part No.
	1	LevelMatic complete	1 mg, 5 mg, 10 mg	11120415
1	2	Pan support for LevelMatic	1 mg, 5 mg, 10 mg	11120418
	3	Weighing pan (280 x 360 mm)	1 mg, 5 mg, 10 mg	00239105
	3	Weighing pan (280 x 360 mm) for models with a capacity of 64 kg	5 mg, 10 mg	11102124
	4	Weighing pan support cap	1 mg, 5 mg, 10 mg	00239104
	4	Weighing pan support cap for models with a capacity of 64 kg	5 mg, 10 mg	30416107
3				

11.2.6 L platform miscellaneous


	Pos.	Description	Models	Part No.
	1	Protective cover for XPR terminal	all models	30125377
1——	2	XPR terminal	all models	30317506
	3	Terminal connection cable	all models	30416123
2——	4	Terminal holder	all models	30215058
	5	AC/DC Power adapter	all models	30388323
	6	Country-specific power cable	all models	
		Power cable AU	all models	00088751
		Power cable BR	all models	30015268
3		Power cable CH	all models	00087920
S		Power cable CN	all models	30047293
		Power cable DK	all models	00087452
		Power cable EU	all models	00087925
		Power cable GB	all models	00089405
		Power cable IL	all models	00225297
		Power cable IN	all models	11600569
		Power cable IT	all models	00087457
4		Power cable JP	all models	11107881
		Power cable TH, PE	all models	11107880
		Power cable US	all models	00088668
_		Power cable ZA	all models	00089728
6				
We He				

11.2.7 Pro draft shield

	Pos	Description	Part No.
		Pro draft shield complete	30300926
3	1	Door front left	11133080
	2	Door back left	11133079
2 83:39	3	Door top front	11133082
	4	Door top back	11133081
4	5	Door back right	11133077
	6	Door front right	11133078
7	7	Ring seal, for models with 0.1 mg	11131551


11.2.8 Packaging

11.2.8.1 S platform with draft shield




	Order no.	Designation	Remarks
1	30416124	Packaging complete	_
2	30416157	Packaging complete XPR pro draft shield	_
3	30416158	Packaging XSR Magic cube draft shield	_
4	30416159	Export carton XPR, XSR draft shield	_
5	30416156	Export carton	_

11.2.8.2 S platform without draft shield




	Order no.	Designation	Remarks
1	30416160	Packaging complete	-
2	30416161	Export carton	_

11.2.8.3 L platform, readability 10 mg



		Order no.	Designation	Remarks
1 304		30416125	Packaging complete	_
Ì	2	30008482	Export carton	_

11.2.8.4 L platform, readability 100 mg and 1g



	Order no.	Designation	Remarks
1	30416162	Packaging complete	-

Index

A	Calculate target	9
AC/DC Adapter 148, 149	Calibration Certificate	78
Action when calibration expired 77	Certificate	50
Active 75	Certificate date	50
Actual weight 56	Certificate ID	50
Adding a device 63	Change history	73, 7
Adjustment	Cleaning the draft shield	14
External 62, 63	Cloning a method	52
Internal 62	Comment	86, 97, 106, 114, 117, 129
Adjustments 61	Concentration unit	9
Alibi memory 72	Configure method	7:
Allowed number of errors until blocking 132, 134, 137	Configure routine tests / GWI	
Allowed units 79	Configure system	7(
As found test 138	Configure user management	
As left test 139	Control limit	131, 134, 137, 13
Assigned groups 75	Conventions and symbols	_
Automatic export directory 82	Creating new user	6
Automatic feeder support 91	Creating test	5
Automatic label printout for task 94, 95, 103, 104, 112, 122, 123	Custom units D	8
Automatic log off 74	Date	8
Automatic print 131, 133, 136, 138	Date format	8
Automatic result 92, 110, 120	Days before expiration	7:
Automatic tare after result 93, 102, 110, 120	Decimal delimiter	8
Automatic task completion 93, 102	Default gateway	8:
Automatic zero 92, 101, 109, 119	Default value Result ID	87, 99, 106, 118, 12i
В	Default value Task ID	87, 98, 106, 115, 118, 120
Balance ID 82	Defining templates	5
Balance info 74	Deleting a method	55
Balance information 94, 103, 111, 121, 130	Density determination	
Balance menu 22, 71	Performing a method	5
Balance recalibration reminder 77	Density unit	12
Balance settings 76, 85	Description Result ID	87, 99, 106, 118, 12
Barcode data target 91, 101, 109, 116, 119, 129	Description Task ID	87, 98, 106, 115, 12
Barcode reader 83	Devices	8
Adding 63	Discharge feeder at the end	9
Barcode settings 95, 104, 112, 123	Display brightness	8
Block balance 132, 134, 137, 139	Display readability	79, 89
Block/unblock balance 75	Disposal	18
Blocking the balance 70	DNS server (primary)	8
C	DNS server (secondary)	8
Calculate amount of component 97	E	
Calculate concentration per component 97	Eccentricity test	5
	creating	58

settings	131	L	
Editing a method	52	Label printer	83
End of line character	80	LabX	84
Environment	78	LabX service	84
Environmental conditions	148	Language	81
Ergosens	83	Last name	75
Ethernet	82	Level indicator	21
EULA	36	Leveling aid	36
Execute external adjustment	76	Leveling the balance	36
Execute routine tests	76	Leveling warning	77
Execute service commands	75	Location	25
Expiry date	98	Lock method	
External adjustment	62, 63		86, 97, 106, 114, 117, 125 36, 69
External test weight	56	Login	36, 69 69
F		Logoff Logout	69
Factor	89	M	09
Feed rate	91		
Field delimiter	80	MAC address	83
Field settings 95, 103, 104, 112,		Main weighing screen	21
File Server	84	Method name	86, 97, 106, 114, 117, 125
Firmware update on system start-up	82	Methods	22
First name	75	Cloning	52
Foot switch	83	Deleting	53
Format	80	Editing	52
Formula	89	Methods list	43
	03	Minimum tare weight	134, 136
G		MT-SICS service	84
General Weighing	86	N	
Performing a method	44, 47	Name	
GWP Approved mode	77	Method	86, 97, 106, 114, 117, 125
Н		profile	78
	71	test	131, 133, 136
History Home	19	Net indicator	80
	83	Net indicator field length	80
Host name	03	Network configuration	83
I		Nominal weight	131, 134, 136
Indicator	78	Notification all (x) hours	132, 135, 138
Info unit 88, 100, 107,	, 115, 127	Number of items to feed	91
Internal adjustment	62	Number of repetitions	133
Interval weighing	113	Number of Result IDs	87, 98, 106, 118, 126
Introduction	7	Number of Task IDs	86, 98, 106, 114, 118, 125
IP address	83		00, 00, 100, 114, 110, 120
K		0	
		Occurrence of day	133, 135, 138
Keyboard Layout	81	Output mode	79

P		Service date reminder	78
Packing the balance	39	Settings	76, 85
Password	36	Eccentricity test	131
Password reset	75	System	76
Performing a method		Show change history	76
Density determination	52	Show info weight	88, 100, 107, 115, 127
General weighing	44, 47	Show preparation instructions	
Simple formulation	46	Sign	80
Titration	50	Sign position	80
Period	98	Signal words	12
Piece Counting	47, 105	Simple Formulation	45
Planning type	132, 135, 137	Performing a method	46
Plausibility limits	91	Software version	7
Power supply	148	Sound	0.1
Preferred days	133, 135, 138	on error	81
Prefix Result ID	87, 99, 107, 118, 126	on info	81
Prefix Task ID	87, 98, 106, 115, 118, 126	on key press	81
Pretare value	92, 101, 109, 120	on warning Sound volume	81
Printer			81
Adding	63	Standby made	82
Printers	83	Standby mode	19 <i>,</i> 37 139
Production date	98	Start after temperature chang	
Protection and standards	148	Start after temperature change Start time	
Protocol	23	Statistical evaluation	132, 135, 137, 139 90, 108, 128
R		Status light	90, 100, 128
Reference	107	Status light brightness	82
Reference average weight	107	Storing the balance	39
Reference flask volume	97	Strategy	138
Reference weight (100%)	97	Strip printer	83, 93, 102, 110, 121, 129
Repeatability test	58	Subnet mask	83
creating	55	Switch on	36
Reset password	69	Switching off the balance	37
Result calculation	131, 133, 136	Symbols and conventions	7
Result ID	87, 99, 106, 118, 126	System settings	76
RFID reader	49, 83		
RFID tag	49	T	
S		Tare	19
		Tare mode	92, 101, 109, 120
Safety information		Tare name	134, 136
Signal words	12	Target	79
Warning symbols	12	Target weight	87, 88, 99, 100, 107, 119
Sample ID	88	Task	53
Schedule	139	Task ID	87, 98, 106, 114, 118, 126
Selecting the location	25	Technical data	148
Sensitivity test	59	Template	
creating	55	defining ad-hoc	54

defining in Meth	nod	53	Warning symbols	12
Templates	100	53	Weighing data export	93, 102, 110, 116, 121
Test		22	Weighing mode	78
creating		55	Weight	
Eccentricity		57	Test weight	56
Repeatability		58	Weight capture delay	89, 108, 128
Sensitivity		59	Weight capture mode	89, 108, 128
Test activated		131, 133, 136	Weight class	56, 131, 134, 137
Test type		131, 133, 136	Weight field length	79
Test weight		56	Weight set ID	56
Test weight ID		56	Weight trigger	93, 110, 120
Test weight name		56	Weight value character outp	
Test weight recalibr	ation reminder	78	121	,,
Tests		54	Weight value output over US	SB 77
Time		81	Work screen	
Time format		81	Balance menu	20, 22
Time zone		81	Methods	20, 22
Titration		01	Protocol	20, 23
Performing a m	ethod	50	X	
Tolerance (max)		100, 107, 119		
Tolerance (min)		100, 107, 119	x hours before test	132, 135, 138
Tolerance profile		107, 115, 127	Z	
Tolerance profiles	33, .33,	77	Zero	19
Transport over long	distances	38	Zero drift compensation	79
Type plate	, 4	19		
U				
Unblocking the balo	nnca	70		
Unit	80, 87, 88, 99,			
Unit field length	00, 01, 00, 00,	80		
Unpacking		25		
Updates/sec.		80		
USB device		00		
Adding		63		
Used template	94, 95, 103, 104,			
User ID	9 4 , 90, 100, 104,	36, 75		
User language		36, 75 75		
User management		82		
Activate user ma	anagement	65		
	ser management	66		
User proposals	sei illulluyeilleill	75		
V		73		
Value release		78		
W		70		
Wait time		74, 82		
Warning limit	122	134, 137, 139		
waiting illilli	102,	107, 107, 100		



Good Weighing Practice[™]

GWP® is the global weighing standard, ensuring consistent accuracy of weighing processes, applicable to all equipment from any manufacturer It helps to:

- Choose the appropriate balance or scale
- Calibrate and operate your weighing equipment with security
- Comply with quality and compliance standards in laboratory and manufacturing

www.mt.com/GWP

www.mt.com/xpr-precision

For more information

Mettler-Toledo GmbH

Im Langacher 44 8606 Greifensee, Switzerland www.mt.com/contact

Subject to technical changes. © Mettler-Toledo GmbH 09/2019 30357075D en

